




**BU 0600 – en**

**NORDAC PRO (SK 500P)**

**Manual with installation instructions**



**Circuit diagram**



- |   |   |    |  |
|---|---|----|--|
| 1 | Power supply suitable for device (see Technical Data) | 8  | Alternative example “Digital input power supply via external power source (24 V DC)” |
| 2 | Connection message “FI Ready” (default)               | 9  | Alternative example “PTC connected to D15”   |
| 3 | Electromechanical brake connection (default)          | 10 | Optional braking resistor  |
| 4 | Top view  | 11 | Bottom view  |
| 5 | Slot for option modules SK CU5 -..., SK TU5-CTR       | M  | Motor  |
| 6 | Setpoint (e.g. speed)                                 | 12 | Customer unit (NORDCON, Bluetooth stick, ControlBox)                                 |
| 7 | Actual value (e.g. speed)                             |    |  |

**Important: Please note the detailed description of the control terminals in the manual.**



### Read document and keep for future reference

Read this document carefully prior to performing any work on or putting the device into operation. It is essential to read and observe the instructions in this document. They serve as the prerequisite for smooth and safe operation and the fulfilment of any warranty claims.

Contact Getriebebau NORD GmbH & Co. KG if your questions regarding the handling of the device are not answered in this document or if you require further information.

The German version of this document is the original. The German document is always decisive. If this document is available in other languages, this will be a translation of the original document.

Keep this document in the vicinity of the device so that it is available if required.

Use the version of this documentation that is valid for your device at the time of delivery. You can find the currently valid version of the documentation under [www.nord.com](http://www.nord.com).

Please also note the following documents:

- Catalogue “NORDAC electronic drive technology” ([E3000](#)),
- Documentation for optional accessories
- Documentation for equipment which is attached or provided.

Please contact [Getriebebau NORD GmbH & Co. KG](#) if you require further information.

## Documentation

Designation:	BU 0600	
Part no.:	6076002	
Series:	NORDAC <i>PRO</i>	
Device series:	SK 500P, SK 510P, SK 530P, SK 550P	
Device types:	SK 5xxP-250-123- ... SK 5xxP-221-123-	(0.25 ... 2.2 kW, 1~ 230 V, Out: 3~ ...230 V)
	SK 5xxP-250-340- ... SK 5xxP-222-340-	(0.25 ... 22 kW, 3~ 400 V, Out: 3~ ...400 V)

## Version list

Title, Date	Order number	Software version of device	Remarks
BU 0600, June 2019	6076002 / 2319	V 1.0 R1	Field test version
BU 0600, March 2020	6076002 / 1020	V 1.1 R1	First edition
BU 0600, July 2021	6076002 / 3021	V 1.1 R1	<ul style="list-style-type: none"> <li>• Update of “Standards and Approvals”</li> <li>• Update of EU Declaration of Conformity</li> <li>• Supplementation of data according to the Ecodesign Directive</li> </ul>
BU 0600, August 2021	6076002 / 3221	V 1.3 R0	<ul style="list-style-type: none"> <li>• Circuit diagram integrated</li> <li>• Parameters revised <ul style="list-style-type: none"> <li>– Indication of visibility via mains voltage</li> <li>– Setting values / Arrays amended</li> </ul> </li> <li>• Operating status messages revised</li> <li>• Rotor position identification via dwell method for PMSM</li> <li>• Motor chokes supplemented</li> <li>• Supplements to EMC kits</li> </ul>
BU 0600, September 2021	6076002 / 3921	V 1.3 R0	<ul style="list-style-type: none"> <li>• Supplementation of sizes 4 – 5</li> </ul>
BU 0600, October 2022	6076002 / 4022	V 1.3 R5	<ul style="list-style-type: none"> <li>• Supplement to the section on the motor data</li> <li>• Supplement to the standby values for the UKCA</li> <li>• General corrections</li> <li>• Supplement disposal notes</li> </ul>

Table 1: Version list

## Copyright notice

As an integral component of the device described here, this document must be provided to all users in a suitable form.

Any editing or amendment or other utilisation of the document is prohibited.

## Publisher

### Getriebebau NORD GmbH & Co. KG

Getriebebau-Nord-Straße 1 • 22941 Bargteheide, Germany • <http://www.nord.com>

Fon +49 (0) 45 32 / 289-0 • Fax +49 (0) 45 32 / 289-2253

**Member of the NORD DRIVESYSTEMS Group**



## Table of Contents

<b>1</b>	<b>General</b> .....	<b>10</b>
1.1	Device characteristics .....	11
1.2	Delivery .....	14
1.3	Scope of delivery.....	14
1.4	Safety, installation and application information .....	16
1.5	Explanation of markings.....	20
1.6	Warning information on the product .....	21
1.7	Standards and approvals .....	22
1.7.1	UL and CSA approval.....	23
1.8	Type code / nomenclature.....	25
1.8.1	Name plate .....	26
<b>2</b>	<b>Assembly and installation</b> .....	<b>28</b>
2.1	Frequency inverter installation .....	29
2.2	EMC kit .....	30
2.3	Braking resistor (BR).....	33
2.3.1	Electrical data for braking resistors.....	34
2.3.2	Monitoring of the braking resistor .....	35
2.3.2.1	Monitoring with a temperature switch .....	35
2.3.2.2	Monitoring with current measurement and calculation .....	35
2.4	Chokes.....	36
2.4.1	Mains chokes.....	36
2.4.1.1	Mains choke SK CI5 .....	37
2.4.2	Motor choke SK CO5.....	38
2.5	Electrical Connection .....	39
2.5.1	Overview of connections .....	40
2.5.2	Wiring guidelines .....	42
2.5.3	Electrical connection of power unit .....	43
2.5.3.1	Electromechanical brake .....	45
2.5.3.2	Mains connection (PE, L1, L2/N, L3) .....	45
2.5.3.3	Motor cable .....	47
2.5.3.4	Braking resistor (B+, B-) .....	48
2.5.3.5	DC coupling (B+, DC-) .....	48
2.5.4	Electrical connection of the control unit .....	50
2.6	Incremental encoder .....	60
2.7	Fans.....	61
2.7.1	Removing the fan .....	61
2.7.2	Installing the fan .....	61
<b>3</b>	<b>Options</b> .....	<b>62</b>
3.1	Overview of option modules.....	62
3.2	ControlBox SK TU5-CTR .....	64
3.2.1	Control keys.....	64
3.2.2	Display.....	65
3.2.2.1	Displays .....	65
3.2.2.2	Operation .....	65
3.2.2.3	Status displays .....	66
3.2.3	Control.....	66
3.2.4	Parameterisation .....	67
3.3	Frequency addition and subtraction via control boxes .....	69
3.4	Connection of multiple devices to one parameterisation tool .....	69
<b>4</b>	<b>Commissioning</b> .....	<b>70</b>
4.1	Factory settings.....	70
4.2	Selecting the operating mode for motor control .....	72
4.2.1	Explanation of the operating modes (P300) .....	72
4.2.2	Overview of controller parameter settings .....	73
4.2.3	Motor control commissioning steps .....	74
4.3	Minimum configuration of control connections .....	75
4.4	Temperature sensors.....	76

<b>5</b>	<b>Parameter.....</b>	<b>78</b>
5.1	Parameter overview.....	82
5.1.1	Operating display.....	85
5.1.2	DS402 parameter.....	87
5.1.3	Basic parameter.....	99
5.1.4	Motor data / characteristic curve parameters.....	107
5.1.5	Control parameters.....	118
5.1.6	Control terminals.....	128
5.1.7	Additional parameters.....	157
5.1.8	Positioning.....	183
5.1.9	Information.....	184
<b>6</b>	<b>Operating status messages.....</b>	<b>199</b>
6.1	Display of messages.....	200
6.2	Messages.....	203
<b>7</b>	<b>Technical data.....</b>	<b>216</b>
7.1	General Data.....	216
7.2	Technical data for determining the energy efficiency level.....	217
7.3	Electrical data.....	219
7.3.1	Electrical data 230 V.....	219
7.3.2	Electrical data 400 V.....	221
<b>8</b>	<b>Additional information.....</b>	<b>224</b>
8.1	Setpoint processing.....	224
8.2	Process controller.....	226
8.2.1	Process controller application example.....	227
8.2.2	Process controller parameter settings.....	228
8.3	Electromagnetic compatibility (EMC).....	229
8.3.1	General Provisions.....	229
8.3.2	EMC evaluation.....	229
8.3.3	EMC of device.....	230
8.3.4	Declarations of Conformity.....	233
8.4	Reduced output power.....	235
8.4.1	Increased heat dissipation due to pulse frequency.....	235
8.4.2	Reduced overcurrent due to time.....	236
8.4.3	Reduced overcurrent due to output frequency.....	237
8.4.4	Reduced output current due to low voltage.....	239
8.4.5	Reduced output current due to the heat sink temperature.....	239
8.5	Operation on the FI circuit breaker.....	239
8.6	NORD system bus.....	240
8.6.1	Description.....	240
8.6.2	NORD system bus participants.....	242
8.6.3	Physical structure.....	242
8.7	Options for optimising the energy efficiency.....	243
8.8	Motor data – characteristic curves (Asynchronous motors).....	244
8.8.1	50 Hz characteristic curve.....	244
8.8.2	87 Hz characteristic curve (only 400V devices).....	247
8.8.3	100 Hz characteristic curve (only 400 V devices).....	249
8.9	Motor data – characteristic curves (synchronous motors).....	251
8.10	Scaling of setpoint/actual values.....	253
8.11	Definition of setpoint and actual value processing (frequencies).....	254
<b>9</b>	<b>Maintenance and servicing information.....</b>	<b>255</b>
9.1	Maintenance information.....	255
9.2	Service notes.....	256
9.3	Disposal.....	257
9.3.1	Disposal according to German law.....	257
9.3.2	Disposal outside of Germany.....	257
9.4	Abbreviations.....	258

## List of illustrations

Figure 1: Installation spacings .....	28
Figure 2: Frequency inverter with bottom-mounted braking resistor SK BRU5-.....	33
Illustration 3: Illustration of a DC-coupling .....	49
Figure 4: ControlBox menu structure .....	68
Figure 5: Motor type plate.....	71
Figure 6: Explanation of parameter description .....	81
Illustration 7: Setpoint processing.....	225
Figure 8: Process controller flow diagram .....	226
Figure 9: Wiring recommendation.....	232
Figure 10: Heat losses due to pulse frequency .....	235
Figure 11: Reduced output current due to low voltage .....	239
Figure 12: Example of the structure of a NORD system bus.....	241
Figure 13: Energy efficiency due to automatic flux optimisation .....	243
Illustration 14: Characteristic curve 50 Hz .....	244
Figure 15: 87 Hz characteristic curve .....	247
Figure 16: 100 Hz characteristic curve .....	249



## List of tables

Table 1: Version list .....	4
Table 2: Overview of FI characteristics.....	13
Table 3: Warning symbols on the product .....	21
Table 4: Standards and approvals.....	22
Table 5: Technical data bottom mounted braking resistor SK BRU5-.....	34
Table 6: Technical data chassis braking resistor SK BR2-.....	34
Table 7: Technical details of the braking resistor temperature switch .....	34
Table 8: Connection data mains side X1 .....	43
Table 9: Connection data motor side X2, X3 .....	44
Table 10: Colour and contact assignments for NORD TTL / HTL incremental encoders.....	60
Table 11: EMC comparison between EN 61800-3 and EN 55011.....	230
Table 12: EMC, max. shielded motor cable length with regard to compliance with the limit value classes .....	231
Table 13: Overview according to product standard EN 61800-3 .....	231
Table 14: Overcurrent relative to time .....	236
Table 15: Overcurrent depending on pulse and output frequency.....	238
Table 16: Scaling of set/actual values (selection).....	253
Table 17: Processing of setpoints and actual values in the frequency inverter .....	254

## 1 General

The devices have sensorless current vector control with a wide range of settings. In combination with suitable motor models, which always provide an optimised voltage/frequency ratio, all three-phase asynchronous motors that are suitable for inverter operation and permanently excited synchronous motors (IE4, IE5+) can be driven. For the drive unit, this means very high starting and overload torques with constant speed.

The power range is from 0.25 kW to 22 kW.

The device series can be adapted to individual requirements by means of modular assemblies.

This manual is based on the device software as stated in the version list (see P707). If the frequency inverter uses a different software version, this may cause differences. If necessary, the current manual can be downloaded from the Internet (<http://www.nord.com/>).

Additional descriptions exist for optional functions and bus systems (<http://www.nord.com/>).



### Information

#### Accessories

The accessories that are mentioned in the manual are also subject to changes. Current details of these are included in separate data sheets, which are listed under [www.nord.com](http://www.nord.com) under the heading *Documentation* → *Manuals* → *Electronic drive technology* → *Techn. info / Data sheet*. The data sheets available at the date of publication of this manual are listed by name in the relevant sections (TI ...).




### Information


As of firmware version 1.3R0, only processors with large memories are supported. This version is therefore not compatible with older devices and hardware status AAA (Chap. 1.8.1 "Name plate").






---

## 1.1 Device characteristics

The NORDAC *PRO* series is available in various versions. The following gives an overview of the essential characteristics of the particular versions.

Characteristic SK ...	500P/510P	530P	550P	Additional information
Operating manual	BU 0600			
<b>Legend</b>				
x =	Present		- =	Not present
			O =	Optionally available
Sensorless current vector control (high starting torque and precise control of motor speed)	x	x	x	
Asynchronous motor operation	x	x	x	
Operation of PMSM synchronous motors (Permanent Magnet Synchronous Motor)	x	x	X	
Operation permissible on network types: TN, TT, IT <sup>1)</sup>	x	x	x	(Chap. 2.5.3.2)
DC coupling / Link voltage coupling	x	x	x	(Chap. 2.5.3.5)
Brake management for mechanical holding brake	x	x	x	(Chap. 2.5.3.1)
Brake chopper (braking resistor optional)	x	x	x	(Chap. 2.5.3.4)
Integrated EMC mains filter for Class A1 / Category C2 limits	x	x	x	(Chap. 8.3)
Can be mounted next to each other without additional spacing	x	x	x	(Chap. 2)
Extensive monitoring functions	x	x	x	(Chap. 7)
Status LEDs (FI / Bus)	x / x	x / x	x / x	(Chap. 6.1)
Status LEDs ((Industrial Ethernet)	-	-	x	 <a href="#">BU 0620</a>
Stator resistance measurement	x	x	x	(Chap. 5.1.4), P220
Automatic optimisation of precise motor data	x	x	x	
Internal 24 V power supply unit to supply the control board	x	x	x <sup>2)</sup>	An additional power supply is required for the bus communication.

Characteristic SK ...	500P/510P	530P	550P	Additional information
Operating manual	BU 0600			
<b>Legend</b>				
x = Present	- = Not present		O = Optionally available	
External connection for the control board voltage 24 V DC supply with automatic switch-over between the internal and external 24 V DC power supply and supply for the Ethernet interface. <b>Note:</b> Note the restrictions for individual parameters	-	x	x	(Chap. 2.5.4)
RS-232 / -485 diagnostic interface / -485 via RJ12 connection	x	x	x	
RS-232 diagnostic interface via USB-C connection <sup>3)</sup>	-	x	x	
USS and Modbus RTU on board	x	x	x	
(CANopen ) on board	x	x	x	
Industrial Ethernet on board	-	-	x	 <a href="#">BU 0620</a>
Plug in data storage via microSD card (for exchange of parameters)	-	x	x	See "microSD-card X18" / "P550"
Parameters pre-set with standard values	x	x	x	(Chap. 5)
4 switchable parameter sets	x	x	x	
Parameterisation with NORDCON-Software, NORDCON APP or external ParameterBox SK ...-3H / -3E via RJ12	x	x	x	
Parameterisation possible with NORDCON software via USB interface without mains connection or 24 V DC power supply <sup>3)</sup> .	-	x	x	
Programmable direct current braking	x	x	x	(Chap. 5.1.3), P108
Energy-saving function (automatic load-dependent flux optimisation)	x	x	x	(Chap. 8.7)

Characteristic SK ...	500P/510P	530P	550P	Additional information
Operating manual	BU 0600			
<b>Legend</b>				
	x = Present	- = Not present	O = Optionally available	
Load monitor	x	x	x	(Chap. 5.1.7), P525-P529
Lifting gear functionality	x	x	x	(Chap. 5.1.3), P107, P114
Process controller / PID controller	x	x	x	(Chap. 8.2)
Safe pulse block (STO / SS1-t) <sup>4)</sup> , two channel <sup>5)</sup>	- <sup>5)</sup>	O	O	 <a href="#">BU 0630</a>
PLC functionality	x	x	x	 <a href="#">BU 0550</a>
Integrated POSICON positioning control	x	x	x	 <a href="#">BU 0610</a>
2 x Industrial Ethernet via RJ45 plug	-	-	x	 <a href="#">BU 0620</a>
CANbus/CANopen interface via connection terminals	x	x	x	(Chap. 2.5.4)
HTL encoder connection <sup>6,7)</sup>	x	x	x	(Chap. 2.5.4)
Speed feedback via incremental encoder input (TTL) <sup>6)</sup>	-	x	x	
CANopen absolute encoder evaluation	x	x	x	 <a href="#">BU 0610</a>
Universal encoder interface (SSI, BISS, Hiperface, EnDat and SIN/COS) <sup>8)</sup>	-	O	O	
Number of digital inputs / outputs <sup>9)</sup>	5 / -	6 / 2	6 / 2	(Chap. 2.5.4)
Number of analogue inputs / outputs	2 / 1	2 / 1	2 / 1	
Number of relay messages	2	2	2	
PTC input with potential isolation <sup>10)</sup>	-	1	1	
Removable control panel (SK TU5-CTR)	O	O	O	(Chap. 3.2)
Function extension with customer unit SK CU5-... <sup>11)</sup>	-	x	x	(Chap. 3.1)

- 1) IT network; manual adaptation of hardware configuration required
- 2) Connection terminal X6 for external 24-V-supply
- 3) No access to Ethernet parameters without external 24-V-supply
- 4) Optional SK CU5-STO or CU5-MLT interface
- 5) SK 510P: STO and SS1-t, single channel, on board
- 6) for speed control and/or positioning (POSICON)
- 7) Max. length 10 m for ASM and PMSM
- 8) Optional SK CU5-MLT interface
- 9) PTC evaluation via digital input (DI5) possible
- 10) PTC evaluation via digital input (DI5) also possible
- 11) 1 x per FI

**Table 2: Overview of FI characteristics**

## 1.2 Delivery

Examine the frequency inverter for transport damage or loose components **immediately** on delivery / unpacking.

In case of damage, contact the carrier immediately and arrange for a careful survey.

**Important! This also applies if the packaging is undamaged.**

## 1.3 Scope of delivery

### NOTICE

#### Defect in the device

Use of unauthorised accessories and options, e.g. options for other inverter series, may result in defects of connected components.

- Only use accessories and options which are explicitly intended for use with this inverter and which are stated in these instructions.

Standard version:






- IP20
- Integrated brake chopper
- Integrated EMC mains filter for limit curve A1, Category C2
- Blank cover for technology unit slot
- Covering for the control terminals
- Standard control connection shielding plate (fitted)
- Standard motor connection shielding plate (enclosed for SK 530P and higher)
- Operating instructions on CD
- Warning signs as addition for assembly near to the device according to UL/cUL, 1x each in the languages English and French:

**ATTENTION** THE OPENING OF THE BRANCH-CIRCUIT PROTECTIVE DEVICE MAY BE AN INDICATION THAT A FAULT HAS BEEN INTERRUPTED. TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CURRENT-CARRYING PARTS AND OTHER COMPONENTS OF THE CONTROLLER SHOULD BE EXAMINED AND REPLACED IF DAMAGED. IF BURNOUT OF THE CURRENT ELEMENT OF AN OVERLOAD RELAY OCCURS, THE COMPLETE OVERLOAD RELAY MUST BE REPLACED.

**ATTENTION** LE DÉCLENCHEMENT DU DISPOSITIF DE PROTECTION DU CIRCUIT DE DÉRIVATION PEUT ÊTRE DÙ À UNE COUPURE QUI RÉSULTE D'UN COURANT DE DÉFAUT. POUR LIMITER LE RISQUE D'INCENDIE OU DE CHOC ÉLECTRIQUE, EXAMINER LES PIÈCES PORTEUSES DE COURANT ET LES AUTRES ÉLÉMENTS DU CONTRÔLEUR ET LES REMPLACER S'ILS SONT ENDOMMAGÉS. EN CAS DE GRILLAGE DE L'ÉLÉMENT TRAVERSÉ PAR LE COURANT DANS UN RELAIS DE SURCHARGE, LE RELAIS TOUT ENTIER DOIT ÊTRE REMPLACÉ.

#### Accessories

An overview on options and accessories can be found in the “NORDAC – Electronic drive technology” ([E3000](#)) catalogue. This catalogue is available for download on our website [www.nord.com](http://www.nord.com).

Software (Free download)	<p><b>NORDCON</b> MS Windows® - based software</p>		<p>For commissioning, parametrisation and control of the inverter  <a href="http://www.nord.com">www.nord.com</a>  <a href="#">NORDCON</a></p>
	<p><b>NORDCON APP</b></p>		<p>The NORDCON APP in combination with the NORDAC ACCESS BT is used for mobile commissioning and control of the inverter.  <a href="#">BU 0960</a></p>
	<p><b>ePlan macros</b></p>		<p>Macros for producing electrical circuit diagrams  <a href="http://www.nord.com">www.nord.com</a>  <a href="#">ePlan</a></p>
	<p><b>Device master data</b></p>		<p>Device master data / device description files for NORD field bus options  <a href="http://www.nord.com">www.nord.com</a>  <a href="#">NORD field bus files</a></p>
	<p><b>S7- standard module for PROFINET IO</b></p>		<p>Standard modules for NORD frequency converters  <a href="http://www.nord.com">www.nord.com</a>  <a href="#">S7_Files_NORD</a></p>
	<p><b>Standard modules for the TIA portal for PROFINET IO</b></p>		<p>Standard modules for NORD frequency converters  <i>Available on request.</i></p>

## 1.4 Safety, installation and application information

Before working on or with the device, please read the following safety instructions extremely carefully. Please pay attention to all other information from the device manual.

Non-compliance can result in serious or fatal injuries and damage to the device or its surroundings.

**These safety instructions must be kept in a safe place!**

### 1. General

Do not use defective devices or devices with defective or damaged housings or missing covers. Otherwise there is a risk of serious or fatal injuries caused by electric shock or bursting electrical components such as powerful electrolytic capacitors.

Unauthorised removal of covers, improper use, incorrect installation or operation causes a risk of serious personal injury or material damage.

During operation, depending on their protection class, devices may have live bare components as well as hot surfaces.

The device operates with a dangerous voltage. Dangerous voltage may be present at the supply lines, contact strips and PCBs of all connecting terminals (e.g. mains input, motor connection), even if the device is not working or the motor is not rotating (e.g. caused by electronic disabling, jamming of the drive or a short circuit at the output terminals).

The device is not equipped with a mains switch and is therefore always live when connected to the power supply. Voltages may therefore be connected to a connected motor at standstill.

Even if the drive unit has been disconnected from the mains, a connected motor may rotate and possibly generate a dangerous voltage.

If persons come into contact with dangerous voltage such as this, there is a risk of an electric shock, which can lead to serious or fatal injuries.

The fact that the status LED or other indicators are not illuminated does not indicate that the device has been disconnected from the mains and is without voltage.

The heat sink and all other metal components can heat up to temperatures above 70°C.

Touching parts such as this can result in local burns to the body parts concerned (cooling times and clearance from neighbouring components must be complied with).

All work on the device, e.g. transportation, installation, commissioning and maintenance work must be carried out by qualified personnel (observe IEC 364 or CENELEC HD 384 or DIN VDE 0100 and IEC 664 or DIN VDE 0110 and national accident prevention regulations). In particular, the general and regional installation and safety regulations for work on high voltage systems (e.g. VDE) must be complied with, as must the regulations concerning correct use of tools and the use of personal protection equipment.

During all work on the device, take care that no foreign bodies, loose parts, moisture or dust enter or remain in the device (risk of short circuit, fire and corrosion).

Further information can be found in this documentation.

#### *Triggering of a circuit breaker*

If the device is secured by a circuit breaker and if this was triggered, this may indicate that a residual current was interrupted. A component (e.g. device, cable or plug connector) in this circuit may have caused an overload (e.g. short circuit or earth fault).

A direct reset of the circuit breaker may lead to the circuit breaker not being triggered afterwards although the fault cause is still present. As a result, any current flowing into the fault location may cause overheating and ignite the surrounding material.



After each triggering of a circuit breaker, all live components within this circuit must thus be visually checked for defects and flashover tracks. Also check the connections at the device's connection terminals.

In case of no faults found or after the replacement of the defect components, switch on the power supply by resetting the circuit breaker. Carefully observe the components keeping a safe physical distance. As soon as you observe a malfunction (e.g. smoke, heat or unusual odours), the occurrence of a new fault or if the status LED on the device does not light up, switch off the circuit breaker immediately and disconnect the defect component from the mains. Replace the defect component.

## **2. Qualified specialist personnel**

Within the meaning of this basic safety information, qualified specialist personnel are persons who are familiar with the installation, assembly, commissioning and operation of the product and who have the qualifications appropriate to their work.

In addition, the device and the accessories associated with it must only be installed and commissioned by a qualified electrician. A qualified electrician is a person who, because of his/her technical training and experience, has sufficient knowledge with regard to

- switching on, switching off, disconnection, earthing and labelling of electric circuits and devices,
- correct maintenance and use of protective devices according to specified safety standards.

## **3. Intended use – general**

Frequency inverters are devices for industrial and commercial systems that are used to operate three-phase asynchronous motors with squirrel-cage rotors and Permanent Magnet Synchronous Motors – PMSM. These motors must be suitable for operation with frequency inverters, other loads must not be connected to the devices.

The devices are components intended for installation in electrical systems or machines. They must only be operated inside an enclosed control cabinet.

Technical data and information for connection conditions can be found on the rating plate and in the documentation, and must be complied with.

The devices may only be used for safety functions which are described and explicitly approved.

CE-labelled devices fulfil the requirements of the Low Voltage Directive 2014/35/EU. The stated harmonized standards for the devices are used in the declaration of conformity.

### **a. Supplement: Intended use within the European Union**

When installed in machines, commissioning of the devices (i.e. commencement of proper use) is prohibited until it has been ensured that the machine fulfils the provisions of EC Directive 2006/42/EC (Machinery Directive); EN 60204-1 must also be complied with.

Commissioning (i.e. start-up of proper use) is only permitted if the EMC directive (2014/30/EU) has been complied with.

### **b. Supplement: Intended use outside the European Union**

The local conditions of the operator for the installation and commissioning of the device must be complied with at the usage location (see also “a. Supplement: Intended use within the European Union”).

## **4. Do not make any modifications.**

Unauthorised changes and the use of spare parts and additional equipment not purchased from or recommended by NORD may cause fire, electric shock and injury.

Do not change the original coating / paint or apply additional coatings / paints.

Do not make any structural modifications to the product.

## **5. Phases of life**

### *Transport, storage*

The information in the manual regarding transport, storage and correct handling must be complied with.

The permissible mechanical and climatic ambient conditions (see technical data in the manual for the device) must be complied with.

If necessary, suitable, adequately dimensioned means of transport (e.g. lifting gear, rope guides) must be used.

### *Installation and assembly*

The installation and cooling of the device must be implemented according to the regulations in the corresponding documentation. The permissible mechanical and climatic ambient conditions (see technical data in the manual for the device) must be complied with.

The device must be protected against impermissible loads. In particular, components must not be deformed and/or insulation distances must not be changed. Touching of electronic components and contacts must be avoided.

The device and its optional modules contain electrostatically sensitive components, which can be easily damaged by incorrect handling. Electrical components must not be mechanically damaged or destroyed.

### *Electrical connection*

Ensure that the device and the motor are specified for the correct supply voltage.

Installation, maintenance and repair work must not be carried out unless the device has been disconnected from the voltage and at least 5 minutes have elapsed since the mains was switched off! (Due to charged capacitors, hazardous voltages may be present on the device for up to 5 minutes after being switched off from the mains). Before starting work it is essential to check by measurement that for all connection terminal contacts the connections are voltage-free.

The electrical installation must be implemented according to the applicable regulations (e.g. cable cross-section, fuses, earth lead connections). Further instructions can be found in the documentation or manual for the device.

Information regarding EMC-compliant installation such as shielding, earthing, location of filters and routing of cables can be found in the documentation for the device and in the technical information manual [TI 80-0011](#). This information must always be observed even for devices with a CE label. Compliance with the limit values specified in the EMC regulations is the responsibility of the manufacturer of the system or machine.

In case of a fault, inadequate earthing may result in electric shock, possibly with fatal consequences.

The device may only be operated with effective earth connections which comply with local regulations for large leakage currents (> 3.5 mA). Detailed information regarding connections and operating conditions can be obtained from the technical Information manual [TI 80-0019](#).

Connection of the supply voltage may directly or indirectly set the device into operation. Contact with electrically live components may result in electric shock, possibly with fatal consequences.

All poles of cable connections (e.g. power supply) must always be disconnected.

### *Setup, troubleshooting and commissioning*

When working on live devices, the applicable national accident prevention regulations must be complied with.

Connection of the supply voltage may directly or indirectly set the device into operation. Contact with electrically live components may result in electric shock, possibly with fatal consequences.

The parametrisation and configuration of the devices must be selected so that no hazards can occur.

With certain setting conditions, the device or the motor which is connected to it may start automatically when the mains are switched on. The machinery which it drives (press / chain hoist / roller / fan etc.) may then make an unexpected movement. This may cause various injuries, including to third parties.

Before switching on the mains, secure the danger area by warning and removing all persons from the danger area.

#### *Operation*

Where necessary, systems in which the devices are installed must be equipped with additional monitoring and protective equipment according to the applicable safety requirements (e.g. legislation concerning technical equipment, accident prevention regulations, etc.).

All covers must be kept closed during operation.

With certain setting conditions, the device or the motor which is connected to it may start automatically when the mains are switched on. The machinery which it drives (press / chain hoist / roller / fan etc.) may then make an unexpected movement. This may cause various injuries, including to third parties.

Before switching on the mains, secure the danger area by warning and removing all persons from the danger area.

Due to its operation, the device produces noises within the audible frequency range. These noises may cause long-term stress, discomfort and fatigue, with negative effects on concentration. The frequency range or the noise can be shifted to a less disturbing or almost inaudible range by adjustment of the pulse frequency. However, this may possibly result in derating (lower power) of the device.

#### *Maintenance, repair and decommissioning*

Installation, maintenance and repair work must not be carried out unless the device has been disconnected from the voltage and at least 5 minutes have elapsed since the mains was switched off! (Due to charged capacitors, hazardous voltages may be present on the device for up to 5 minutes after being switched off from the mains). Before starting the work, it is essential to check by measurement that all contacts of the power plug connectors or the connection terminals are voltage-free.

#### *Disposal*

The product and its parts and accessories must not be disposed of as domestic waste. At the end of its life, the product must be properly disposed of according to the local regulations for industrial waste. In particular, this product contains integrated semiconductor circuits (PCBs and various electronic components, including high power electrolytic capacitors). In case of incorrect disposal there is a risk of formation of toxic gases, which may cause contamination of the environment and direct or indirect injuries (e.g. chemical burns). In the case of high power electrolytic capacitors, there is also a risk of explosion, with the associated risk of injury.

### **6. Potentially explosive environment (ATEX)**

The device is not approved for operation or maintenance work in potentially explosive environments (ATEX).

## 1.5 Explanation of markings

### **DANGER**

Indicates an immediate danger, which may result in death or very serious injury if it is not avoided.

### **WARNING**

Indicates a dangerous situation, which may result in death or serious injury if it is not avoided.

### **CAUTION**

Indicates a dangerous situation, which may result in minor injuries if it is not avoided.

### **NOTICE**






Indicates a situation, which may result in damage to the product or its environment if it is not avoided.

### **Information**

Indicates hints for use and especially important information to ensure reliability of operation.

### 1.6 Warning information on the product

The following warning symbols are used on the product.

Warning symbol	Supplement to warning symbol <sup>1)</sup>	Meaning
	DANGER 300 s	<div style="background-color: red; color: white; text-align: center; padding: 5px;"><b>! DANGER</b></div> <p><b>Electric shock</b></p> <p>The device contains powerful capacitors. Because of this, a hazardous voltage may be present for more than 5 minutes after disconnection from the mains.</p> <ul style="list-style-type: none"> <li>• Before starting work, check that the device is free of voltage at all power contacts by means of suitable measuring equipment.</li> </ul>
		<p>It is essential to read the manual in order to prevent hazards!</p>
	HOT SURFACE	<div style="background-color: yellow; text-align: center; padding: 5px;"><b>! CAUTION</b></div> <p><b>Hot surfaces</b></p> <p>The heat sink and all other metal components may heat up to temperatures above 70 °C. Risk of local burns on contact</p> <ul style="list-style-type: none"> <li>• Allow sufficient cooling time before starting work on the device.</li> <li>• Check the surface temperatures with suitable measuring equipment.</li> <li>• Keep an adequate distance from adjacent components or provide protection against contact.</li> </ul>
		<div style="background-color: blue; color: white; text-align: center; padding: 5px;"><b>NOTICE</b></div> <p><b>EDS</b></p> <p>The device contains electrostatically sensitive components, which can be easily damaged by incorrect handling.</p> <ul style="list-style-type: none"> <li>• Avoid all contact (indirect contact by tools or similar, or direct contact) with PCBs and their components.</li> </ul>

1) Texts are written in English.

Table 3: Warning symbols on the product

## 1.7 Standards and approvals

All devices across the entire series comply with the standards and directives listed below.







Approval	Directive	Applied standards	Certificates	Label
CE (European Union)	Low Voltage 2014/35/EU	EN 61800-5-1 EN 60529 EN 61800-3 EN 63000 EN 61800-9-1 EN 61800-9-2	C310601	
	EMC 2014/30/EU			
	RoHS 2011/65/EU			
	Delegated Directive (EU) 2015/863			
	Ecodesign 2009/125/EC			
	EU Ecodesign Directive 2019/1781			
UL (USA)		UL 61800-5-1	E171342	
CSA (Canada)		C22.2 No.274-13	E171342	
RCM (Australia)	F2018L00028	EN 61800-3	.....	
EAC (Eurasia)	TR CU 004/2011, TR CU 020/2011	IEC 61800-5-1 IEC 61800-3	EAЭC N RU Д- DE.HB27.B.0271 8/20	
UkrSEPRO (Ukraine)		EN 61800-5-1 EN 60529 EN 61800-3 EN 63000 EN 60947-1 EN 60947-4 EN 61558-1 EN 50581	C311900	
UKCA (United Kingdom)		EN 61800-5-1 EN 60529 EN 61800-3 EN 63000 EN 61800-9-1 EN 61800-9-2	C350601	

Table 4: Standards and approvals

### 1.7.1 UL and CSA approval

**File No. E171342**

The categorisation of protective equipment approved by the UL according to United States standards for the devices described in this manual is listed below, basically with the original wording. The categorisation of the individually relevant fuses or circuit breakers can be found in the “Electrical Data” section of this manual.

All devices include motor protection.

((Chap. 7.3 "Electrical data "))

*Additional adhesive labels with supplementary warning information*

Attach the signs enclosed with the device and listed according to Section 1.3 "Scope of delivery" in a clearly visible position in the immediate vicinity of the device.

**Conditions UL/CSA according to report**

** Information**

- “Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Manufacturer Instructions, National Electrical Code and any additional local codes”.  
CSA: For Canada: “Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Canadian Electrical Code, Part I”.
- “Use 60 °C Copper Conductors Only”, or “Use min. 60°C rated Copper Conductors Only”, or equivalent. Higher temperature ratings are acceptable.
- For installations according to Canadian National Standard C22.2 No. 274: “For use in Pollution Degree 2 and Overvoltage Category III environments only”, or equivalent.
- “Maximum surrounding air Temperature 40°C.”
- The devices are not allowed for use in corner grounded supplies, with that the maximum working voltage to ground is considered to be 240Vac or 277Vac.

Frame Size	description
all	“Suitable For Use On A Circuit Capable Of Delivering Not More Than 5000 DC Symmetrical Amperes, 410 Volts (-123 Devices) or 715 Volts (-340 Devices) Max., When Protected by R/C Semiconductor fuses, type _____, manufactured by _____”, as listed in <sup>1)</sup>
all	“Suitable For Use On A Circuit Capable Of Delivering Not More Than _____ rms Symmetrical Amperes, 240 (1-phase) or 480 (3-phase) Volts Max., When Protected by High-Interrupting Capacity, Current Limiting Class _____ Fuses or faster, rated _____ Amperes, and _____ Volts”, as listed in <sup>1)</sup>
all	“Suitable for Use On A Circuit Capable Of Delivering Not More Than _____ rms Symmetrical Amperes, _____ Volt maximum” (240V for 1-phase models or 480V for 3-phase models), “When Protected by Circuit Breaker (inverse time trip type) in accordance with UL 489, rated _____ Amperes, and _____ Volts”, as listed in <sup>1)</sup>
1, 2	“Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 240 (1-phase) or 480 (3-phase) V max, when Protected by High-Interrupting Capacity, Current Limiting Class RK5 Fuses or faster, rated max. 15 Amperes.
3	“Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 240 (1-phase) or 480 (3-phase) V max, when Protected by High-Interrupting Capacity, Current Limiting Class RK5 Fuses or faster, rated max. 30 Amperes”.
4	“Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 480 (3-phase) V max, when Protected by High-Interrupting Capacity, Current Limiting Class J Fuses or faster, rated max. 125 Amperes”.
1, 2	“Suitable for motor group installation on a circuit capable of delivering not more than 20000 rms symmetrical

Frame Size	description
	amperes, 240 (1-phase) or 480 (3-phase) V max, when Protected by High-Interrupting Capacity, Current Limiting Class J Fuses or faster, rated max. 15 Amperes".
1, 2	"Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 240 (1-phase) or 480 (3-phase) V max, when Protected by Circuit Breaker (inverse time trip type) in accordance with UL 489, rated 15 Amperes and respectively 240 or 480 Volts min."
3	"Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 240 (1-phase) or 480 (3-phase) V max, when Protected by Circuit Breaker (inverse time trip type) in accordance with UL 489, rated 30 Amperes and respectively 240 or 480 Volts min."
4	"Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 480 (3-phase) V max, when Protected by Circuit Breaker (inverse time trip type) in accordance with UL 489, rated max. 125 Amperes and 480 Volts min."
1	"Suitable for motor group installation on a circuit capable of delivering not more than 5000 rms symmetrical amperes, DC 715 V max, when Protected by 50 215 26 from SIBA rated max. 20 Amperes"

1) 7.3 "Electrical data "



### 1.8 Type code / nomenclature


Unique type codes have been defined for the individual modules and devices. These provide individual details of the device type and its electrical data, protection class, fixing version and special versions. A differentiation is made according to the following groups:



Frequency inverters
---------------------



SK TU5-CTR




SK CU5-...

Optional modules
------------------

### 1.8.1 Name plate

All information which is relevant for the device, including information for the identification of the device can be obtained from the type plate.




Type: SK 550P-750-123-A  
 Part-No: 275295106  
 ID: 49S305103669

Version: 1.0R0  
 AAA

<b>Type:</b>	Type / designation
<b>Part-No:</b>	Part number
<b>ID:</b>	Identification number
<b>Version:</b>	Software / Hardware version
<b>Input</b>	Mains voltage
<b>Input Current</b>	Input current
<b>Output</b>	Output voltage
<b>Output Current</b>	Output current
<b>Output Power</b>	Output power
<b>Protection</b>	Protection classes
<b>Temp Range</b>	Temperature range
<b>Dissipation</b>	Energy efficiency

#### Frequency inverter type code


SK 530P-370-340-A(-xxx)



- 1) Optional. Only stated if relevant.
- 2) Designation 3 also includes combined devices which are intended for single and three-phase operation (please refer to the technical data).

## Type code for option modules

SK TU5-CTR(-xxx)



- 1) Optional. Only stated if relevant.
- 2) Option type **CTR** is implemented as **TU5** (technology unit). All other options are implemented as **CU5** (customer unit).

## 2 Assembly and installation

The frequency inverters are available in various sizes depending on their output. Attention must be paid to a suitable position when installing.

The inverters require sufficient ventilation for protection against overheating. For this the minimum distances from adjacent components above and below the frequency inverter, which could obstruct the air flow apply. (above > 100 mm, below > 100 mm)

**Distance from device:** Mounting can be immediately next to each other.

**Installation position:** Always install the frequency inverter vertically on a flat surface.



**Figure 1: Installation spacings**

If several inverters are arranged above each other, it must be ensured that the upper air intake temperature limit is not exceeded ( (Chap. 7 "Technical data")). If this is the case, it is recommended that an "obstacle" (e.g. a cable duct) is mounted between the inverters so that the direct air flow (rising warm air) is interrupted.

**Heat dissipation:** If the frequency inverter is installed in a control cabinet, adequate ventilation must be ensured. The heat dissipation in operation is approx. 5 % (according to the size and equipment of the device) of the rated power of the frequency inverter.

### 2.1 Frequency inverter installation

Install the frequency inverter directly on the rear wall of a control cabinet. Sizes 1 and 2 have two mounting holes, size 3 has four mounting holes.

Care must be taken that the rear of the cooling element is covered with a flat surface and that the inverter is mounted vertically. This enables optimum convection, which ensures fault-free operation.

Power [kW]		Device type SK 5xxP-...		Size	Overall dimensions (as delivered)			Fixing dimensions (Wall mounting)				Weight approx. [kg] <sup>2)</sup>
					A	B	C	D	E1	E2	∅	
From	to	From	to		Height	Width	Depth	Hole spacing length	Hole spacing width	Hole spacing edge	Diameter	
0.25	0.75	250-123	750-123	1	200	66	141	180	22	-	5.5	1.2
		250-340	750-340									
1.1	2.2	111-123	221-123	2	240 <sup>1)</sup>	66	141	220	22	-	5.5	1.6
		111-340	221-340									
3.0	5.5	301-340	551-340	3	286	91	175	266	20	50	5.5	2.6
7.5	11	751-340	112-340	4	331	91	175	311	20	50	5.3	3.8
15	22	152-340	222-340	5	371	126	232	351	22	83	5.3	7.1
All dimensions in mm												


1) SK 5xxP-221-123: Mains connection terminal protrudes approx. 15 mm beyond the stated overall dimension H

2) depending on configuration


### Information

Frequency inverters with configuration versions SK 530P and higher can be extended with a plug-in option module. This increases the installation depth by 23 mm.

Sizes 1 and 2



Size 3




## 2.2 EMC kit

Depending on size and configuration level, various EMC kits are optionally available. A shielding plate for the motor connection is supplied as standard for advanced devices (SK 530P and higher).





Size	SK 5xxP	EMC kit			Document
	Device type	Motor connection shield (MS)	IO port shield (IS)	Customer unit shield (SK CU5-...) (CS) <sup>2, 3)</sup>	
1	SK 5xxP-250-...-A SK 5xxP-370-...-A SK 5xxP-550-...-A SK 5xxP-750-...-A	SK HE5-EMC-MS- HS12 Part No.: 275 292 300	SK HE5-EMC-IS- HS1 Part No.: 275 292 304	SK HE5-EMC-CS- HS1 Part No.: 275 292 310	<input type="checkbox"/> <a href="#">TI 2752 923xx</a>
2	SK 5xxP-111-...-A SK 5xxP-151-...-A SK 5xxP-221-...-A	SK HE5-EMC-MS- HS12 Part No.: 275 292 300	SK HE5-EMC-IS- HS2 Part No.: 275 292 305	SK HE5-EMC-CS- HS23 Part No.: 275 292 311	
3	SK 5xxP-301-340-A SK 5xxP-401-340-A SK 5xxP-551-340-A	SK HE5-EMC-MS- HS34 <sup>1)</sup> Part No.: 275 292 301	SK HE5-EMC-IS- HS34 Part No.: 275 292 306	SK HE5-EMC-CS- HS23 Part No.: 275 292 311	
4	SK 5xxP-751-340-A SK 5xxP-112-340-A	SK HE5-EMC-MS- HS34 <sup>1)</sup> Part No.: 275 292 301	SK HE5-EMC-IS- HS34 Part No.: 275 292 306	-	
5	SK 5xxP-152-340-A SK 5xxP-182-340-A SK 5xxP-222-340-A	SK HE5-EMC-MS- HS5 <sup>1)</sup> Part No.: 275 292 302	SK HE5-EMC-IS- HS5 Part No.: 275 292 308	-	

- 1) Two-part
- 2) For SK 530P and higher with customer unit SK CU5-...
- 3) CS is only possible in combination with MS; simultaneous CS and IS is not possible







- 1) Motor connection

### Installation

Sizes 1 and 2	Sizes 3, 4 and 5
EMC Kit SK HE5-EMC-MS-HS12	EMC Kit SK HE5-EMC-MS-HS34
	
<p>The screw mounting facility for fastening the EMC kit for the motor connection SK HE5-EMC-MS-HS12 is located on the rear side of the frequency inverter.</p>	<p>The EMC kit for the motor connection SK HE5-EMC-MS-HS34 is fastened to the underside of the frequency inverter with three screws.</p>
	

**Installation – Advanced Devices (SK 530P and higher)**

Sizes 1 and 2	Sizes 3, 4 and 5
	
<p>The screw mounting facility for fastening the EMC kit is located on the rear side of the frequency inverter.</p>	<p>The EMC kit is fastened to the underside of the frequency inverter with three screws.</p>
	



### 2.3 Braking resistor (BR)

#### CAUTION

##### Hot surfaces

The braking resistor and all other metal components can heat up to temperatures above 70 °C.

- Danger of injury due to local burns on contact.
- Heat damage to adjacent objects.

Allow sufficient cooling time before starting work on the product. Check surface temperature with suitable measuring equipment. Maintain an adequate distance to adjacent components or provide protection against contact.

#### Information

To protect the braking resistor against overload, the electrical data of the braking resistor which is used must be set in parameters **P555**, **P556** and **P557**.

During dynamic braking (frequency reduction) of a three-phase motor, electrical energy is returned to the inverter. An external braking resistor can be used to prevent the FI from being shut down due to overvoltage. With this, the integrated brake chopper (electronic switch) pulses the link circuit voltage (switching threshold approx. 420 V / 775 V DC, depending on the mains voltage (230 V / 400 V)) to the braking resistor. Here the excess energy is converted into heat.

For inverter powers **up to 11 kW** (230 V: up to 2.2 kW) a standard bottom-mounted resistor (**SK BRU5-...**, **IP40**) can be used. Approval: UL recognised



SK BRU5-...

Figure 2: Frequency inverter with bottom-mounted braking resistor SK BRU5-...

For frequency inverters **above 3 kW** chassis-mounted resistors (**SK BR2-...**, **IP20**) are also available. These must be mounted in the control cabinet, close to the frequency inverter. Approval: UL, cUL

### 2.3.1 Electrical data for braking resistors

Frequency inverter		Type	Material No.	Document
230 V	0.25 ... 0.75 kW	<b>SK BRU5-1-240-050</b>	275 299 004	<input type="checkbox"/> <a href="#">TI 275299004</a>
	1.1 ... 2.2 kW	<b>SK BRU5-2-075-200</b>	275 299 210	<input type="checkbox"/> <a href="#">TI 275299210</a>
400 V	0.25 ... 0.75 kW	<b>SK BRU5-1-400-100</b>	275 299 101	<input type="checkbox"/> <a href="#">TI 275299101</a>
	1.1 ... 2.2 kW	<b>SK BRU5-2-220-200</b>	275 299 205	<input type="checkbox"/> <a href="#">TI 275299205</a>
	3.0 ... 5.5 kW	<b>SK BRU5-3-100-300</b>	275 299 309	<input type="checkbox"/> <a href="#">TI 275299309</a>
	7.5 ... 11 kW	<b>SK BRU5-4-044-400</b>	275 299 512	<input type="checkbox"/> <a href="#">TI 275299512</a>

Table 5: Technical data bottom mounted braking resistor SK BRU5-...

Frequency inverter		Type	Material No.	Document
400 V	3.0 ... 4.0 kW	<b>SK BR2-100/400-C</b> <sup>1)</sup>	278 282 040	<input type="checkbox"/> <a href="#">TI 278282040</a>
	5.5 ... 7.5 kW	<b>SK BR2-60/600-C</b>	278 282 060	<input type="checkbox"/> <a href="#">TI 278282060</a>
	11 ... 15 kW	<b>SK BR2-30/1500-C</b>	278 282 150	<input type="checkbox"/> <a href="#">TI 278282150</a>
	18.5 ... 22 kW	<b>SK BR2-22/2200</b>	278 282 220	<input type="checkbox"/> <a href="#">TI 278282220</a>

1) Type of assembly: vertical

Table 6: Technical data chassis braking resistor SK BR2-...

The chassis braking resistors (SK BR2-...) listed above are equipped with a temperature switch at the factory. Two different temperature switches with different triggering temperatures are optionally available for bottom-mounted braking resistors (SK BRU5-...).

In order to use the signal from the temperature switch it must be connected to a free digital input of the frequency inverter and, for example, parameterised with the function "Voltage Block" or "Quick Stop".

## NOTICE

### Impermissible heating

If the bottom mounted braking resistor is mounted below the frequency inverter, a temperature switch with a nominal switch-off temperature of 100°C (Part No. 275991200) must be used. This is necessary to prevent impermissible heating of the frequency inverter.

- Failure to observe this may result in damage to the cooling system of the inverter (fan).

Bi-metal temperature switch							
For SK...	Part No.	Protection class	Voltage	Current	Nominal switching temperature	Dimensions	Connection cable/ terminals
BRU5- ...	275991100	IP40	250 V AC	2.5 A for $\cos\varphi=1$	180°C ± 5 K	Width +10 mm (one side)	2 x 0.8 mm <sup>2</sup> ; AWG 18 L = 0.5 m
BRU5- ...	275991200			1.6 A for $\cos\varphi=0.6$	100°C ± 5 K		
BR2-...	integrated	IP00	250 V AC 125 V AC 30 V DC	10 A 15 A 5 A	180°C ± 5 K	Internal	Terminals 2 x 4 mm <sup>2</sup>

Table 7: Technical details of the braking resistor temperature switch

### 2.3.2 Monitoring of the braking resistor

To prevent overload of the braking resistor, it should be monitored during operation. The most reliable method is thermal monitoring with a temperature switch which is mounted directly on the braking resistor.

#### 2.3.2.1 Monitoring with a temperature switch

As standard, SK BR2-... braking resistors are equipped with a suitable temperature switch.


Typically, evaluation of the temperature switch is performed by an external control system.

Alternatively, the temperature switch can be evaluated directly by the frequency inverter. To do this, it must be connected to a free digital input. This digital input must be parameterised with the function {10} "Block voltage".

#### Example, SK 5xxP

- Connect the temperature switch to digital input 4 (Terminal 43 / 24)
- Set parameter **P420** to function {10} "Block voltage".

The switch opens if the maximum permissible temperature of the braking resistor is reached. The output of the frequency inverter is blocked. The motor runs down to a standstill.



#### 2.3.2.2 Monitoring with current measurement and calculation

As an alternative to direct monitoring with a temperature switch, it is also possible to use indirect, arithmetical monitoring of the braking resistor load on the basis of measurement values.

This software-assisted indirect monitoring is activated by setting parameter **P556** "Braking resistor" and **P557** "Brake resistor type". The actual calculated resistor load can be read out in parameter **P737** "Usage brake resistor". Overload of the braking resistor results in a shut-down of the frequency inverter with the error message **E3.1** "Overcurrent Chopper I<sup>2</sup>t".

### Information

Indirect monitoring using measurement of electrical data and calculation is based on standard ambient conditions. In addition, the calculated values are reset when the frequency inverter is switched off. It is therefore not possible to detect the actual load on the braking resistor.

It is therefore possible that an overload may not be detected and the braking resistor or its environment may be damaged due to excess temperatures.

Reliable temperature monitoring is only possible with the use of a temperature switch.

## 2.4 Chokes

Frequency inverters cause loads both on the mains side and the motor side (e.g. current harmonics, steep flanks, EMC interference), which may result in malfunctions in system operation and in the frequency inverter. Mains or link circuit chokes are primarily used for protection of the mains, motor chokes primarily reduce influences on the motor side.

### 2.4.1 Mains chokes

**Mains chokes** are available for protection on the mains side. These are incorporated in the supply cable immediately in front of the inverter.

Mains input chokes reduce the charging current and harmonics from the mains. Chokes fulfil several functions:

- Reduction of harmonics in the mains voltage upstream of the choke
- Reduction of the negative effects of mains voltage asymmetries
- Increase of efficiency due to lower input current
- Increase of the service life of link circuit capacitors

Use of mains chokes is recommended e.g.:

- If the proportion of the installed inverter power exceeds 20 % of the installed transformer power.
- For very hard mains or capacitive compensation systems
- In case of large voltage fluctuations due to switching

### 2.4.1.1 Mains choke SK C15

Type SK C15- chokes are intended for a maximum supply voltage of 230 V or 500 V at 50/60 Hz.

All chokes have a protection class corresponding to IP00. The choke which is used must therefore be installed in a control cabinet.



Single phase / 400 V



3-phase / 400 V

#### Mains choke SK C15-230/xxx

Inverter ID SK 5xxP		Mains choke		
		Type	Part number	Data sheet
1~ 230 V	0.25 ... 0.37 kW	SK C15-230/006-C	276 993 005	<input type="checkbox"/> <a href="#">TI 276993xxx</a>
	0.55 ... 0.75 kW	SK C15-230/010-C	276 993 009	
	1.1 ... 2.2 kW	SK C15-230/025-C	276 993 024	

#### Mains choke SK C15-500/xxx

Inverter ID SK 5xxP		Mains choke		
		Type	Part number	Data sheet
3~ 400 V	0.25 ... 0.75 kW	SK C15-500/004-C	276 993 004	<input type="checkbox"/> <a href="#">TI 276993xxx</a>
	1.1 ... 2.2 kW	SK C15-500/008-C	276 993 008	
	3.0 ... 5.5 kW	SK C15-500/016-C	276 993 016	
	7.5 kW ... 11 kW	SK C15-500/035-C	276 993 035	
	15 kW ... 22 kW	SK C15-500/063-C	276 993 063	

## 2.4.2 Motor choke SK CO5

To reduce interference radiation from the motor cable or to compensate for cable capacitance in long motor cables, an additional output choke (motor choke) can be installed into the inverter output.

During installation, care must be taken that the pulse frequency of the frequency inverter is set to 3 ... 6 kHz (**P504 = 3 ... 6**).

These chokes are specified for a maximum supply voltage of 480 V at 0 ... 100 Hz.



An output choke should be fitted for low powers up to 370 w, for motor cable lengths over **50 m / 15 m** (unshielded / shielded) and for higher powers for motor cable lengths over **100 m / 30 m** (unshielded / shielded). All chokes have a protection class corresponding to **IP00**. The choke used must therefore be installed in a control cabinet.

### Motor choke SK CO5-500/xxx

Inverter type SK 5xxP		Motor choke		
		Type	Part number	Data sheet
1~ 230 V	0.25 ... 0.37 kW	SK CO5-500/002-C	276 992 002	<input type="checkbox"/> <a href="#">TI 276992xxx</a>
	0.55 ... 0.75 kW	SK CO5-500/006-C	276 992 006	
	1.1 ... 2.2 kW	SK CO5-500/012-C	276 992 012	
3~ 400 V	0.25 ... 0.75 kW	SK CO5-500/002-C	276 992 002	
	1.1 ... 2.2 kW	SK CO5-500/006-C	276 992 006	
	3.0 ... 5.5 kW	SK CO5-500/012-C	276 992 012	
	7.5 ... 11 kW	SK CO5-500/024-C	276 992 024	
	15.0 ... 22.0 kW	SK CO5-500/046-C	276 992 046	

### 2.5 Electrical Connection

#### **WARNING**

##### **Electric shock**

Hazardous voltages may be present at the mains input and all power connection terminals (e.g. motor connection terminals, link circuit) even when the device is not in operation.

- Before starting work, check that all relevant components (voltage source, connection cables, connection terminals are free of voltage using suitable measuring equipment.
- Use insulated tools (e.g. screwdrivers).
- Earth devices.

#### **NOTICE**

##### **Device failure due to increased input current**

If 1-phase and 3-phase frequency inverters are operated on the same circuit, this can lead to increased input currents and corresponding faults on the 1-phase devices. You can prevent this effect through

- long mains supply cables (at least 10 m) or
- use of a mains choke before the 1-phase device.

#### **Information**


##### **Temperature sensor and PTC (TF)**

As with other signal cables, thermistor cables must be laid separately from the motor cables. Otherwise the interfering signals from the motor winding that are induced into the line affect the device.

Ensure that the device and the motor are specified for the correct supply voltage.

### 2.5.1 Overview of connections



Depending on the size of the frequency inverter, the connection terminals for the supply cables and the control cables are located in different positions. According to the configuration of the frequency inverter, various terminals are not present.



Note for X17/X19: The illustration shows the X17 Ethernet connection.

Terminal		Signal	Pin no.		Number of poles	SK 500P	SK 510P	SK 530P	SK 550P
			230 V	400 V					
X1	Mains	L1	L	L1	3 <sup>1)</sup>	X	X	X	X
		L2 / N	N	L2					
		L3	–	L3					
X2	Motor	U	U		3	X	X	X	X
		V	V						
		W	W						
X3	Braking resistor	B+	B+		3	X	X	X	X
		B-	B-						
		DC-	DC-						
X4	Thermistor	TF-	39		2	–	–	X	X
		TF+	38						
X5	Multi-function relay	K1.1	1		4	X	X	X	X
		K1.2	2						
		K2.1	3						
		K2.2	4						
X6	24 V	GND	40		1	–	–	X	X
		24 V	44						



Terminal		Signal	Pin no.		Number of poles	SK 500P	SK 510P	SK 530P	SK 550P
			230 V	400 V					
X10	Analog inputs	10 V	11	5	X	X	X	X	
		0 V	12						
		AI1	14						
		AI2	16						
		AO	17						
X11	Digital inputs	DI1	21	8	X	X	X	X	
		DI2	22						
		DI3	23						
		DI4	24						
		DI5	25						
		24 V	43						
		GND	40						
		5 V	41						
X12	Digital inputs and outputs	DI6	26	5	-	-	X	X	
		DO1	34						
		DO2	35						
		24 V	43						
		GND	40						
X13	TTL incremental encoder	24 V	43	6	-	-	X	X	
		GND	40						
		A+	51						
		A-	52						
		B+	53						
		B-	54						
X14	RJ12 diagnostic connection	-	-	6	X	X	X	X	
X15	CAN	SHD	90	4	X	X	X	X	
		GND	40						
		CAN-	76						
		CAN+	75						
X16	USB	-	-	4	-	-	X	X	
X17	Industrial Ethernet 	-	-	2 x 8	-	-	-	X	
X18	microSD	-	-	-	-	-	X	X	
X19 <sup>2)</sup>	STO, single channel 	24VOut	43	-	-	X	-	-	
		GND	40						
		VISD_24V	94						
		VIS_0V	93						
		VIS_24V	91						
CAN	CANopen system bus termination	DIP switch		1	X	X	X	X	
USS	RS485 termination	DIP switch		1	X	X	X	X	

1) Size 2 230 V devices have 2 poles

2) Connection X19 is to the position of X17

## 2.5.2 Wiring guidelines

The devices have been developed for use in an industrial environment. In this environment, electromagnetic interference can affect the device. In general, correct installation ensures safe and problem-free operation. To meet the limiting values of the EMC directives, the following instructions should be complied with.

1. Ensure that all devices are securely earthed to a common earthing point or earthing rail using short earthing cables with a large cross-section. It is especially important that each control unit which is connected to the electronic drive technology (e.g. an automatic device) has a short cable with a large cross-section, which is connected to the same earthing point as the device itself. Flat cables (e.g. metal clamps) are preferable, as they have a lower impedance at high frequencies.
2. The bonding cable of the motor controlled by the soft starter should be connected directly to the earthing terminal of the associated device. The presence of a central earthing bar in the control cabinet and the grouping together of all bonding conductors to this bar normally ensures safe operation.
3. Where possible, shielded cables should be used for control circuits. The shielding at the cable end should be carefully sealed and it must be ensured that the wires are not laid over longer distances without shielding.

The shielding of analogue setpoint cables should only be earthed on one side on the device.

4. Control cables should be installed as far as possible from power cables, using separate cable ducts, etc. Where cables cross, an angle of 90° should be ensured as far as possible.
5. Ensure that the contactors in the cabinet are interference protected, either by RC circuits in the case of AC contactors or by free-wheeling diodes for DC contactors, for which **the interference suppressors must be positioned on the contactor coils**. Varistors for over-voltage limitation are also effective.

This interference suppression is particularly important if the circuit breakers are controlled by the relay in the frequency inverter.

6. Shielded or armoured cables should be used for the load connections (motor cable). The shielding or armouring must be earthed at both ends. If possible, earthing should be made directly to the electrically conducting mounting plate of the control cabinet or the screening angle of the EMC Kit.

Furthermore, attention must be paid to the EMC-compliant wiring.

***During the installation of the devices, the safety requirements must not be violated under any circumstances!***

### NOTICE!

#### Damage due to high voltage

The device may be damaged by electrical loads which do not correspond to its specification.

- Do not perform any high voltage tests on the device itself.
- Disconnect the cable which is to be tested from the device before performing a high voltage insulation test.

### 2.5.3 Electrical connection of power unit

The following information relates to all power connections to the frequency inverter. This includes:

- Mains cable connection X1 (L1, L2/N, L3) and PE to connection contact
- Motor cable connection X2 (U, V, W) and PE to connection contact
- Braking resistor connection X3 (B+, B-)
- Link circuit connection (B+, DC-)

When connecting the device, please note the following:

1. Ensure that the mains supply provides the correct voltage and is suitable for the current required (Chap. 7 "Technical data")
2. Ensure that suitable electrical fuses with the specified nominal current range are installed between the voltage source and the device.
3. Mains cable connection: to terminals **L1-L2/N-L3** (depending on device) and **PE** to marked connection contact on base plate
4. Motor connection: to terminals **L1-L2/N-L3** and **PE** to marked connection contact on base plate

**Note:** PE connection contact is indicated by this symbol:



5. The shield of a shielded motor cable must also be connected to a large area of the metal shielding bracket of the EMC Kit, however, at least to the electrically conducting mounting surface of the control cabinet.

**Note:** The use of ring cable lugs is recommended for connecting to PE.

#### Information

##### Connection cable

Only use copper cables with temperature class 80 °C or equivalent for connection. Higher temperature classes are permissible.

When using **wiring sleeves**, the maximum connection cross-section can be reduced.

All power terminals up to Size 2 are plug-in versions.

To connect the power unit, the following **tools** must be used:

FI Size	Cable Ø [mm²]		AWG	Tightening torque		Tool Screwdriver
	rigid	flexible		[Nm]	[lb-in]	
1	0.2...2.5	0.2...2.5	24...12	0.5...0.6	4.42...5.31	SL 0.6x3.5
2	0.2...2.5	0.2...2.5	24...12	0.5...0.6	4.42...5.31	SL 0.6x3.5
2 (only 2.2 kW)	0.2...4.0	0.2...4.0	24...10	0.5...0.6	4.42...5.31	SL 0.6x3.5
3	0.2...6.0	0.2...4.0	24...10	0.5...0.6	4.42...5.31	SL 0.8x4.0
4	0.5...16.0	0.5...16.0	20...6	1.2	10.62	SL 0.8x4.0
5	0.5...35.0	0.5...35.0	20...2	3.8...4.5	33.6...39.8	SL 1.0x6.5

Table 8: Connection data mains side X1

FI Size	Cable Ø [mm <sup>2</sup> ]		AWG	Tightening torque		Tool Screwdriver
	rigid	flexible		[Nm]	[lb-in]	
1	0.2...2.5	0.2...2.5	24...12	0.5...0.6	4.42...5.31	SL 0.6x3.5
2	0.2...2.5	0.2...2.5	24...12	0.5...0.6	4.42...5.31	SL 0.6x3.5
3	0.2...6.0	0.2...4.0	24...10	0.5...0.6	4.42...5.31	SL 0.8x4.0
4	0.2...6.0	0.2...4.0	24...10	0.5...0.6	4.42...5.31	SL 0.8x4.0
5	0.5...16.0	0.5...16.0	20...6	1.2	10.62	SL 0.8x4.0

Table 9: Connection data motor side X2, X3

### 2.5.3.1 Electromechanical brake

#### NOTICE

##### Power supply for an electromechanical brake

Connection of an electromechanical brake to the motor terminals may cause destruction of the brake or the frequency inverter.

- Only provide the power supply for an electromechanical brake (or its brake rectifier) via the mains or mains voltage.

An electromechanical brake (holding brake) can be connected to control terminal X5 via one of the two multi-function relays (K1 / K2). In particular, take special note of parameters P107, P114 and P434.

### 2.5.3.2 Mains connection (PE, L1, L2/N, L3)

No special safety measures are required on the mains input side of the frequency inverter. It is advisable to use the normal mains fuses (see technical data) and a master switch or circuit breaker.

Isolation from or connection to the mains must always be carried out simultaneously for all poles (L1/L2/L3 or L1/N).

#### NOTICE

##### Damage to the FI by mains distortion

Strong mains distortions (harmonics) can lead to increased input currents and damage the rectifier in the frequency inverter.

- To prevent this, the use of mains chokes is recommended .

### Adaptation to IT networks

#### WARNING

##### Unexpected movement in case of mains faults

In case of a mains fault (short circuit to earth) a frequency inverter which is switched off may switch on automatically. Depending on the parameterisation, this may cause the drive unit to start automatically and therefore cause a risk of injury.

- Secure the system against unexpected movement (block, decouple mechanical drive, provide protection against falling, etc.)

#### NOTICE

##### Operation in IT networks


If a mains fault (short-circuit to earth) occurs in an IT network, the link circuit of a connected frequency inverter may become charged, even if it is switched off. This results in destruction of the link circuit capacitors due to overcharging.

- Connect a braking resistor to dissipate excess energy.

Despite connection of the braking resistor, the error message *Overvoltage DC link voltage* may occur. The use of the braking resistor to dissipate the charging prevents the destruction/damage of the device. However, the switching threshold for activation of the brake chopper is above the fault threshold so that an error is indicated and the earth fault can be detected.

As delivered, the device is configured for operation in TN or TT networks. For operation in IT networks, simple adaptations must be made. However, these impair the suppression of radio interference.

Adaptation is carried out via two screw connections. The two screws must be removed from the housing to enable IT network operation.



1) Motor output      2) Mains input

### Adaptation to HRG networks

The device may also be operated in supply networks with a high resistance earthed star point (**H**igh **R**esistance **G**rounding) (typical for the US American region). For this, the same conditions and modifications must be taken into account as for operation in an IT network (see above).

### Use with differing supply networks or network types

The frequency inverter may only be connect to and operated in supply networks which are explicitly stated in this section (Chap. 2.5.3.2 "Mains connection (PE, L1, L2/N, L3)"). Operation in differing network types may be possible, but must be **explicitly checked and approved by the manufacturer in advance**.

### 2.5.3.3 Motor cable

The motor cable may have a **total length of 100 m** if it is a standard cable type (observe EMC). If a shielded motor cable is used or if the cable is installed in a metallic and well grounded duct, the total length should not exceed **30 m** (connect cable shield to PE at both ends).

For inverter powers up to 370 W, the length of the motor cable must not exceed 50 m / 15 m (unshielded / shielded).

For longer cable lengths an additional motor choke (accessory) must be used.



### Information

#### Multiple motor operation

Multiple motor operation is the parallel operation of several motors by a frequency inverter.

For multiple motor operation the frequency inverter must be changed to a linear voltage/frequency characteristic curve (→ **P211 = 0** and **P212 = 0**).

For multiple motor operation the total motor cable length consists of the sum of the individual motor cable lengths.

---

#### 2.5.3.4 Braking resistor (B+, B-)

Terminals +B/ B- are intended for the connection of a suitable braking resistor. A short screened connection should be selected.

### CAUTION

#### Hot surfaces

The braking resistor and all other metal components can heat up to temperatures above 70 °C.

- Danger of injury due to local burns on contact.
- Heat damage to adjacent objects

Allow sufficient cooling time before starting work on the product. Check the surface temperatures with suitable measuring equipment. Maintain an adequate distance to adjacent components or provide protection against contact.

#### 2.5.3.5 DC coupling (B+, DC-)

### NOTICE


#### Link circuit overload

Link circuit coupling faults can have negative effects on the charging circuits in the inverters or the life of the link circuits, up to their complete destruction.

- It is essential to observe the criteria summarised below for establishing the frequency inverter link circuit coupling.
- For direct current coupling of single-phase devices, it is essential to ensure that coupling to the same external conductor is used.

In drive technology, DC-coupling is advisable if motors simultaneously act as drivers and generators in the system. In this case, the energy from the drive which is acting as a generator can be fed back to the drive which is acting as a motor. The advantages are lower energy consumption and the sparing use of braking resistors. In principle, devices with the same power should be connected together for DC coupling wherever possible. Furthermore, only devices which are ready for operation (whose link circuits are charged) may be coupled.






**Illustration 3: Illustration of a DC-coupling**

- 1 The link circuits of the individual frequency inverters must be protected with suitable fuses.
- 2 **NOTICE!** Ensure that the coupling is only made after readiness is reported. Otherwise, there is a danger that all the frequency inverters will be charged by a single device.
- 3 Ensure that the coupling is disconnected as soon as one of the devices is no longer ready for operation.
- 4 For high availability, a braking resistor must be used. If different sizes of frequency inverters are used, the braking resistor must be connected to the larger of the two frequency inverters.
- 5 If devices with the same rating (identical type) are coupled, and the same mains impedances are in effect (identical lengths of cable to the mains rail), the frequency inverters may be operated without mains chokes. Otherwise, a mains choke must be installed in the mains cable of each frequency inverter.

### 2.5.4 Electrical connection of the control unit

The control connections differ depending on the version. All control terminals can be simply plugged in and exchanged. To prevent connection errors, the connections are coded and protected against incorrect connection.

To simplify wiring, a slot (third hand) to hold the connections is located next to the terminals. Both hands can then be used for wiring.



Simple assembly and removal



Fixing of the connections (third hand)

#### Connection data:

Terminal bar		X5	X19	X10, X11, X12	X13, X15, X4, X6
Rigid cable Ø	[mm <sup>2</sup> ]	0.2 ... 2.5	0.2 ... 2.5	0.2 ... 1.5	0.14 ... 1.5
Flexible cable Ø	[mm <sup>2</sup> ]	0.2 ... 2.5	0.2 ... 2.5	0.2 ... 1.5	0.14 ... 1.5
Cross section of the flexible conductor with end ferrule without plastic sleeve	[mm <sup>2</sup> ]	0.2 ... 2.5	0.25 ... 2.5	0.25 ... 1.5	0.25 ... 1.5
Cross section of the flexible conductor with end ferrule with plastic sleeve	[mm <sup>2</sup> ]	0.25 ... 2.5	0.25 ... 2.5	0.14 ... 0.75	0.25 ... 0.5
AWG standard		24 ... 12	26 ... 12	24 ... 16	28 ... 16
Tightening torque	[Nm] [lb-in]	0.5 ... 0.6	Push-in spring connection	Push-in spring connection	0.22 ... 0.25

GND is a common reference potential for analogue and digital inputs.

### Information

5 V / 24 V can be obtained from several terminals if required. This also includes e.g. digital outputs or a control module connected via RJ12.

The total output current must not exceed 150 mA (5 V) / 250 mA (24 V).

### Information

#### Response time of digital inputs

The response time of a digital signal is approx. 4 – 5 ms and consists of the following:

Scan time	1 ms
Signal stability check	3 ms
Internal processing	< 1 ms

A parallel channel exists for digital inputs DIN2 and DIN3, which relays the signal pulses between 250 Hz and 150 kHz directly to the processor, and therefore makes it possible for an encoder to be evaluated.

### Information

#### Cable laying

All control cables (including thermistors) must be routed separately from the mains and the motor cables to prevent interference in the device.

If the cables are routed in parallel, a minimum distance of 20 cm must be maintained from cables which carry a voltage of > 60 V. The minimum distance may be reduced by screening the cables which carry a voltage, or by the use of earthed metal partitions within the cable conduits.


Alternatively: Use a hybrid cable with shielding of the control lines.



### Information


#### Restricted parameter access

The external 24 V supply only supplies the bus communication circuit. Access to display parameters such as the actual position, device status or information parameters is not possible.

Meaning, Functions		Description / Technical data		
Terminal				Parameter
No.	Designation	Meaning	No.	Function of factory setting
<b>PTC input X4 (SK 530P and higher)</b>		Monitoring of motor temperature using PTC		
		A shielded cable must be used if the device is installed near the motor. Switching shaft according to EN 60947-8 On: > 3.6 kΩ Off: < 1.65 kΩ Measurement voltage ≤ 6.6 V on R < 4 kΩ	The input is always active. In order to make the device operational, a temperature sensor must be connected or both contacts must be connected with jumpers. The function can be disabled via parameter <b>P425</b> .	
<b>38</b>	TF+	PTC resistor input	-	-
<b>39</b>	TF-	PTC resistor input	-	-
<b>Relay X5</b>		Relay closing contact 230 V AC, 24 V DC, < 60 V DC in circuits with safe isolation, ≤ 2 A <b>Note:</b> If two relays are to be used at the same time, the voltage reference must be identical: 24 V DC or 230 V AC. For 230 V AC, always use the same mains cable for both relays.		
<b>1</b>	K1.1	Test multi-function relay 1	P434 [-01]	External brake (applied on enabling)
<b>2</b>	K1.2			
<b>3</b>	K2.1	Test multi-function relay 2	P434 [-02]	Fault (closes when FI ready / no fault)
<b>4</b>	K2.2			
<b>Control voltage connection X6 (SK 530P and higher)</b>		External power supply to the device for bus communication or offline parameterisation. 24 V ... 30 V, min. 1000 mA, depending on the load on inputs and outputs and use of options <b>Note:</b> Without the mains supply, there is only restricted visibility of the device status, position values and information parameters.		
<b>44</b>	24 V	Voltage input, connection optional. If a power supply is not connected, this is provided by an internal mains unit (no access to Ethernet parameters).	-	-
<b>40</b>	GND / 0V	Reference potential GND	-	-

Analogue inputs/outputs X10		Actuation of device by external controller, potentiometer or similar			
		Analogue input: For control of the FI output frequency. Analogue output: For external display or further processing in a following machine. Switch-over between current and voltage setpoints (or actual values) is performed automatically. The possible digital functions are described in parameter P420.			
11	10 V	10 V reference voltage, 10 V, 5 mA, not short-circuit protected	-	-	
12	0 V	Reference potential for analogue signals, 0 V analogue	-	-	
14	AI1	Analogue input 1	$U = 0 \dots 10 \text{ V}$ , $R_i = 20\text{-}40 \text{ k}\Omega$ , $I = 0/4 \dots 20 \text{ mA}$ , $R_i = 165 \Omega$ , reference potential GND. For the use of digital functions 7.5 ... 30 V.	P400 [-01]	Setpoint frequency
16	AI2	Analogue input 2		P400 [-02]	No function
17	AO	Analogue output	$U = 0 \dots 10 \text{ V}$ , Max. load current: 5 mA  $I = 0 \dots 20 \text{ mA}$ ,  $R_i = 165 \Omega$ , reference potential GND, max. load current for digital signals: 20 mA	P418 [-01]	No function

<b>Digital inputs X11</b>		Actuation of device using an external controller, switch or similar. Each digital input has a response time of $\leq 5\text{ms}$ . Control with internal 24 V:  Control with external 7,5 ... 30 V: 			
<b>21</b>	DI1	Digital input 1	7.5 ... 30 V, $R_i = 6.1\text{ k}\Omega$ , not suitable for PTC evaluation. HTL encoders can only be connected to DIN3 and DIN4. HTL encoder cable max. 10 m, max. limit frequency 150 kHz	P420 [-01]	ON right
<b>22</b>	DI2	Digital input 2		P420 [-02]	ON left
<b>23</b>	DI3	Digital input 3		P420 [-03]	Parameter set bit 0
<b>24</b>	DI4	Digital input 4		P420 [-04]	Fixed frequency 1, P429
<b>25</b>	DI5	Digital input 5, 2.5 ... 30 V, $R_i = 2.2\text{ k}\Omega$ . Not suitable for evaluation of a protective switching device. Suitable for thermistor evaluation with 5 V.		P420 [-05]	No function
<b>43</b>	24 V	24V supply voltage <b>output</b> . Power supply provided by the FI for controlling digital inputs or a 10 ... 30 V encoder, 24 V $\pm 20\%$ , max. 200 mA (Output)		–	–
<b>40</b>	GND	Reference potential for digital signals, 0 V digital		–	–
<b>41</b>	5 V	5V voltage supply <b>output</b> ; voltage supply for motor PTC, 5 V $\pm 20\%$ , max. 250 mA (Output), short-circuit protected		–	–

Digital inputs and outputs X12 (SK 530P or higher)		Signalling of operating statuses of the FI			
		24 V DC With inductive loads: Provide protection via free-wheeling diode!	Maximum load 20 mA		
26	DI6	Digital input 6	P420 [-06]	No function	
34	DO1	Digital output 1	P434 [-03]	No function	
35	DO2	Digital output 2	P434 [-04]	No function	
43	24 V	Output voltage, VO/24 V	–	–	
40	GND	Reference potential for digital signals, 0 V digital	–	–	
Encoder (TTL) X13 (SK 530P or higher)		Speed feedback with TTL incremental encoder			
43	24 V	Output voltage, VO/24 V	-	-	
40	GND	Reference potential for digital signals, 0 V	-	-	
51	A+	Track A	TTL, RS 422, 16 ... 8192 impulses/revolution. Limiting frequency: max. 1 MHz	P300	Specification of zero track
52	A-	Track A inverse			
53	B+	Track B			
54	B-	Track B inverse			
Communication interface X14		Connection of the FI to various communication tools			
		24 VDC ± 20 %	RS485 (for connecting a parametrisation box) 9600 ... 115000 Baud Terminating resistance (1 kΩ) fixed RS232 (for connection to a PC, NORDCON, NORDCON APP) 9600 ... 115000 Baud		
1	RS485 A+	Data cable RS485	P502...	 <p>1 - 2 - 3 - 4 - 5 - 6</p>	
2	RS485 B-	Data cable RS485	P513 [-02]		
3	GND	Bus signal reference potential			
4	RS232 TXD	Data cable RS232			
5	RS232 RXD	Data cable RS232			
6	+24 V	Voltage output			
System bus (CANopen) X15		Evaluation of an absolute encoder			
		The CANopen interface can be used to evaluate an absolute encoder and for coupling inverters. With SK 530P and higher, IOE or Profibus modules can also be connected. Further details can be found in manual <a href="#">BU 0610</a> . Baud rate ... 500 kBd; Termination resistor R = 240 Ω; DIP switch 2; recommended: Implement strain relief			
90	SHD	Shielding	P503 P509		
40 <sup>1)</sup>	GND	Reference potential for the CANopen system bus			
76	CAN-	CAN_L			
75	CAN+	CAN_H			

1) The potential of this terminal differs from that of other 40 terminals.

Two options exist for the CANopen connection:

1. Double terminal SK TIE5-CAO-WIRE-2x4P




Part no.:  
275292201


Connection data		X15 (CAO-WIRE-2x4P)
Rigid cable	[mm <sup>2</sup> ]	0.2 ... 1.5
Flexible cable	[mm <sup>2</sup> ]	0.2 ... 1.5
Cross section of the flexible conductor with end ferrule without plastic sleeve	[mm <sup>2</sup> ]	0.25 ... 1.5
Cross section of the flexible conductor with end ferrule with plastic sleeve	[mm <sup>2</sup> ]	0.25 ... 0.75
AWG standard		24 ... 16
Tightening torque		Push-in spring connection

Connections to these terminals correspond to the connection of the standard terminal for the CANopen system bus X15, however with two connection options for looping CANopen signals.


2. RJ45 adapter SK TIE5-CAO-2X-RJ45






Part no.: 275292202

		<p>Baud rate ... 500 kBd The RJ45 sockets are connected in parallel internally. Termination resistor R = 240 Ω</p>  <p>2 x RJ45: Pin No. 1... 8</p>		
1	CAN_H	CAN/CANopen signal	P503 P509	
2	CAN_L			
3	CAN_GND	Reference potential for digital signals, 0 V		
4	nc	No function		



		<p>Baud rate ... 500 kBd          The RJ45 sockets are connected in parallel internally.          Termination resistor <math>R = 240 \Omega</math></p>  <p>2 x RJ45: Pin No. 1... 8</p>	
5	nc		
6	CAN_SHLD	Cable shield	
7	CAN_GND	Reference potential for digital signals, 0 V	
8	CAN_24V	24 V DC potential	

<b>USB Communication interface X16 (SK 530P or higher)</b>		Connection of the FI to a PC (alternatively to the RJ12 interface) for communication with the NORDCON software <b>Note:</b> A 24 V supply (X6) is necessary for access to the Ethernet parameters.		
		USB 2.0 Type C (SK 530P or higher)		
1	+5 V	Supply voltage	P502...	
2	Data -	Data cable	P513 [-02]	
3	Data +	Data cable		
4	GND	Bus signal reference potential		
				
<b>Ethernet-on-Board X17 (SK 550P or higher)</b>		<b>RJ45 socket details</b>		
1	TX+	Transmission Data +		
2	TX-	Transmission Data -		
3	RX+	Receive Data +		
6	RX-	Receive Data -	Pin 8	Pin 1
		Port 1		Port 2
<b>microSD-card X18</b>		Interface for microSD card		
		Option for saving and transferring data (see also P550). <b>Note:</b> Only industrial grade microSD cards should be used with the interface (Chap. 1.3).		
<b>USS/CAN DIP switches S1/S2</b>				
USS		Termination resistor for RS485 interface (RJ12); ON = switched in [Default = "OFF"] For RS232 communication DIP1 to "OFF"	DIP switch ON – OFF 	
CAN		Termination resistor for CAN/CANopen interface (RJ12); ON = switched in [Default = "OFF"]		

### Encoder connection

The incremental encoder connection is an input for a type with two tracks and TTL-compatible signals for EIA RS 422-compliant drivers. The maximum current consumption of the incremental encoder must not exceed 150 mA.

The pulse number per rotation can be between 16 and 8192 increments. This is set with the normal scaling via parameter **P301** "Incremental encoder pulse number" in the menu group "Control parameters". For cable lengths > 20 m and motor speeds above 1500 rpm the encoder should not have more than 2048 pulses/revolution.

For longer cable lengths the cable cross-section must be selected large enough so that the voltage drop in the cable is not too great. This particularly affects the supply cable, in which the cross-section can be increased by connecting several conductors in parallel.



### Information

#### Rotation direction

The counting direction of the incremental encoder must correspond to the direction of rotation of the motor. If the two directions are not identical, the connections of the encoder tracks (Track A and Track B) must be switched. Alternatively, the resolution (pulse number) of the encoder in **P301** can be set with a negative prefix.

Alternatively, the motor phase sequence can be changed via parameter **P583**. In this way the direction of rotation can be changed using the software only.

---

## 2.6 Incremental encoder

According to the resolution (pulse number), incremental encoders generate a defined number of pulses for each rotation of the encoder shaft (Track A / Track A inverse) With this, the precise speed of the encoder or motor can be measured by the frequency inverter. By the use of a second track (B / B inverse) shifted by 90° (¼ period), the direction of rotation can also be determined.

The supply voltage for the encoder is 10 ... 30 V. An external source or the internal voltage can be used as the voltage source.

### TTL encoder

Special terminals are available for connection of a rotary encoder with TTL signals. Parameterisation of the corresponding functions is made with the parameters from the group "Control parameters" (P300 et seq.). TTL encoders enable the best performance for control of a drive unit with frequency inverters SK 530P and higher.

### HTL encoder

HTL encoders are not suitable for PMSMs The digital inputs DIN 3 and DIN 4 are used to connect an encoder with an HTL signal. Parameterisation of the corresponding functions is performed with parameters P420 [-03/-04]. The length of the HTL encoder cable should be limited to max. 10 m.

Function	Cable colours for incremental encoders	Signal type TTL		Signal type HTL	
10-30 V supply	Brown / green	X13: 43	(24 V)	X11: 43	(24 V)
0 V supply	White / green	X13: 40	GND	X11: 40	GND
Track A	Brown	X13: 51	A+	X11: 23	DI3
Track A inverse	Green	X13: 52	A-	-	-
Track B	Grey	X13: 53	B+	X11: 24	DI4
Track B inverse	Pink	X13: 54	B-	-	-
Track 0	Red	X11: 25	DI5 <sup>1)</sup>	X11: 25	DI5 <sup>1)</sup>
Track 0 inverse	Black	-	-	-	-
Cable shield	Connect to a large area of the frequency inverter housing or shielding bracket				

1) Recommended, DI can be freely selected

Table 10: Colour and contact assignments for NORD TTL / HTL incremental encoders

### Information

#### Encoder signal faults

Wires that are not required (e.g. Track A inverse / B inverse) must be insulated. Otherwise, if these wires come into contact with each other or the cable shield, short-circuits may occur, which can cause encoder signal problems or destruction of the encoder.

### Information

#### Incremental encoder data sheet


If the equipment deviates from the standard equipment (Type 5820.0H40, 10-30V encoder, TTL/RS422 or encoder type 5820.0H30, 10 ... 30 V encoder, HTL) for the motors, please note the accompanying data sheet or consult your supplier.

## 2.7 Fans

### 2.7.1 Removing the fan

Remove the fan by pressing the two fixing points out of the frequency inverter (1).

1.




### 2.7.2 Installing the fan

Fit the fan by pressing the two fixing points into the frequency inverter (1). Take care that the plug connector on the fan matches the socket of the frequency inverter.

1.



2.




### 3 Options

#### 3.1 Overview of option modules

The function of the frequency inverter can be extended with a ControlBox SK TU5-CTR, a customer unit SK CU5-... (SK 530P and higher) and other option modules. The options can be plugged in. Either a blank cover or an SK TU5 module can be attached to an SK CU5 module.



SK TU5-CTR



SK CU5-...

Detailed information about the options listed below can be found in the relevant documentation.

#### ControlBox

Module	Designation	Description	Data	Part No.	Info
SK TU5-CTR	ControlBox	Commissioning, parameterisation and control of the frequency inverter	5-digit, 7-segment display, keyboard	275297000	Installation in the SK TU5 slot

#### Customer units

Module	Interface	IOs	Part No.	Info
SK CU5-MLT	Encoder interface: TTL, SIN/COS, Hiperface, Endat, Biss, SS1 Functional safety: STO, SS1	4 IO (usable as DIN or DOUT)	275298200	Functional safety: 2-channel connection <a href="#">BU 0630</a>
SK CU5-STO	Functional safety: STO, SS1	1 Safe DI	275298000	

#### Other option modules

Module	Interface	Data	Part No.	Info
SK EBGR-1	Electronic brake rectifier	Extension for direct control of an electromechanical brake, IP20, snap-on rail mounting	19140990	<a href="#">TI 19140990</a>
SK EBIOE-2	IO extension <sup>1)</sup>	Extension with 4 DI, 2 AI, 2 DO and 1 AO, IP20, snap-on rail mounting. Firmware version V1.3R1 required.	275900210	<a href="#">TI 275900210</a>

1) Usable with SK 530P and higher

## Installation


### Information

Modules should not be inserted or removed unless the device is free of voltage. The slots may only be used for the intended modules.

Installation of a technology unit separate from the frequency inverter is not possible. It must be connected directly to the frequency inverter.

Installation must be carried out as follows:

1. Switch off the mains voltage, observe the waiting period
2. Push the control terminal cover down slightly or remove
3. Remove the blank cover by activating the release mechanism at the lower edge and removing it with an upward rotating movement
4. Hook the technology unit onto the upper edge and press in lightly until it engages. Take care that the connector strip makes proper contact
5. Close the control terminal cover again



Blank cover and control  
terminal cover



SK TU5-CTR



SK CU5-...







### 3.2 ControlBox SK TU5-CTR

The SK TU5-CTR ControlBox is used for commissioning, configuring and controlling the frequency inverter. It is mounted directly on the slot for technology units or on the SK CU5 module. Communication with the inverter and the power supply of the module is provided by a contact rail. The module cannot be used independently from the inverter.







Display is by means of a five digit seven segment LCD display. Control is via six control keys.

#### 3.2.1 Control keys

		Frequency inverter	parameterisation
	Start key	Switches on the FI The frequency inverter is now enabled with the set jog frequency ( <b>P113</b> ). A pre-set minimum frequency ( <b>P104</b> ) is at least provided. Parameter "Interface" <b>P509</b> and <b>P510</b> must = 0.	Disables parameterisation mode.
	Stop key	Switches off the FI. The output frequency is reduced to the absolute minimum frequency ( <b>P505</b> ) and the frequency inverter shuts down.	
	Selection key	Increases the frequency. Both selection keys pressed simultaneously = Quick stop.	Enables parameterisation mode. Increases the parameter value.
	Selection key	Reduces the frequency Both selection keys pressed simultaneously = Quick stop.	Enables parameterisation mode. Reduces the parameter value.
	OK key	Saves the set frequency value. The version number is displayed during the switch-on phase.	Saves the changed parameter value or switches between parameter number and parameter value.
	Esc key	Changes the direction of rotation.	If a changed value is <u>not</u> to be saved, the parameter mode can be exited by pressing the Esc key.


Further functions can be accessed via combinations of two or more keys:

	If the inverter is switched on: Switch to the parameter level	
	Trigger quick stop by enabling with the keyboard	
	Reset the value to the default setting	
	Flashing:	Only the last 5 bars flash: Warning, inverter overloaded Over a long period this results in a shutdown with an I²t error or a PT error
	Lights:	Depending on the number of bars which are displayed the inverter has a load of 0 % (0 bars) to ≥ 150 % (15 bars).











### 3.2.2 Display

#### 3.2.2.1 Displays









- 1 Inverter load display (with 100% value)
- 2 Parameter set display
- 3 Five digit 7-segment display with prefix and 4 x point
- 4 Three digit 14-segment display for units
- 5 Enable right and enable left
- 6 4 Inverter status displays

#### 3.2.2.2 Operation

5-digit, 7-segment LED display	Operating mode	Display	Comment
	Ready for operation without setpoint present		If the underscores flash slowly the frequency inverter is not ready for operation: <ul style="list-style-type: none"> <li>• Switch-on inhibit: Function "safe pulse block" or "quick stop active"</li> <li>• Enable signal present before the frequency inverter is ready for operation.</li> </ul>
	In operation	Numerical display 	Display of the operating value (e.g. Actual frequency) selected in parameter <b>P001</b>
	In case of a warning		The actual operating display remains until the background changes to yellow.
	In case of fault	Displays the present fault message. Display lights up red. 	Slow flashing of the display indicates that the fault is no longer present and the error message can be acknowledged.
	Parameterisation	Parameter value 	Parameter group: Example motor data (P2 - -)
			Parameter number: Example nominal speed ( <b>P202</b> )
			Parameter value Example: 1360 rpm
			PASS flashes if password protection is enabled in P004. The parameter settings are not saved.

### 3.2.2.3 Status displays

	Fault present		FI is ready to switch-on
	Warning present		Enable (rotates left) present
	Switch-on inhibit present		Enable (rotates right) present

### 3.2.3 Control

The frequency inverter can only be controlled via the control panel, if it has not been previously enabled via the control terminals or via a serial interface (**P509 = 0** and **P510 = 0**).

Once the control panel has been mounted on the frequency inverter and provided with power, the display briefly shows the type of device and the rated power. After this the display for readiness to operate is shown.

If the Start key is pressed, the frequency inverter changes to the operating display (selection **P001**). The frequency inverter supplies 0 Hz or the minimum frequency (**P104**) or jog frequency (**P113**) which has been set.

#### Parameter set display

In the operating display (**P000**) the parameter set display shows the actual parameter set, and for parameterisation ( $\neq$  **P000**), the parameter set which is being parameterised.

For control of the frequency inverter via the control panel, the parameter set can be switched over via **P100** even during operation and will be displayed in the display (P1...P4).

#### Frequency setpoint

The actual frequency setpoint depends on the setting in the parameters "Jog frequency" (**P113**) and "Minimum frequency" (**P104**). With keyboard operation, this value can be altered with the value keys **▲** and **▼** and permanently stored as the jog frequency in **P113** by pressing the OK key.

#### Emergency stop:

By simultaneously pressing the ESC and STOP keys, a quick stop can be initiated.

#### Minimum frequency

Switching to the minimum frequency is carried out by pressing the selection keys **▼** and **▲** simultaneously.

### 3.2.4 Parameterisation

Switching to parameter mode is performed in different ways depending upon the operating states and the enabling source.

1. If enabling is not present via the control panel, control terminals or a serial interface, switch-over from the operating value display to parameterisation mode can be made directly with ▼ or ▲.
2. If an enable is present via the control terminals or a serial interface and the frequency inverter is producing an output frequency, it is also possible to switch to the parameterisation mode directly from the operating value display using the ▼ or ▲ keys.
3. If the frequency inverter has been enabled via the control panel (start key) the parameterisation mode can be reactivated with the key combination START and OK. Exit is only possible using the START key. The STOP key retains its function

#### Changing parameter values

Each parameter has a parameter number → P x x x (Chap. 5 "Parameter").

1. Press ▼ or ▲, to access the parameter area. The display changes to the menu group display P 0 \_\_ ... P 8 \_\_.
2. Press the Start key to open the menu group. All parameters are arranged in a ring structure in the individual menu groups. It is therefore possible to scroll forwards or backwards within this section.
3. Select the required parameter with ▼ or ▲ and press the OK key.
4. Change the setting with ▼ or ▲ and confirm the changed setting by pressing the OK key.
5. Optionally, the parameter can be reset to its default value by pressing the ▼ and ▲ keys simultaneously.

As long as a changed value has not been confirmed by pressing OK key, the value display will flash; this value is not stored in the frequency inverter. Changed values which have not been saved flash. Flashing only stops when these have been saved (by pressing the OK key).

Press the ESC key to exit from the menu.

**Menu structure with the ControlBox**





Figure 4: ControlBox menu structure


**i Information**

Some parameters such as **P420** and **P502** have additional levels (Arrays), in which further settings can be made, e.g.:



### 3.3 Frequency addition and subtraction via control boxes

If the parameter **P549** (PotentiometerBox Function) is set to 4 “Frequency addition” or 5 “Frequency subtraction”, a value can be added or subtracted using the value keys ▲ or ▼ of the ControlBox or the ParameterBox.

If the ENTER key  is pressed, the value is saved in **P113**. The next time the device is started, the value will be added or subtracted immediately.

### 3.4 Connection of multiple devices to one parametrisation tool

In principle it is possible to access several frequency inverters via the **ParameterBox** (SK PAR-3X) or the **NORD CON software**. In the following example, communication is made via the parameterisation tool, by tunnelling the protocols of the individual devices (max. 8) via the common CAN system bus. The following points must be noted:

1. Physical bus structure Establish a CAN connection (system bus) between the devices.
2. Parameterisation

Parameter		Settings on the FI							
No.	Designation	FI 1	FI 2	FI 3	FI 4	FI 5	FI 6	FI 7	FI 8
P503	Master function output	4 (system bus active)							
P512	USS address	0	0	0	0	0	0	0	0
P513 [-3]	Telegram time-out (s)	0.6	0.6	0.6	0.6	0.6	0.6	0.6	0.6
P514	CAN baud rate	5 (250 kBaud)							
P515	CAN address	32	34	36	38	40	42	44	46

3. Connect the parameterisation tool as usual via RS485 (Terminal: X14 type: RJ12) to the **first** frequency inverter.

*Conditions / Restrictions:*

- a. The parameterisation tools must also correspond to the actual software status:

<b>NORDCON</b>	≥ 02.09.xx.xx
<b>ParameterBox</b>	≥ 4.6 R2
<b>NORDAC PRO Advanced</b>	Hardware: BAA, Firmware: V1.3RX

## 4 Commissioning

### WARNING

#### Unexpected movement

Connection of the supply voltage may directly or indirectly set the drive unit into motion. This can cause unexpected movement of the drive and the attached machine, which may result in serious or fatal injuries and/or material damage. Possible causes of unexpected movements are e.g.:

- Parameterisation of an "automatic start"
  - Incorrect parameterisation
  - Control of the device with an enabling signal from a higher level control unit (via IO or bus signals)
  - Incorrect motor data
  - Incorrect encoder connection
  - Release of a mechanical holding brake
  - External influences such as gravity or other kinetic energy which acts on the drive unit
  - In IT networks: Earth fault (short circuit to earth)
- To avoid any resulting hazard the drive or drive chain must be secured against unexpected movements (mechanical blocking and/or decoupling, provision of protection against falling, etc.) In addition, it must be ensured that there are no persons within the area of action and the danger area of the system.

### 4.1 Factory settings

All frequency inverters supplied by Getriebebau NORD are pre-programmed with the default setting for standard applications with 4IE3pole standard motors (same voltage and power). For use with motors with other powers or number of poles, the data from the rating plate of the motor must be input into parameters **P201 ... P207** of the menu group >Motor data<.

### Information

All data from IE3 -/IE4 and IE5+ motors can be pre-set with parameter **P200**. After the function has been used, this parameter is reset to 0 = *no change!* The data are automatically loaded once into parameter **P201 ... P209** and can be compared with the data on the motor type plate.




Figure 5: Motor type plate

**RECOMMENDATION:** For correct operation of the drive unit, it is necessary to input the motor data (name plate) as precisely as possible. In particular, automatic stator resistance measurement using parameter **P220** is recommended.

To automatically determine the stator resistance, **P220 = 1** must be set and confirmed by pressing "ENTER". The value calculated for the line resistance (depending on **P207**) will be saved in **P208**.

Motor data for IE1 / IE2 motors are provided via the NORDCON software. With the aid of the "Import motor parameter" function (also refer to the NORDCON software manual [BU 0000](#)), the required data set can be selected and imported into the frequency inverter.

## 4.2 Selecting the operating mode for motor control

The frequency inverter is able to control motors with efficiency classes IE1 to IE5+. Our motors are designed as asynchronous motors in efficiency classes IE1 to IE3, and IE4 and IE5+ motors are designed as synchronous motors.

In terms of control technology, the operation of synchronous motors shows many special features. In order to achieve ideal results, the frequency inverter was therefore designed for the control of synchronous motors from NORD, which match the type of an IPMSM (Interior Permanent Magnet Synchronous Motor) in terms of structure. In these motors, the permanent magnets are embedded in the rotor. The operation of other manufacturer's motors must be checked by NORD, if required. See also technical information [TI 80-0010](#) "Planning and Commissioning Guideline for NORD IE4 Motors with NORD Frequency Inverters".

### 4.2.1 Explanation of the operating modes (P300)

The frequency inverter provides different operating modes for the control of a motor. All operating modes can be used with either an ASM (asynchronous motor) or a PMSM (Permanent Magnet Synchronous Motor), however various constraints must be complied with. In principle, all these methods are "flux oriented control methods".

#### 1. VFC open-loop mode (P300, setting "0")

This operating mode is based on a voltage-governed flux oriented control method (Voltage Flux Control Mode (VFC)). This is used for both ASMs as well as PMSMs. In association with the operation of asynchronous motors this is often referred to as "ISD control".

Control is carried out without the use of encoders and exclusively on the basis of fixed parameters and the measurement results of actual electrical values. No specific control parameter settings are necessary for the use of this mode. However, parameterisation of the precise motor data is an essential prerequisite for efficient operation.

As a special feature for the operation of an ASM there is also the possibility of control according to a simple V/f characteristic curve. This mode of operation is important if several motors which are not mechanically coupled are to be operated with a single frequency inverter, or if it is only possible to determine the motor data in a comparatively imprecise manner.

Operation according to a V/f characteristic curve is only suitable for drive applications with relatively low demands on the quality of speed control and dynamics (ramp times  $\geq 1$  s). For machines which tend to have relatively large mechanical vibrations due to their construction, control according to a V/f characteristic curve can also be advisable. Typically, V/f characteristic curves are used to control fans, certain types of pump drives or agitators. Operation according to a V/f characteristic curve is activated via parameters (P211) and (P212) (each set to "0").

#### 2. CFC closed-loop – Mode (P300, setting "1")

In comparison with setting "0" "VFC open-loop – Mode", this is generally a control with current-controlled field orientation (Current Flux Control). For this operating mode, which with ASM is functionally identical to the designation previously listed under "servo control", the use of an encoder is mandatory. This way, the motor's exact speed characteristics are recorded and included in the calculation for the motor control. The determination of the rotor position is enabled by the encoder, where for the operation of a PMSM the initial value of the rotor position must be determined. This allows for a more precise and faster control of the drive.


For ASM and PMSM, this operating mode provides the optimal results in control behaviour, and is especially suitable for lifting gear applications or applications with requirements on optimal dynamic behaviour (ramp times  $\geq 0.05$  s). This operating mode has the greatest benefit in connection with a motor of energy efficiency class IE5+ (energy efficiency, dynamics, precision).

#### 3. CFC open-loop –mode (P300, setting "2")



CFC mode is also possible with the open-loop method, i.e. in operation without an encoder. Here, the speed and position detection are determined by "observation" of measurements and setting values. Precise setting of the current and speed controller is also essential for this operating mode. This mode is especially suitable for applications with higher demands for dynamics in comparison with VFC control (ramp times  $\geq 0.25$  s) and e.g. also for pump applications with high starting torques).

### 4.2.2 Overview of controller parameter settings

The following illustration provides an overview of all parameters which are important, depending on the selected operating mode. In principle, the following applies: The more precise the setting, the more accurate the control and the higher the possible values for the dynamics and precision of drive operation. A detailed description of the individual parameters can be found in  Section "Parameter".

		"∅" = Parameter has no meaning		"- " = Leave the parameter in the factory setting			
		"√" = Change to the parameter is relevant					
Group	Parameter	Operating mode					
		VFC open-loop		CFC open-loop		CFC closed-loop	
		ASM	PMSM	ASM	PMSM	ASM	PMSM
Motor data	P201 ... P209	√	√	√	√	√	√
	P210	√ <sup>1)</sup>	√	√	√	√	√
	P211, P212	- <sup>2)</sup>	-	-	-	-	-
	P215, P216	- <sup>1)</sup>	-	-	-	-	-
	P217	√	√	√	√	∅	∅
	P220	√	√	√	√	√	√
	P240	-	√	-	√	-	√
	P241	-	√	-	√	-	√
	P243	-	√	-	√	-	√
	P244	-	√	-	√	-	√
	P246	-	-	√ <sup>3)</sup>	√ <sup>3)</sup>	√	√
P245, 247	-	√	∅	∅	∅	∅	
Controller data	P300	√	√	√	√	√	√
	P301	∅	∅	∅	∅	√	√
	P310, P311, P314, P317 ... P320	∅	∅	√	√	√	√
	P312, P313, P315, P316	∅	∅	-	√	-	√
	P330 ... P333	-	√	-	√	-	√
	P334	∅	∅	∅	∅	-	√

1) For the V/f characteristic curve: precise change to the parameter is important

2) For the V/f characteristic curve: typical setting "0"

3) Only effective above the switch-over point, because the CFC open-loop PMSM first starts with VFC (without the influence of **P246**) and CFC is only effective above the switch-over point

### 4.2.3 Motor control commissioning steps

The main commissioning steps are mentioned below in their ideal order. Correct assignment of the inverter / motor and the mains voltage is assumed. Detailed information, especially for optimisation of the current, speed and position control of asynchronous motors is described in the guide "Control optimisation" (AG 0100). Detailed commissioning and optimisation information for PMSM in CFC closed loop mode can be found in the "Drive optimisation" guide (AG 0101). Please contact our Technical Support.

1. Carry out the motor connection as usual (note  $\Delta$  / Y!). Connect the encoder, if present
2. Connect the mains supply
3. Carry out the factory setting (P523)
4. Select the basic motor from the motor list (P200) (ASM types are at the beginning of the list, PMSM types are at the end, designated by their type (e.g. ...**80T**...))
5. Check the motor data (P201 ... P209) and compare with the type plate / motor data sheet
6. Measure the stator resistance (P220) → P208, P241[-01] are measured, P241[-02] is calculated (Note: if an SPMSM is used, P241[-02] must be overwritten with the value from P241[-01])
7. Encoders: Check the settings (P301, P735)
8. with PMSM only:
  - a. EMF voltage (P240) → motor type plate / motor data sheet
  - b. Determine / set reluctance angle (P243) (not required with NORD motors)
  - c. Peak current (P244) → motor data sheet
  - d. Only for PMSMs in VFC mode:  
determine (P245), (P247)
  - e. Determine (P246)
9. Select the operating mode (P300)
10. Determine / adjust the current control (P312 – P316)
11. Determine / adjust the speed control P310, P311)
12. PMSM only:
  - a. Select the control method (P330)
  - b. Make the settings for the starting behaviour (P331 ... P333)
  - c. Make the settings for the 0 pulse of the encoder P334 ... P335)
  - d. Activation of slip error monitoring (P327  $\neq$  0)

---

#### Information

Further information for commissioning NORD IE4 - motors with NORD frequency inverters can be found in the technical information [TI80\\_0010](#).

---

#### Information

#### HTL encoder length limit


The length of the HTL encoder cable should not exceed 10 m.

---

### 4.3 Minimum configuration of control connections


If the frequency inverter is to be controlled via the digital and analogue inputs, this can be implemented immediately in the condition as delivered. Settings are not necessary for the moment.

#### Minimum circuitry



#### Basic parameters

If the current setting of the frequency inverter is not known, loading the default setting is recommended → **P523 = 1**. The inverter is pre-programmed for standard applications in this configuration. If necessary the following parameters can be changed with the optional ControlBox SK TU5-CTR.



## 4.4 Temperature sensors

The current vector control of the frequency inverter can be further optimised by the use of a *temperature sensor*. By continuous measurement of the motor temperature, the highest precision of regulation by the frequency inverter and the associated optimum speed precision of the motor is achieved at all times. As the temperature measurement starts immediately after (mains) switch-on of the frequency inverter, the frequency inverter provides immediate optimum control, even if the motor has a considerably increased in temperature after an intermediate "Mains off / Mains on" of the frequency inverter.

### Information

To determine the stator resistance of the motor, the temperature range 15 ... 25 °C should not be exceeded.

Excess temperature of the motor is also monitored and at 155 °C (switching threshold for the thermistor) causes the drive unit to shut down with error message E002.

### Information

#### Pay attention to polarity

Temperature sensors are wired semiconductors that must be operated in the conducting direction. For this, the anode must be connected to the "+" contact of the analogue input. The cathode must be connected to earth.

Failure to observe this can lead to false measurements. Motor winding protection is therefore no longer guaranteed.

#### Approved temperature sensors

The function of the approved temperature sensors is comparable. However, their characteristic curves differ. Correct matching of the characteristic curves to the frequency inverter is made by changing the following two parameters.

Sensor type	Shunt resistor [kΩ]	P402[xx] <sup>1)</sup> 0 % Adjustment [%]	P403[xx] <sup>1)</sup> 100 % Adjustment [%]
KTY84-130	2.7	15.4	26.4
PT100	2.7	3.6	4.9
PT1000	2.7	26.8	33.2

1) Xx = Parameter array, depending on the analogue input used

Connection of a temperature sensor is made according to the following examples.

Taking into account the relevant values for the 0% adjustment(**P402**) and 100% adjustment(**P403**), these examples can be used for all of the approved temperature sensors listed above.


### Information

Due to self-heating, the maximum measurement current according to the data sheet must be taken into account for selection of the PT1000/PT100.

### Connection examples

A temperature sensor can be connected to either of the two analogue inputs of the relevant option. In the following examples, analogue input 2 is used.

AO AI2 AI1 0V 10V



### Parameter settings (Analogue input 2)

The following parameters must be set for the function of the temperature sensor.

1. Analogue input 2 function, **P400 [-02] = 48** (motor temperature)
2. Analogue input 2 mode, **P401 [-02] = 1** (negative temperatures are also measured)
3. Comparison of analogue input 2: **P402 [-02]** (V) and **P403 [-02]** (V) for  $R_v$  (k $\Omega$ )
4. Motor temperature monitoring (display): **P739 [-03]**

## 5 Parameter

### WARNING

#### Unexpected movement

Connection of the supply voltage may directly or indirectly set the drive unit into motion. This can cause unexpected movement of the drive and the attached machine, which may result in serious or fatal injuries and/or material damage. Possible causes of unexpected movements are e.g.:

- Parameterisation of an "automatic start"
  - Incorrect parameterisation
  - Control of the device with an enabling signal from a higher level control unit (via IO or bus signals)
  - Incorrect motor data
  - Incorrect encoder connection
  - Release of a mechanical holding brake
  - External influences such as gravity or other kinetic energy which acts on the drive unit
  - In IT networks: Earth fault (short circuit to earth)
- To avoid any resulting hazard the drive or drive chain must be secured against unexpected movements (mechanical blocking and/or decoupling, provision of protection against falling, etc.) In addition, it must be ensured that there are no persons within the area of action and the danger area of the system.

### WARNING

#### Unexpected movement due to changes in the parameterisation

Parameter changes become effective immediately. Under certain conditions, dangerous situations may occur, even when the drive is in standstill. Functions such as **P428** "Automatic starting" or **P420** "Digit inputs" or the "Brake off" setting can put the drive in motion and put persons at risk due to moving parts.

Therefore:

- Changes to parameter settings must only be made when the Frequency Inverter is not enabled.
- During parametrisation works, precautions must be taken to prevent unwanted drive movements (e.g. lifting equipment plunging down). The danger area of the system must not be entered.

 **WARNING****Unexpected movement due to overload**

In case of overload of the drive there is a risk that the motor will "break down" (sudden loss of torque). An overload may be caused e.g. by inadequate dimensioning of the drive unit or by the occurrence of sudden peak loads. Sudden peak loads may be of a mechanical origin (e.g. blockage) or may be caused by extremely steep acceleration ramps (P102, P103, P426).

Depending on the type of application, "breakdown" of the motor may cause unexpected movement (e.g. dropping of loads by lifting equipment).

To prevent any risk, the following must be observed:

- For lifting equipment applications or applications with frequent large load changes, parameter P219 must remain in the factory setting (100 %).
- Do not inadequately dimension the drive unit, provide adequate overload reserves.
- If necessary, provide fall protection (e.g. for lifting equipment) or equivalent protective measures.

A description of the relevant parameters for the frequency inverter can be found below. Access to the parameters is via a parameterisation tool (e.g. NORDCON software) or a control or parameterisation box (Chap. 1.3 "Scope of delivery

")and enables optimal adjustment of the frequency inverter to the drive application. Dependencies of the relevant parameters may result from the various configurations of the frequency inverters.

 **Information****Restricted visibility of parameters with external 24 V supply**

Via terminal 44 the device can be externally supplied with 24 V (X6). This enables the values of most parameters to be read out and changed by the usual parameterisation methods. However, this does not apply for all parameters. The available display range is limited and essentially consists of the setting values for bus communication (Ethernet, CANopen, USS). The device status is not available if the mains supply is not connected (X1). Except for the communication sector, the device is therefore in a switched-off state. For complete diagnosis of the device, a mains supply (X1) is required (230 V for single phase devices, 400 V for 3-phase devices).

 **Information****Ethernet parameterisation**

With power supply via USB (X169 the parameter for setting the Ethernet dialect cannot be changed, Unless 24 V is connected to terminal X6.

Every frequency inverter is factory-set for a motor of the same power. All parameters can be adjusted "online". Four switchable parameter sets are available during operation. The scope of the parameters to be displayed can be influenced using the supervisor parameter **P003**.

The relevant parameters for the device are described in the following. Explanations for parameters which concern the field bus options or the special functionality of the POSICON, for example, can be obtained from the respective supplementary manuals.

The individual parameters are combined into functional groups. The first digit of the parameter number indicates the assignment to a **menu group**:

Menu group	No.	Master function
<b>Operating displays</b>	(P0--)	Display of parameters and operational values
<b>DS402 parameter</b>	(P0--)	Parameter for DS402 drive profile
<b>Basic parameters</b>	(P1--)	Basic device settings such as behaviour when switching on/off
<b>Motor data</b>	(P2--)	Electrical settings for the motor (motor current or starting voltage)
<b>Control parameters</b>	(P3--)	Setting for current and speed controls as well as encoder settings (incremental encoders)
		Settings for the integrated PLC (Details in <a href="#">BU0550</a> )
<b>Control terminals</b>	(P4--)	Assignment of functions for the inputs and outputs
<b>Additional parameters</b>	(P5--)	Primarily monitoring functions and other parameters
<b>Positioning</b>	(P6--)	Setting of the positioning function (details <a href="#">BU0610</a> )
<b>Information</b>	(P7--)	Display of operating values and status messages
<b>Bus parameters</b>	(P8--)	Parameters for Industrial Ethernet (Details in <a href="#">BU0620</a> )

## Information

### Factory setting P523

The factory settings of the entire parameter set can be loaded at any time using parameter **P523**. For example, this can be useful during commissioning if it is not known which device parameters have been previously changed and could have an unexpected influence on the operating behaviour of the drive.

The restoration of the factory settings (**P523**) normally affects all parameters. This means that all motor data must subsequently be checked or reconfigured. However, parameter **P523** also provides a facility for excluding the motor data or the parameters relating to bus communication when the factory settings are restored.

It is advisable to back up the present settings of the frequency inverter beforehand.



P000 (parameter number)	Operating para. disp. (parameter name)	S	P
<b>Setting range</b> or display range	Display of typical display format (e.g. (bin = binary)) of possible setting range and number of decimal places		
<b>Arrays</b>	[-01] If parameters have a substructure in several arrays, this is shown here.		
<b>Factory setting</b>	{ 0 } Typical default setting of parameters in the as-delivered condition of the FI, or to which it is set after carrying out "Restore factory settings" (see parameter <b>P523</b> ).		
<b>Scope of application</b>	List of variants for which this parameter applies. If the parameter is generally valid, i.e. for the entire model series, this line is omitted.		
<b>Description</b>	Description, function, meaning and similar for this parameter.		
<b>Note</b>	Additional notes about this parameter		
<b>Setting values</b> or display values	List of possible settings with description of their respective functions		

Figure 6: Explanation of parameter description



### Information

#### Parameter description

Unused lines of information are not listed.

#### Notes / Explanations

Label	Designation	Meaning
<b>S</b>	Supervisor parameter	The parameter can only be displayed and changed if the relevant supervisor code has been set (see parameter <b>P003</b> ).
<b>P</b>	Depending on the parameter set	The parameter provides various setting options which depend on the selected parameter set.
<b>!</b>	Parameter name	For DS402 parameters <b>P046</b> , <b>P047</b> , <b>P048</b> , <b>P056</b> , <b>P057</b> , <b>P062</b> , <b>P063</b> and <b>P064</b> the precise designations can be obtained from the arrays.

## 5.1 Parameter overview

### Operating displays

<b>P000</b> Operating para. disp	<b>P001</b> Select of disp.value	<b>P002</b> Display factor
<b>P003</b> Supervisor-Code	<b>P004</b> Password	<b>P005</b> Change password

### DS402 parameters

<b>P020</b> Target velocity	<b>P021</b> Velocity demand	<b>P022</b> Control effort
<b>P023</b> Velocity amount	<b>P024</b> Velocity acceleration	<b>P025</b> Velocity deceleration
<b>P026</b> Quick Stop	<b>P027</b> Percent demand	<b>P028</b> Control word
<b>P029</b> Status word	<b>P030</b> Stop opt. code	<b>P031</b> Modes of operation
<b>P032</b> Modes of operation display	<b>P033</b> Target torque	<b>P034</b> Actual digital inputs
<b>P035</b> Digital outputs	<b>P046</b> Actual position / inc.	<b>P047</b> Follow time-out Pos. / Time
<b>P048</b> Position window / timeout	<b>P049</b> Target position	<b>P050</b> Enc. polarity
<b>P051</b> Max profile velocity	<b>P052</b> Profile velocity	<b>P053</b> Motion pro type
<b>P054</b> Position notation	<b>P055</b> Position dimension	<b>P056</b> Gear ratio
<b>P057</b> Feed constant / rotations	<b>P058</b> Homing method	<b>P059</b> Homing speeds
<b>P060</b> Homing acceleration	<b>P061</b> Homing offset	<b>P062</b> Velocity actual
<b>P063</b> Velocity time window	<b>P064</b> speeds threshold / time	<b>P065</b> Prof. acceleration
<b>P066</b> Prof. deceleration	<b>P067</b> Quick Stop deceleration	<b>P068</b> Velocity notation
<b>P069</b> Velocity speeds	<b>P070</b> Acceleration notation	<b>P071</b> Acceleration dimension
<b>P072</b> Target velocity	<b>P073</b> Torque act value	<b>P074</b> Current act value
<b>P075</b> DC link circuit voltage	<b>P076</b> Torque ramp	

### Basic parameters

<b>P100</b> Parameter set	<b>P101</b> Copy parameter set	<b>P102</b> Acceleration time
<b>P103</b> Deceleration time	<b>P104</b> Minimum frequency	<b>P105</b> Maximum frequency
<b>P106</b> Ramp smoothing	<b>P107</b> Brake response time	<b>P108</b> Disconnection mode
<b>P109</b> DC brake current	<b>P110</b> Time DC-brake on	<b>P111</b> P-factor torque limit
<b>P112</b> Torque current limit	<b>P113</b> Jog frequency	<b>P114</b> Brake release time
<b>P120</b> Option monitoring		

### Motor data

<b>P200</b> Motor list	<b>P201</b> Nominal motor frequency	<b>P202</b> Nominal motor speed
<b>P203</b> Nominal motor current	<b>P204</b> Nominal motor voltage	<b>P205</b> Nominal motor power
<b>P206</b> Motor cos phi	<b>P207</b> Motor circuit	<b>P208</b> Stator resistance
<b>P209</b> No-load current	<b>P210</b> Static boost	<b>P211</b> Dynamic boost
<b>P212</b> Slip compensation	<b>P213</b> Amplification ISD control	<b>P214</b> Torque lead time
<b>P215</b> Boost lead time	<b>P216</b> Boost lead time	<b>P217</b> Oscillation damping
<b>P218</b> Modulation depth	<b>P219</b> Auto. flux adaptation	<b>P220</b> Par. identification
<b>P240</b> PMSM EMF voltage	<b>P241</b> PMSM inductance	<b>P243</b> Reluct. angle IPMSM
<b>P244</b> PMSM peak current	<b>P245</b> Power system stabilisation PMSM VFC	<b>P246</b> Moment of inertia
<b>P247</b> Switchover frequency VFC PMSM		

### Control parameters

#### Control parameters

<b>P300</b> Control method	<b>P301</b> Incremental encoder	<b>P310</b> Speed ctrl P
<b>P311</b> Speed ctrl I	<b>P312</b> Torque curr. ctrl. P	<b>P313</b> Torque curr. ctrl. I
<b>P314</b> Torq curr ctrl limit	<b>P315</b> Field curr. ctrl. P	<b>P316</b> Field curr. ctrl. I
<b>P317</b> Field curr. ctrl. lim.	<b>P318</b> P-weak	<b>P319</b> P-weak I
<b>P320</b> Weak border	<b>P321</b> Speed ctr. I brake off	<b>P325</b> Function encoder
<b>P326</b> Ratio encoder	<b>P327</b> Speed slip error	<b>P328</b> Speed slip delay
<b>P330</b> Ident startrotor pos	<b>P331</b> Switch over freq.	<b>P332</b> Hyst.switchover freq
<b>P333</b> Flux feedb.fact.PMSM	<b>P334</b> Encoder offset PMSM	<b>P336</b> Mode Rotorpos ident
<b>P350</b> PLC functionality	<b>P351</b> PLC set val. select.	<b>P353</b> Bus status via PLC
<b>P355</b> PLC Integer setvalue	<b>P356</b> PLC long setvalue	<b>P360</b> PLC display value
<b>P370</b> PLC status		

### Control terminals

#### Control terminals

<b>P400</b> Analog input func.	<b>P401</b> Analog input mode	<b>P402</b> Analog input bal. 0%
<b>P403</b> Analog input bal. 100%	<b>P404</b> Analog input filter	<b>P405</b> V/C Analog
<b>P410</b> Min. freq. a-in 1/2	<b>P411</b> Max. freq. a-in 1/2	<b>P412</b> Nom.val process ctrl
<b>P413</b> PID control P comp.	<b>P414</b> PID control I comp.	<b>P415</b> PID control D comp.
<b>P416</b> Ramptime PI setpoint	<b>P417</b> Offset analog output	<b>P418</b> Analog output func.
<b>P419</b> Analog output scal.	<b>P420</b> Digit inputs	<b>P423</b> Safety SS1 max. time
<b>P424</b> Safe Dig.input	<b>P425</b> Function PTC input	<b>P426</b> Quick stop time
<b>P427</b> Quick stop on Error	<b>P428</b> Automatic starting	<b>P429</b> Fixed frequency 1
<b>P430</b> Fixed frequency 2	<b>P431</b> Fixed frequency 3	<b>P432</b> Fixed frequency 4
<b>P433</b> Fixed frequency 5	<b>P434</b> Digital out function	<b>P435</b> Dig. out scaling
<b>P436</b> Dig. out. hysteresis	<b>P460</b> Watchdog time	<b>P464</b> Fixed Frequency Mode
<b>P465</b> Fixed freq. Array	<b>P466</b> Min.freq. proc.ctrl.	<b>P475</b> Delay on/off switch
<b>P480</b> Funct. BusIO In Bits	<b>P481</b> Funct-BusIO Out Bits	<b>P482</b> Norm. BusIO Out Bits
<b>P483</b> Hyst. BusIO Out Bits	<b>P499</b> Safety CRC	

## Additional parameters

### Additional parameters

<b>P500</b> Language	<b>P501</b> Inverter name	<b>P502</b> Value Masterfunction
<b>P503</b> Leading func. output	<b>P504</b> Pulse frequency	<b>P505</b> Absolute mini. freq.
<b>P506</b> Automatic acknowledged.	<b>P509</b> Source control word	<b>P510</b> Source Setpoints
<b>P511</b> USS baud rate	<b>P512</b> USS address	<b>P513</b> Telegram time-out
<b>P514</b> CAN bus baud rate	<b>P515</b> CAN bus address	<b>P516</b> Skip frequency 1
<b>P517</b> Skip freq. area 1	<b>P518</b> Skip frequency 2	<b>P519</b> Skip freq. area 2
<b>P520</b> Flying start	<b>P521</b> Fly. start resol.	<b>P522</b> Flying start offset
<b>P523</b> Factory setting	<b>P525</b> Load control max.	<b>P526</b> Load control min.
<b>P527</b> Load control freq.	<b>P528</b> Load monitoring delay	<b>P529</b> Mode Load control
<b>P533</b> Factor I <sup>2</sup> t motor	<b>P534</b> Torque disconn. limit	<b>P535</b> I <sup>2</sup> t motor
<b>P536</b> Current limit	<b>P537</b> Pulse Disconnection	<b>P538</b> Check input voltage
<b>P539</b> Check output voltage	<b>P540</b> Mode phase sequence	<b>P541</b> Set bus / IOE out
<b>P542</b> Set analog out	<b>P543</b> Bus actual value	<b>P546</b> Func. bus-setpoint
<b>P549</b> Pot box function	<b>P550</b> µSD jobs	<b>P551</b> Drive profile
<b>P552</b> CAN master cycle	<b>P553</b> PLC set values	<b>P554</b> Chopper min.
<b>P555</b> P-limit chopper	<b>P556</b> Braking resistor	<b>P557</b> Brake resistor type
<b>P558</b> Flux delay	<b>P559</b> DC Run-on time	<b>P560</b> Mode of param.save
<b>P583</b> Motor phase sequence		

## Information

<b>P700</b> Actual operating status	<b>P701</b> Last fault	<b>P702</b> Freq. last error
<b>P703</b> Current. last error	<b>P704</b> Volt. last error	<b>P705</b> Dc. link volt. last er.
<b>P706</b> P set last error	<b>P707</b> Software version	<b>P708</b> State of digital in.
<b>P709</b> V/C analog input	<b>P710</b> V/C analog output	<b>P711</b> State of digital out
<b>P712</b> Energy consumption	<b>P713</b> Energy brake res.	<b>P714</b> Operating time
<b>P715</b> Running time	<b>P716</b> Current frequency	<b>P717</b> Current speed
<b>P718</b> Current set freq.	<b>P719</b> Actual current	<b>P720</b> Act. torque current
<b>P721</b> Actual field current	<b>P722</b> Current voltage	<b>P723</b> Voltage -d
<b>P724</b> Voltage -q	<b>P725</b> Current cos phi	<b>P726</b> Apparent power
<b>P727</b> Mechanical power	<b>P728</b> Input voltage	<b>P729</b> Torque
<b>P730</b> Field	<b>P731</b> Parameter set	<b>P732</b> Phase U current
<b>P733</b> Phase V current	<b>P734</b> Phase W current	<b>P735</b> Speed encoder
<b>P736</b> D.c. link voltage	<b>P737</b> Usage rate brakeres.	<b>P738</b> Usage rate motor
<b>P739</b> Temperature	<b>P740</b> PZD bus in	<b>P741</b> PZD bus out
<b>P742</b> Data base version	<b>P743</b> Inverter ID	<b>P744</b> Configuration
<b>P745</b> Option version	<b>P746</b> Option status	<b>P747</b> Inverter Volt. Range
<b>P748</b> Status CANopen	<b>P750</b> Error statistics	<b>P751</b> Counter statistics
<b>P752</b> Last extended error	<b>P780</b> Device ID	<b>P799</b> Op.-time last error

**5.1.1 Operating display**

P001	Selection of display value		
<b>Setting range</b>	0 ... 65		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	Selection of the operating display for display via 7-segment display.		
Display values	Value	Meaning	
	0	Actual frequency [Hz]	Actually output frequency supplied
	1	Speed [rpm]	Calculated speed
	2	Setpoint frequency [Hz]	Output frequency corresponding to the present setpoint. This need not correspond with the actual output frequency.
	3	Current [A]	Actually measured output current
	4	Torque current [A]	Torque-generating output current
	5	Voltage [V AC]	Present AC voltage at the device output
	6	D.c. link voltage [V DC]	The " <i>Link circuit voltage</i> " is the internal FI DC voltage. Amongst other things, this depends on the level of the mains voltage.
	7	cos Phi [-]	Calculated value of actual power factor
	8	Apparent power KVA	Calculated value of actual apparent power
	9	Real power [kW]	Calculated value of actual effective power
	10	Torque [%]	Calculated value of actual torque
	11	Field [%]	Calculated value of actual rotating field in the motor
	12	Hours of operation [h]	Time for which mains voltage has been supplied to the device
	13	Operating time Enable [h]	" <i>Enabled operating hours</i> " is the time for which the device has been enabled.
	14	Analog input1 [%]	Actual value present at analogue input 1 of the FI
	15	Analog input2 [%]	Actual value present at analogue input 2 of the FI
	16	... 18	<i>Reserved, POSICON</i>
	19	Heat sink temperature [°C]	Actual temperature of heat sink
	20	Usage rate motor [%]	Average motor load based on known motor data P201 ... P209
	21	Brake load R [%]	" <i>Usage rate brakeres.</i> " is the average load on the braking resistor based on the known resistance data P556 ... P557
	22	Ambient UZW temp. [°C]	Actual internal temperature of the device
	23	Motor temperature	measured via temperature sensor (KTY-84, PT100, PT1000)
	24	... 29	<i>Reserved</i>
	30	Actual setp. freq. [Hz]	" <i>Actual motor potentiometer function setpoint with storage</i> ": P420 ... = 71/72.. With this function the setpoint can be read out or pre-set (without the drive running).
	31	... 39	<i>Reserved</i>
	40	PLC CtrlBox value	Visualisation mode for PLC communication
	41	... 59	<i>Reserved, POSICON</i>
	60	R stator ident.	Stator resistance determined by measurement P220
	61	R rotor ident.	Rotor resistance determined by measurement (P220 Function 2)
	62	L scat. stator ident.	Stray inductance determined by measurement (P220 Function 2)
	63	L stator ident.	Inductance determined by measurement (P220 Function 2)
	64	Clock input 1	
	65		<i>Reserved</i>

<b>P002</b>	<b>Display factor</b>		<b>S</b>
<b>Setting range</b>	0.01 ... 999.99		
<b>Factory setting</b>	{ 1 }		
<b>Description</b>	The selected operating value in parameter <b>P001</b> “ <i>Select display value</i> ” is multiplied by the scaling factor in <b>P000</b> and displayed in the “ <i>Operating para. display</i> ”. It is therefore possible to display system-specific operating values e. g. the throughput quantity.		
<b>P003</b>	<b>Supervisor code</b>		
<b>Setting range</b>	0 ... 9999		
<b>Factory setting</b>	{ 1 }		
<b>Description</b>	The scope of the visible parameters can be influenced by setting the supervisor code.		
<b>Note</b>	<b>Display via NORDCON</b> If parameterisation is carried out with the NORDCON software, the settings 2 ... 9999 the settings are as for the 0 setting.		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	Supervisor mode Off	The supervisor parameters are not visible.
	1	Supervisor mode On	All parameters are visible.
	2	Supervisor mode Off	Only the menu group 0 (without supervisor parameter) is visible.
<b>P004</b>	<b>Password</b>		<b>S</b>
<b>Setting range</b>	- 32768 ... 32767		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	Entry of the password from <b>P005</b> to unlock all standard parameters. Safety parameters are excluded from this.		
<b>Note</b>	The value which is entered here is lost when the control board / frequency inverter is switched off. Password protection is active again.		
<b>P005</b>	<b>Change password</b>		<b>S</b>
<b>Setting range</b>	-32768 ... 32767		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	Specification of a password to protect the setting values of standard parameters from unauthorised changes. Password protection can be temporarily suspended via <b>P004</b> . Safety parameters are excluded from this.		
<b>Note</b>	The password is generally suspended with setting {0} in <b>P005</b> .		

### 5.1.2 DS402 parameter

#### Information

For parameters **P046**, **P047**, **P048**, **P056**, **P057**, **P062**, **P063** and **P064** the precise designations can be obtained from the arrays. These parameters are indicated with an exclamation mark (!) in the top line.

#### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P020</b>	<b>6042 Target velocity</b>	<b>S</b>
<b>Setting range</b>	-24000... 24000 rpm	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	RxPDO	
<b>Data type</b>	INTEGER 16Bit	
<b>Description</b>	DS402 object 6042h: Target speed in "Velocity" operating mode.	

<b>P021</b>	<b>6043 Velocity demand</b>	<b>S</b>
<b>Display range</b>	-32768...32767 rpm	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	TxPDO	
<b>Data type</b>	INTEGER 16Bit	
<b>Description</b>	DS402 object 6043h: Actual target speed after the ramp function in "Velocity" operating mode.	

#### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P022</b>	<b>6044 Control effort</b>	<b>S</b>
<b>Display range</b>	-32768...32767 rpm	
<b>Factory settings</b>	{ 0 }	
<b>PDO mapping</b>	TxPDO	
<b>Data type</b>	INTEGER 16Bit	
<b>Description</b>	DS402 object 6044h: Present actual speed in "Velocity" mode.	

<b>P023</b>	<b>6046 Velocity amount</b>		<b>S</b>
<b>Setting range</b>	[-01] = 0... 24000 rpm	[-02] = 1... 24000 rpm	
<b>Arrays</b>	[-01] = Minimum speed	[-02] = Maximum speed	
<b>Factory setting</b>	[-01] = { 0 }	[-02] = { 1500 }	
<b>PDO mapping</b>	[-01] = No	[-02] = No	
<b>Data type</b>	[-01] = UNSIGNED 32Bit	[-02] = UNSIGNED 32Bit	
<b>Description</b>	DS402 object 6046h: Minimum or maximum speed in "Velocity" mode.		

<b>P024</b>	<b>6048 Velocity accele</b>		<b>S</b>
<b>Setting range</b>	[-01] = 1... 2400000 rpm	[-02] = 0... 32767 sec	
<b>Arrays</b>	[-01] = Delta-N acceleration	[-02] = Delta-T acceleration	
<b>Factory setting</b>	[-01] = { 1500 }	[-02] = { 2 }	
<b>PDO mapping</b>	[-01] = No	[-02] = No	
<b>Data type</b>	[-01] = UNSIGNED 32 Bit	[-02] = UNSIGNED 16 Bit	
<b>Description</b>	DS402 object 6048h: Acceleration ramp in "Velocity" mode.		
<b>P025</b>	<b>6049 Velocity decele</b>		<b>S</b>
<b>Setting range</b>	[-01] = 1... 2400000 rpm	[-02] = 0... 32767 sec	
<b>Arrays</b>	[-01] = Delta-N braking	[-02] = Delta-T braking	
<b>Factory setting</b>	[-01] = { 1500 }	[-02] = { 2 }	
<b>PDO mapping</b>	[-01] = No	[-02] = No	
<b>Data type</b>	[-01] = UNSIGNED 32 Bit	[-02] = UNSIGNED 16 Bit	
<b>Description</b>	DS402 object 6049h: Braking ramp in "Velocity" operating mode.		
<b>P026</b>	<b>604A Velocity qStop</b>		<b>S</b>
<b>Setting range</b>	[-01] = 1... 2400000 rpm	[-02] = 0... 32767 sec	
<b>Arrays</b>	[-01] = Delta-N Quick stop	[-02] = Delta-T Quick stop	
<b>Factory setting</b>	[-01] = { 1500 }	[-02] = { 1 }	
<b>PDO mapping</b>	[-01] = No	[-02] = No	
<b>Data type</b>	[-01] = UNSIGNED 32 Bit	[-02] = UNSIGNED 16 Bit	
<b>Description</b>	DS402 object 604Ah: Braking ramp when quick stop is triggered in "Velocity" operating mode		
<b>P027</b>	<b>6053 Percent demand</b>		<b>S</b>
<b>Display range</b>	-32768... 32767 ( -200%... 200%)		
<b>Factory setting</b>	{ 0 }		
<b>PDO mapping</b>	TxPDO		
<b>Data type</b>	INTEGER 16Bit		
<b>Description</b>	DS402 object 6053h: Actual target speed in percentage of the setpoint value after the ramp function in "Velocity" mode.		
<b>P028</b>	<b>6040 Controlwort</b>		<b>S</b>
<b>Setting range</b>	-32768 ... 32767		
<b>Factory setting</b>	{ 0 }		
<b>PDO mapping</b>	RxPDO		
<b>Data type</b>	INTEGER 16Bit		
<b>Description</b>	DS402 object 6040h: Control word for control of the frequency inverter in the DS402 drive profile.		



### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.



<b>P029</b>	<b>6041 Statuswort</b>	<b>S</b>
<b>Display range</b>	-32768 ... 32767	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	TxPDO	
<b>Data type</b>	INTEGER 16 Bit	
<b>Description</b>	DS402 object 6041h: The status word shows the actual status of the frequency inverter in the DS402 drive profile.	

<b>P030</b>	<b>605D Stop opt. code</b>	<b>S</b>
<b>Setting range</b>	0 ... 2	
<b>Factory setting</b>	{ 2 }	
<b>PDO mapping</b>	No	
<b>Data type</b>	INTEGER 16 Bit	
<b>Description</b>	DS402 object 605Dh: Setting of the behaviour if Bit 8 "Stop" is set in the control word.	
<b>Setting values</b>	<b>Value</b>	<b>Function</b>
	0	Disable voltage
	1	Brake ramp P025
	2	Quick stop P026
		<b>Description</b>
		The frequency inverter output voltage is switched off; the motor runs down freely.
		The frequency inverter reduces the frequency according to the braking ramp from <b>P025</b> .
		The frequency inverter reduces the frequency according to the quick stop ramp from <b>P026</b> .

<b>P031</b>	<b>6060 Modes of operat</b>	<b>S</b>
<b>Setting range</b>	-1 ... 6	
<b>Factory setting</b>	{ 2 }	
<b>PDO mapping</b>	RxPDO	
<b>Data type</b>	INTEGER 8 Bit	
<b>Description</b>	DS402 object 6060h: Setting of the operating mode in the DS402 drive profile.	
<b>Setting values</b>	<b>Value</b>	<b>Function</b>
	-1	NORD Mode
	0	Reserved
	1	Profile Position
	2	Velocity mode
	3	Profile Velocity
	4	Profile Torque
	5	Reserved
	6	Homing mode
		<b>Description</b>
		NORD standard mode
		Position and orientation control
		Speed control with minimum and maximum speeds
		Speed control without minimum and maximum speeds
		Torque control
		Reference run

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P032	6061 Modes of op.Dis		S
Display range	-1 ... 6		
Factory setting	{ 3 }		
PDO mapping	TxPDO		
Data type	INTEGER 8 Bit		
Description	DS402 object 6061h: Display of the actual operating mode in the DS402 drive profile.		
Setting values	Value	Function	Description
	-1	NORD Mode	NORD standard mode
	0	Reserved	
	1	Profile Position	Position and orientation control
	2	Velocity mode	Speed control with minimum and maximum speeds
	3	Profile Velocity	Speed control without minimum and maximum speeds
	4	Profile Torque	Torque control
	5	Reserved	
	6	Homing mode	Reference run

P033	6071 Target torque		S
Setting range	-400 ... 400 %		
Factory setting	[-01] = { 100 }		
PDO mapping	RxPDO		
Data type	INTEGER 16 Bit		
Description	DS402 object 6071h: Target torque for "Profile Torque" operating mode.		



### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P034	60FD Digital inputs		S
Display range	-2147483648 ... 2147483647		
Factory setting	{ 0 }		
PDO mapping	TxPDO		
Data type	INTEGER 32 Bit		
Description	DS402 object 60FDh: Displays the actual status of the digital inputs.		
Setting values	Value	Function	Description
	Bit: 0	Negative limit switch	Negative limit switch
	Bit: 1	Positive limit switch	Positive limit switch
	Bit: 2	Home switch	Reference switch
	Bit: 3	... 15: reserved	
	Bit: 16	Bus/ 2nd IOE Dig In1	
	Bit: 17	Digital input 2 (DI2)	
	Bit: 18	Digital input 3 (DI3)	
	Bit: 19	Digital input 4 (DI4)	
	Bit: 20	Digital input 5 (DI5)	
	Bit: 21	Digital input 6 (DI6)	
	Bit: 22	Digital input 7 (DI7)	
	Bit: 23	Digital input 8 (DI8)	
	Bit: 24	Digital input 9 (DI9)	
	Bit: 25	Digital input 10 (DI10)	
	Bit: 26	Digital input 11 (DI11)	
	Bit: 27	Digital input 12 (DI12)	
	Bit: 28	Digital function, analogue input 1 (AI1)	
	Bit: 29	Digital function, analogue input 2 (AI2)	

 **Information**

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P035	60FE Digital outputs		S
<b>Setting range</b>	-2147483648 ... 2147483647		
<b>Factory setting</b>	{ 0 }		
<b>PDO mapping</b>	RxPDO		
<b>Data type</b>	INTEGER 32 Bit		
<b>Description</b>	DS402 object 60FEh: The digital outputs of the frequency inverter can be set with this object.		
<b>Setting values</b>	<b>Value</b>	<b>Function</b>	<b>Description</b>
	Bit: 0	Set brake	Brake control
	Bit: 1	... 15 reserved	
	Bit: 16	Multi-function relay 1 (K1)	
	Bit: 17	Multi-function relay 2 (K2)	
	Bit: 18	Digital output 1 (DO1)	
	Bit: 19	Digital output 2 (DO2)	
	Bit: 20	Digital output 3 (DO3)	
	Bit: 21	Digital output 4 (DO4)	
	Bit: 22	Digital output 5 (DO5)	
	Bit: 23	Digital output 6 (DO6)	
	Bit: 24	Analogue output 1 (AO1) - digital function AO1	

 **Information**

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P046	6063 & 6064 Akt. Position		!	S
<b>Display range</b>	[-01] =	-2147483648 ... 2147483647 inc	[-02] =	-2147483.648 ... 2147483.647 rev
<b>Arrays</b>	[-01] =	6063 Akt. Pos Inc.	[-02] =	6064 Akt. Position
<b>Factory setting</b>	[-01] =	{ 0 }	[-02] =	{ 0 }
<b>PDO mapping</b>	[-01] =	TxPDO	[-02] =	TxPDO
<b>Data type</b>	[-01] =	INTEGER 32 Bit	[-02] =	INTEGER 32 Bit
<b>Description</b>	[-01] =	DS402 object 6063h: Shows the actual position as an incremental value	[-02] =	DS402 object 6064h: Shows the actual position in rotations.

P047		6065 & 6066 Slip error		!	S
Arrays	[-01] =	6065 Follow err wind	[-02] =	6066 Follow timeout	
Setting range	[-01] =	0 ... 2147483.647 rev	[-02] =	0... 32767 ms	
Factory setting	[-01] =	{ 0 }	[-02] =	{ 200 }	
PDO mapping	[-01] =	No	[-02] =	No	
Data type	[-01] =	UNSIGNED 32 Bit	[-02] =	UNSIGNED 16 Bit	
Description	[-01] =	DS402 object 6065h: Maximum permissible deviation of the actual position from the setpoint position.	[-02] =	DS402 object 6066h: Permissible time for a slip error.	

P048		6067 & 6068 target window		!	S
Arrays	[-01] =	6067 Position window	[-02] =	6068 Pos wind timeout	
Setting range	[-01] =	0 ... 2147483.647 rev	[-02] =	0... 32767 ms	
Factory setting	[-01] =	{ 0.1 }	[-02] =	{ 200 }	
PDO mapping	[-01] =	No	[-02] =	No	
Data type	[-01] =	UNSIGNED 32 Bit	[-02] =	UNSIGNED 16 Bit	
Description	[-01] =	DS402 object 6067h: Permissible deviation of the actual position relative to the target position in which the target is considered to have been reached.	[-02] =	DS402 object 6068h: Dwell time in the target window so that the target position is considered to have been reached.	

P049		607A Target position			S
Setting range		-2147483.648 ... 2147483.647 rev			
Factory setting		{ 0 }			
PDO mapping		RxPDO			
Data type		INTEGER 32 Bit			
Description		DS402 object 607Ah: Position setpoint in "Profile Position" operating mode.			

P050		607E Polarity			S
Setting range		0 ... 192			
Factory setting		{ 0 }			
PDO mapping		No			
Data type		UNSIGNED 8 Bit			
Description		DS402 object 607Eh: Setting of encoder polarity			
Setting values		Value	Function	Description	
		Bit 0	... 5 reserved		
		Bit 6	Inverse speed polarity		
		Bit 7	Inverse position polarity		
					0 = Direction reversal disabled, 1 = Direction reversal enabled

P051		607F Max pro velocit			S
Setting range		0... 24000 rpm			
Factory setting		{ 1500 }			
PDO mapping		No			
Data type		UNSIGNED 32 Bit			
Description		DS402 object 607Fh: Maximum profile speed in "Profile Position" and "Profile Velocity" operating modes.			

<b>P052</b>	<b>6081 Profile velocit</b>		<b>S</b>
<b>Setting range</b>	0... 24000 rev		
<b>Factory setting</b>	{ 1500 }		
<b>PDO mapping</b>	RxPDO		
<b>Data type</b>	UNSIGNED 32 Bit		
<b>Description</b>	DS402 object 6081h: Speed setpoint in "Profile Position" and "Profile Velocity" modes.		
<b>P053</b>	<b>6086 Motion pro type</b>		<b>S</b>
<b>Setting range</b>	0 ... 1		
<b>Factory setting</b>	{ 0 }		
<b>PDO mapping</b>	No		
<b>Data type</b>	INTEGER 16 Bit		
<b>Description</b>	DS402 object 6086h: Type of acceleration or deceleration ramps in "Profile Position" and "Profile Velocity" operating modes.		
<b>Setting values</b>	<b>Value</b>	<b>Function</b>	<b>Description</b>
	0	Linear ramp	
	1	sin <sup>2</sup> ramp	

P055		608A Pos dimension		S	
Setting range	0 ... 1				
Factory setting	{ 0 }				
PDO mapping	No				
Data type	UNSIGNED 8 Bit				
Description	DS402 object 608Ah: Setting of the unit.				
Setting values	Value	Function	Description		
	0	rev [rotations]			
	1	m [Metre]			
P056		6091 Gear ratio		! S	
Arrays	[-01] =	6091_1 Gear ratio	[-02] =	6091_2 Gear ratio	
Setting range	[-01] =	1... 2147483647	[-02] =	1... 2147483647	
PDO mapping	[-01] =	No	[-02] =	No	
Data type	[-01] =	UNSIGNED 32 Bit	[-02] =	UNSIGNED 32 Bit	
Factory setting	[-01] =	{ 1 }	[-02] =	{ 1 }	
Description	DS402 object 6091h: Sets the speed ratio and speed reduction ratio				
P057		6092 Feed constant		! S	
Arrays	[-01] =	6092_1 feed constant	[-02] =	6092_2 feed constant	
Setting range	[-01] =	1 ... 2147483647 m	[-02] =	1 ... 2147483647 rev	
Factory setting	[-01] =	{ 1 }	[-02] =	{ 10 }	
PDO mapping	[-01] =	No	[-02] =	No	
Data type	[-01] =	UNSIGNED 32 Bit	[-02] =	UNSIGNED 32 Bit	
Description	DS402 object 6092h: Sets the feed constants.				
Note	The values are only taken into account in scaling if in <b>P055</b> "DS402 Position dimension" (608A) the setting value "Metres" is selected.				

P058	6098 Homing method		S
Setting range	0 ... 35		
Factory setting	{ 0 }		
PDO mapping	No		
Data type	INTEGER 8 Bit		
Description	DS402 object 6098h: Setting of the required reference run method.		
Setting values	Value	Function	Description
	0	No reference run	No reference run
	1	Reference run to negative limit switch taking the index pulse into account.	
	2	Reference run to positive limit switch taking the index pulse into account.	
	3	Reference run to the left falling switching flank of the reference switch, taking the index pulse into account	
	4	Reference run to the left rising switching flank of the reference switch, taking the index pulse into account	
	5	Reference run to the right falling switching flank of the reference switch, taking the index pulse into account	
	6	Reference run to the right rising switching flank of the reference switch, taking the index pulse into account	
	7	Reference run to the left falling flank of the reference switch with consideration of the index pulse and limitation of movement by the positive limit switch	
	8	Reference run to the left rising flank of the reference switch with consideration of the index pulse and limitation of movement by the positive limit switch	
	9	Reference run to the right rising flank of the reference switch with consideration of the index pulse and limitation of movement by the positive limit switch	
	10	Reference run to the right falling flank of the reference switch with consideration of the index pulse and limitation of movement by the positive limit switch	
	11	Reference run to the right falling flank of the reference switch with consideration of the index pulse and limitation of movement by the positive limit switch	
	12	Reference run to the right rising flank of the reference switch with consideration of the index pulse and limitation of movement by the negative limit switch	
	13	Reference run to the left rising flank of the reference switch with consideration of the index pulse and limitation of movement by the negative limit switch	
	14	Reference run to the left falling flank of the reference switch with consideration of the index pulse and limitation of movement by the negative limit switch	
	15	Reserved	
	16		
	17	Reference run to negative limit switch without taking the index pulse into account.	
	18	Reference run to positive limit switch without taking the index pulse into account.	
	19	Reference run to the left falling switching flank of the reference switch without taking the index pulse into account	
	20	Reference run to the left rising switching flank of the reference switch without taking the index pulse into account	
	21	Reference run to the right falling switching flank of the reference switch without taking the index pulse into account	
	22	Reference run to the right rising switching flank of the reference switch without taking the index pulse into account	
	23	Reference run to the left falling flank of the reference switch without consideration of the index pulse and with limitation of movement by the positive limit switch	
	24	Reference run to the left rising flank of the reference switch without consideration of the index pulse and with limitation of movement by the positive limit switch	
	25	Reference run to the right rising flank of the reference switch without consideration of the index pulse and with limitation of movement by the positive limit switch	
	26	Reference run to the right falling flank of the reference switch without consideration of the index pulse and with limitation of movement by the positive limit switch	
	27	Reference run to the right falling flank of the reference switch without consideration of the index pulse and with limitation of movement by the positive limit switch	
	28	Reference run to the right rising flank of the reference switch without consideration of the index pulse and with limitation of movement by the negative limit switch	
	29	Reference run to the left rising flank of the reference switch without consideration of the index pulse and with limitation of movement by the negative limit switch	
	30	Reference run to the right falling flank of the reference switch without consideration of the index pulse and with limitation of movement by the negative limit switch	
	31	Reserved	
	...		
	34		
	35	The actual position of the drive is set directly as the zero point.	

P059	6099 Ref. Pt. for speed		S
<b>Arrays</b>	[-01] =	6099 Ref. Pt. for speed [1]	[-02] = 6099 Ref. Pt. for speed [2]
<b>Setting range</b>	[-01] =	0 ... 24000 rpm	[-02] = 0 ... 24000 rpm
<b>PDO mapping</b>	[-01] =	No	[-02] = No
<b>Data type</b>	[-01] =	UNSIGNED 32 Bit	[-02] = UNSIGNED 32 Bit
<b>Factory setting</b>	[-01] =	{ 30 }	[-02] = { 30 }
<b>Description</b>	[-01] =	DS402 object 6099h: Setpoint speed for reference run to the limit switch.	[-02] = DS402 object 6099h: Setpoint speed for reference run to the limit switch

P060	609A Homing accelera	S
<b>Setting range</b>	0 ... 2147483647 rpm/s	
<b>Factory setting</b>	{ 750 }	
<b>PDO mapping</b>	No	
<b>Data type</b>	UNSIGNED 32 Bit	
<b>Description</b>	DS402 object 609Ah: Acceleration and braking deceleration in "Homing" operating mode	

P061	607C Homing offset	S
<b>Setting range</b>	-2147483.648 ... 2147483.647 rev	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	No	
<b>Data type</b>	INTEGER 32 Bit	
<b>Description</b>	DS402 object 607Ch: States the difference between the zero position of the application and the reference point of the machine.	

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P062	606B & 606C & 6069 Velocity actual		!	S
<b>Display range</b>	-2147483.648 ... 2147483647 rpm			
<b>Arrays</b>	[-01] =	606B Velocity demand		
	[-02] =	606C Velocity actual		
	[-03] =	6069 Actual encoder speed.		
<b>Factory setting</b>	All	{ 0 }		
<b>PDO mapping</b>	[-01] =	No		
	[-02] =	TxPDO		
	[-03] =	No		
<b>Data type</b>	All	INTEGER 32 Bit		
<b>Description</b>	[-01] =	DS402 object 606Bh: Present actual speed in "Profile Velocity" operating mode.		
	[-02] =	DS402 object 606Ch: Actual speed after the ramp function in "Profile Velocity" operating mode.		
	[-03] =	DS402 object 6069h: Actual encoder speed in "Profile Velocity" operating mode.		



<b>P063</b>		<b>606D &amp; 606E Velocity window</b>		<b>!</b>	<b>S</b>
<b>Setting range</b>	[-01] = 0 ... 24000 rpm	[-02] = 0 ... 32767 ms			
<b>Arrays</b>	[-01] = 606D Velocity window	[-02] = 606E Veloc wind time			
<b>Factory setting</b>	[-01] = { 100 }	[-02] = { 200 }			
<b>PDO mapping</b>	[-01] = No	[-02] = No			
<b>Data type</b>	[-01] = UNSIGNED 16 Bit	[-02] = UNSIGNED 16 Bit			
<b>Description</b>	[-01] =	DS402 object 606Dh: Permissible deviation of the actual speed relative to the target speed in which the speed is considered to have been reached. Applies for "Profile Velocity" mode.			
	[-02] =	DS402 object 6068h: Dwell time in the target window so that the target velocity is considered to have been reached. Applies for "Profile Velocity" mode.			
<b>Description</b>	Sets target window for velocity and time				
<b>P064</b>		<b>606F &amp; 6070 Velocity thresh</b>		<b>!</b>	<b>S</b>
<b>Arrays</b>	[-01] = 606F Velocity thresh	[-02] = 6070 Veloc thre time			
<b>Setting range</b>	[-01] = 0 ... 24000 rpm	[-02] = 0 ... 32767 ms			
<b>Factory setting</b>	[-01] = { 100 }	[-02] = { 200 }			
<b>PDO mapping</b>	[-01] = No	[-02] = No			
<b>Data type</b>	[-01] = UNSIGNED 16 Bit	[-02] = UNSIGNED 16 Bit			
<b>Description</b>	[-01] =	DS402 object 606Fh: Permissible deviation of the actual velocity relative to velocity zero. If the drive undershoots this threshold value beyond the dwell time, Bit 12 of the status word is set. Applies for "Profile Velocity" operating mode.			
	[-02] =	DS402 object 6070h: Dwell time below the threshold value until Bit 12 "Drive stopped" is set. Applies for "Profile Velocity" mode.			
<b>P065</b>		<b>6083 Prof accelerat</b>			<b>S</b>
<b>Setting range</b>	0... 2147483647 rpm/s				
<b>Factory setting</b>	{ 750 }				
<b>PDO mapping</b>	RxPDO				
<b>Data type</b>	UNSIGNED 32 Bit				
<b>Description</b>	DS402 object 6083h: Acceleration in "Profile Position" and "Profile Velocity" modes.				
<b>P066</b>		<b>6084 Prof decelerat</b>			<b>S</b>
<b>Setting range</b>	0... 2147483647 rpm/s				
<b>Factory setting</b>	{ 750 }				
<b>PDO mapping</b>	RyPDO				
<b>Data type</b>	UNSIGNED 32 Bit				
<b>Description</b>	DS402 object 6084h: Deceleration in "Profile Position" and "Profile Velocity" modes.				
<b>P067</b>		<b>6085 qStop decelerat</b>			<b>S</b>
<b>Setting range</b>	0... 2147483647 rpm/s				
<b>Factory setting</b>	{ 15000 }				
<b>PDO mapping</b>	RxPDO				
<b>Data type</b>	UNSIGNED 32 Bit				
<b>Description</b>	DS402 object 6085h: Quick stop deceleration in "Profile Position" and "Profile Velocity" modes.				

<b>P072</b>	<b>60FF Target Velocity</b>	<b>S</b>
<b>Setting range</b>	-24000... 24000 rpm	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	RxPDO	
<b>Data type</b>	INTEGER 32 Bit	
<b>Description</b>	DS402 object 60FFh: Target speed in "Profile Velocity" operating mode.	
<b>P073</b>	<b>6077 Torque act val</b>	<b>S</b>
<b>Display range</b>	-400... 400 %	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	TyPDO	
<b>Data type</b>	INTEGER 16 Bit	
<b>Description</b>	DS402 object 6077h: Actual torque as percentage of rated torque in "Profile Torque" mode.	
<b>P074</b>	<b>6078 Current act val</b>	<b>S</b>
<b>Display range</b>	-300... 300 %	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	TxPDO	
<b>Data type</b>	INTEGER 16 Bit	
<b>Description</b>	DS402 object 6078h: Actual current as percentage of the rated current in "Profile Torque" mode.	
<b>P075</b>	<b>6079 DC link cir vol</b>	<b>S</b>
<b>Display range</b>	0... 1200 V	
<b>Factory setting</b>	{ 0 }	
<b>PDO mapping</b>	No	
<b>Data type</b>	UNSIGNED 32 Bit	
<b>Description</b>	DS402 object 6079h: Actual link circuit voltage	
<b>P076</b>	<b>6087 Torque ramp</b>	<b>S</b>
<b>Setting range</b>	0... 1000000 %/s	
<b>Factory setting</b>	{ 10000 }	
<b>PDO mapping</b>	No	
<b>Data type</b>	UNSIGNED 32 Bit	
<b>Description</b>	DS402 object 6087h: Sets the torque ramp	


**5.1.3 Basic parameter**

<b>P100</b>	<b>Parameter set</b>	<b>S</b>
<b>Setting range</b>	0 ... 3	
<b>Factory setting</b>	{ 0 }	
<b>Description</b>	<p>Selection of the parameters sets to be parameterised. Four parameter sets are available. The parameters to which different values can also be assigned in the four parameter sets are known as “parameter set-dependent” and are indicated with a “P” in the header in the following descriptions.</p> <p>The operating parameter set is selected via correspondingly parametrised digital inputs or BUS actuation.</p> <p>If enabling is via the keyboard of a ParameterBox, the operating parameter set corresponds to the settings in <b>P100</b>.</p>	

<b>P101</b>	<b>Copy parameter set</b>	<b>S</b>																								
<b>Setting range</b>	0 ... 4																									
<b>Factory setting</b>	{ 0 }																									
<b>Description</b>	<p>“Copy parameter set”. By confirmation with the OK key, the active parameter set (set in <b>P100</b>) is copied into the selected parameter set.</p>																									
<b>Setting values</b>	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Do not copy</td> </tr> <tr> <td>1</td> <td>Copy actual to P1</td> </tr> <tr> <td>2</td> <td>Copy actual to P2</td> </tr> <tr> <td>3</td> <td>Copy actual to P3</td> </tr> <tr> <td>4</td> <td>Copy actual to P4</td> </tr> </tbody> </table>	Value	Meaning	0	Do not copy	1	Copy actual to P1	2	Copy actual to P2	3	Copy actual to P3	4	Copy actual to P4	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No copy process triggered.</td> </tr> <tr> <td>1</td> <td>Copies the active parameter set to parameter set 1</td> </tr> <tr> <td>2</td> <td>Copies the active parameter set to parameter set 2</td> </tr> <tr> <td>3</td> <td>Copies the active parameter set to parameter set 3</td> </tr> <tr> <td>4</td> <td>Copies the active parameter set to parameter set 4</td> </tr> </tbody> </table>	Value	Meaning	0	No copy process triggered.	1	Copies the active parameter set to parameter set 1	2	Copies the active parameter set to parameter set 2	3	Copies the active parameter set to parameter set 3	4	Copies the active parameter set to parameter set 4
Value	Meaning																									
0	Do not copy																									
1	Copy actual to P1																									
2	Copy actual to P2																									
3	Copy actual to P3																									
4	Copy actual to P4																									
Value	Meaning																									
0	No copy process triggered.																									
1	Copies the active parameter set to parameter set 1																									
2	Copies the active parameter set to parameter set 2																									
3	Copies the active parameter set to parameter set 3																									
4	Copies the active parameter set to parameter set 4																									

<b>P102</b>	<b>Acceleration time</b>	<b>P</b>
<b>Setting range</b>	0.00 ... 320.00 s	
<b>Factory setting</b>	{ 2.00 }	
<b>Description</b>	<p>The acceleration time is the time which corresponds to the linear frequency increase from 0 Hz to the set maximum frequency <b>P105</b>. If an actual setpoint of &lt;100 % is being used, the acceleration time is reduced linearly according to the setpoint which has been set.</p> <p>The acceleration time can be extended by certain circumstances, e.g. FI overload, setpoint delay, ramp smoothing, or if the current limit is reached.</p>	
<b>Note</b>	<p>Care must be taken that the parameter values are realistic. The setting <b>P102 = 0</b> is not permissible for drive units!</p> <p><b>Ramp gradient:</b></p> <p>Amongst other things, the ramp gradient is governed by the inertia of the rotor. A ramp with a gradient which is too steep may result in “breakdown” of the motor.</p> <p>Extremely steep ramps (e.g.: 0 – 50 Hz in &lt; 0.1 s) should be avoided, as this may cause damage to the frequency inverter.</p>	

<b>P103</b>	<b>Deceleration time</b>		<b>P</b>
<b>Setting range</b>	0.00 ... 320.00 s		
<b>Factory setting</b>	{ 2.00 }		
<b>Description</b>	<p>The deceleration time is the time corresponding to the linear frequency reduction from the set maximum frequency <b>P105</b> to 0 Hz. If an actual setpoint &lt;100 % is being used, the deceleration time reduces accordingly.</p> <p>The deceleration time can be extended by certain circumstances, e.g. by the selected "Disconnection mode" <b>P108</b> or "Ramp smoothing" <b>P106</b>.</p>		
<b>Note</b>	<p>Care must be taken that the parameter values are realistic. The setting <b>P103 = 0</b> is not permissible for the drive units!</p> <p><b>Notes on ramp gradient:</b> see <b>P102</b></p>		
<b>P104</b>	<b>Minimum frequency</b>		<b>P</b>
<b>Setting range</b>	0.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	<p>The minimum frequency is the frequency supplied by the FI as soon as it is enabled and no additional setpoint is set.</p> <p>In combination with other setpoints (e.g. analogue setpoint or fixed frequencies) these are added to the set minimum frequency.</p> <p>This frequency is undershot when</p> <ul style="list-style-type: none"> <li>• The drive is accelerated from standstill.</li> <li>• The FI is blocked. The frequency then reduces to the absolute minimum frequency <b>P505</b> before it is blocked.</li> <li>• The FI reverses. Reversal of the rotation field takes place at the absolute minimum frequency <b>P505</b>.</li> </ul> <p>This frequency can be continuously undershot if the function "Maintain the freq." (digital input function = 9) was executed during acceleration or deceleration.</p>		
<b>P105</b>	<b>Maximum frequency</b>		<b>P</b>
<b>Setting range</b>	0.1 ... 400.0 Hz		
<b>Factory setting</b>	{ 50.0 }		
<b>Description</b>	<p>The maximum frequency is the frequency supplied by the FI after being enabled and once the maximum setpoint is present (e. g. analogue setpoint according to <b>P403</b>, a correspondingly fixed frequency or maximum via a ParameterBox).</p> <p>This frequency can only be exceeded by the slip compensation <b>P212</b>, the function "Maintain the freq." (Digit inputs function = 9) or the switch to another parameter set with lower maximum frequency.</p> <p>Maximum frequencies are subject to certain restrictions, e. g.</p> <ul style="list-style-type: none"> <li>• Restrictions in weak field operation,</li> <li>• Compliance with mechanically permissible speeds,</li> <li>• PMSM: Restriction of the maximum frequency to a value which is slightly above the nominal frequency. This value is calculated from the motor data and the input voltage.</li> </ul>		

P106	Ramp smoothing	S	P
<b>Setting range</b>	0 ... 100 %		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	<p>This parameter enables smoothing of the acceleration and deceleration ramps. This is necessary for applications where gentle, but dynamic speed change is important. Ramp smoothing is carried out for every setpoint change.</p> <p>The value to be set is based on the set acceleration and deceleration time, however values &lt;10 % have no effect.</p> <p>The following then applies for the entire acceleration or deceleration time, including ramp smoothing:</p> $t_{ges \text{ ACCELERATION TIME}} = t_{P102} + t_{P102} \cdot \frac{P106[\%]}{100\%}$ $t_{ges \text{ BRAKING TIME}} = t_{P103} + t_{P103} \cdot \frac{P106[\%]}{100\%}$ 		

P107	Brake reaction time	P
<b>Setting range</b>	0 ... 2.50 s	
<b>Factory setting</b>	{ 0.00 }	
<b>Description</b>	<p>Electromagnetic brakes have a physically-dependent delayed Brake reaction time when actuated. This can result in the dropping of the load in lifting equipment applications. The brake takes up the load after a delay.</p> <p>The reaction time must be taken into consideration by setting parameter <b>P107</b>. Within the adjustable reaction time, the FI supplies the set absolute minimum frequency <b>P505</b> and so prevents movement against the brake and load drop when stopping.</p> <p>If a time &gt; 0 is set in <b>P107</b> or <b>P114</b>, at the moment the FI is switched on, the level of the excitation current (field current) is checked. If no excitation current is present, the FI remains in excitation mode and the motor brake is not released.</p>	
<b>Note</b>	<p>In order to achieve a shutdown and an error message <b>E016</b> in case of a too low excitation current, <b>P539</b> must be set to {2} or {3}.</p> <p>For control of an electromagnetic brake (especially for lifting equipment) an internal relay should be used (<b>P434 [-01]</b> or <b>[-02]</b>, function {1}, "External brake"). The absolute minimum frequency (<b>P505</b>) should never be less than 2.0 Hz.</p>	

**Recommendation for applications:**


Lifting equipment with brake, without speed feedback    Lifting equipment with brake

P114 = 0.02...0.4 s \*  
P107 = 0.02...0.4 s \*  
P201...P208 = Motor data  
P434 = 1 (ext. brake)  
P505 = 2...4 Hz

for safe start-up  
P112 = 401 (off)  
P536 = 2.1 (off)  
P537 = 150 %  
P539 = 2/3 (I<sub>SD</sub> monitoring)

to prevent load drops  
P214 = 50...100 % (precontrol)

\* Settings (P107/114) depending on brake type and motor size. At low power levels (< 1.5 kW) lower values apply for higher power ratings (> 4.0 kW) are larger values.



P108	Switch-off mode		S	P
Setting range	0 ... 13			
Factory setting	{ 1 }			
Description	This parameter determines the way in which the output frequency is reduced after "Blocking" (controller enable → Low).			
Setting values	Value	Meaning		
	0	Voltage disable	The output signal is switched off immediately. The FI no longer supplies an output frequency. The motor is only braked by mechanical friction. Switching the FI on again immediately can cause an error message.	
	1	Ramp down	The actual output frequency is reduced in proportion to the remaining deceleration time from <b>P103/P105</b> . The DC run-on <b>P559</b> follows the end of the ramp.	
	2	Delayed ramping	As with {1} "Ramp", however, for generational operation the brake ramp is extended, or for static operation the output frequency is increased. Under certain conditions, this function can prevent overvoltage switch-off or reduce braking resistor power dissipation. <b>Note:</b> This function must not be programmed if defined deceleration is required, e.g. for lifting equipment.	
	3	Immediate DC braking	The FI switches immediately to the preselected DC current <b>P109</b> . This DC current is supplied for the remaining proportion of the "DC brake time" <b>P110</b> . Depending on the relationship of the actual output frequency to the max. frequency <b>P105</b> , the "DC brake time" is shortened. The time taken for the motor to stop depends on the application. The time taken to stop depends on the inertia of the load, friction and the DC current which is set in <b>P109</b> . With this type of braking, no energy is fed back into the FI. Heat losses primarily occur in the rotor of the motor. <b>Note: This function is not suitable for PMSM motors</b>	
	4	Const. Braking distance	"Constant brake distance": Start of the brake ramp is delayed if operation is not at the maximum output frequency ( <b>P105</b> ). This results in an approximately similar braking distance for different actual frequencies. <b>Note:</b> This function cannot be used as a positioning function. This function should not be combined with ramp smoothing ( <b>P106</b> ).	
	5	Combined Braking	"Combined braking": Depending on the actual link circuit voltage (UZV), a high frequency voltage is switched to the basic frequency (only for linear characteristic curves <b>P211 = 0</b> and <b>P212 = 0</b> ). The braking time <b>P103</b> is complied with if possible. → Additional heating in the motor! <b>Note: This function is not suitable for PMSM motors</b>	
	6	Quadratic ramp	The brake ramp does not follow a linear path, but rather a decreasing quadratic one.	
	7	Quad. Ramp with Delay	"Quadratic ramp with delay": Combination of {2} and {6}.	
	8	Quad. comb. braking	"Quadratic combined braking": Combination of {5} and {6}. <b>Note: This function is not suitable for PMSM motors</b>	
	9	Const. Accel. Power	"Constant acceleration power": Only applies in field weakening range. The drive is accelerated or braked with constant electrical power. The shape of the ramps depends on the load.	
	10	Distance calculator	Constant distance between actual frequency / speed and the set minimum output frequency <b>P104</b> . as for "Const. braking distance". However, function [10] only becomes active if the setpoint frequency undershoots the set minimum frequency. In this case, enabling must be retained.	
	11	Const. Accel. Power with Delay	"Constant acceleration power with delay": Combination of {2} and {9}.	
	12	Const. accel. power Mode 3	"Constant acceleration power mode 3" as for {11}, however with additional relief of the brake chopper.	
	13	Switch-off delay	"Ramp with disconnection delay!" as for {1} "Ramp", however, before the brake is applied, the drive unit remains at the absolute minimum frequency set in parameter <b>P505</b> for the time specified in parameter <b>P110</b> . Application example: Re-positioning for crane control	

P109	DC brake current	S	P
<b>Setting range</b>	0 ... 250 %		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>Current setting for the functions of DC current braking (<b>P108 = 3</b>) and combined braking (<b>P108 = 5</b>).</p> <p>The correct setting value depends on the mechanical load and the required deceleration time. A higher setting brings large loads to a standstill more quickly. The 100 % setting corresponds to a current value as stored in the "Nominal motor current" parameter <b>P203</b>.</p>		
<b>Note</b>	<p>The DC current (0 Hz) which the FI can supply is limited. For this value, please refer to the table in Section "Reduced overcurrent due to output frequency", column: 0 Hz. In the basic setting this limiting value is 110 %.</p> <p><b>DC Braking: Not for PMSM motors!</b></p>		
P110	Time DC-brake on	S	P
<b>Setting range</b>	0.00 ... 60.00 s		
<b>Factory setting</b>	{ 2.00 }		
<b>Description</b>	<p>The time for which the DC current selected in <b>P109</b> is applied to the motor. For this, function {3} "Instant d.c. Braking" must be set in <b>P108</b>.</p> <p>Depending on the relationship of the actual output frequency to the max. frequency <b>P105</b>, the "DC brake time" is shortened.</p> <p>The time starts running with the removal of the enable and can be interrupted by renewed enabling.</p>		
<b>Note</b>	<p><b>DC Braking: Not for PMSM motors!</b></p>		



P111	P - torque limit factor		S	P
<b>Setting range</b>	25 ... 400 %			
<b>Factory setting</b>	{ 100 }			
<b>Description</b>	<p>"P torque limit factor". Directly affects the behaviour of the drive at the torque limit. The basic setting of 100 % is sufficient for most drive tasks.</p> <p>If the values are too high the drive tends to oscillate as it reaches the torque limit. If values are too low, the programmed torque limit can be exceeded.</p>			
P112	Torque current limit		S	P
<b>Setting range</b>	25 ... 400 % / 401			
<b>Factory setting</b>	{ 401 }			
<b>Description</b>	<p>With this parameter, a limit value for the torque-generating current can be set. This can prevent mechanical overloading of the drive. However, it cannot provide protection against mechanical blockages. A slipping clutch which acts as a safety device must be provided.</p> <p>The torque current limit can also be set over a continuous range of settings using an analogue input. The maximum setpoint (cf. adjustment 100%, <b>P403/P408</b>) then corresponds to the setting value in <b>P112</b>.</p> <p>The limit value 20% of torque current cannot be undershot by a smaller analogue setpoint (<b>P400 = 2</b>). In contrast, with the control method "CFC closed-loop" (Servo Mode) <b>P300</b> setting "1", a limit value of 0% is possible.</p>			
<b>Note</b>	A torque limit is not permissible for lifting equipment applications!			
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>		
	401	OFF	The torque current is not limited.	
P113	Jog frequency		S	P
<b>Setting range</b>	-400.0 ... 400.0			
<b>Factory setting</b>	{ 0.0 }			
<b>Description</b>	<p>When using the ParameterBox to control the FI, the jog frequency is the starting value after enabling.</p> <p>Alternatively, if control is via the control terminals, the jog frequency can be activated via one of the digital inputs.</p> <p>Setting of the jog frequency can be performed directly via this parameter or, if the FI is enabled via the keyboard, by pressing the OK key. In this case, the actual output frequency is applied to parameter <b>P113</b> and is then available for the next start.</p>			
<b>Note</b>	<p>Activation of the jog frequency via one of the digital inputs causes the remote control to be switched off in case of bus operation. In addition, any set point frequencies which are present are not taken into account.</p> <p>Exception: Analogue setpoints which are processed via the functions "Frequency addition" or "Frequency subtract."</p>			

P114	Brake delay off	S	P
<b>Setting range</b>	0.00 ... 2.50 s		
<b>Factory setting</b>	{ 0.00 }		
<b>Description</b>	<p>Electromagnetic brakes have a delayed reaction time for their release, which depends on physical factors. This can lead to the motor running while the brake is still applied, which will cause the inverter to switch off with an overcurrent message.</p> <p>This release time can be taken into consideration by the parameter P114 (braking control).</p> <p>During the adjustable release time <b>P114</b>, the FI supplies the set absolute minimum frequency <b>P505</b> and thus prevents movement against the brake.</p> <p>See also parameter <b>P107</b> "Brake reaction time" (setting example).</p>		
<b>Note</b>	If <b>P114</b> is set to {0}, then <b>P107</b> is the brake release and reaction time.		

P120	Option monitoring	S	P
<b>Setting range</b>	0 ... 2		
<b>Arrays</b>	[-01] = Bus TB (Ext. 1)      [-03] = 1st IOE (Ext. 3) [-02] = 2nd IOE (Ext. 2)		
<b>Factory setting</b>	{ 1 }		
<b>Scope of application</b>	<b>SK 530P, SK 550P</b>		
<b>Description</b>	Monitoring of communication at system bus level (in case of fault: Error message <b>E10.9</b> )		
<b>Note</b>	If fault messages which are detected by the optional module (e.g. faults at field bus level) are not to result in shut-down of the drive electronics, parameter <b>P513</b> must also be set to the value {-0.1}.		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	Monitoring OFF	
	1	Auto Communication is only monitored if an existing communication is interrupted. If a module which was previously present is not found after switching on the mains, this does not result in an error. Monitoring only becomes active if an extension starts communication with the FI.	
	2	Monitoring active immediately " <i>Monitoring active immediately</i> "; the FI starts to monitor the corresponding module immediately after it is switched on. If the module is not detected on switch-on, the FI remains in the status "not ready for switch-on" for 5 seconds and then triggers an error message.	

**5.1.4 Motor data / characteristic curve parameters**

P200	Motor list				P	
<b>Setting range</b>	0 ... 148					
<b>Factory setting</b>	{ 0 }					
<b>Description</b>	<p>The factory settings for the motor data can be edited with this parameter. A 4-pole IE3 asynchronous standard motor is set at the factory in parameters <b>P201 ... P209</b> to match the rated power of the FI.</p> <p>By selecting one of the possible setting values and pressing the OK key, all of the motor parameters <b>P201 ... P209</b> are set to the selected motor power. The motor data for NORD synchronous motors can be found in the final section of the list.</p>					
<b>Note</b>	<p>After confirmation of the selection, {0} is displayed again in <b>P200</b>. The selection which has been made can be checked via <b>P205</b>.</p> <p><b>IE1 / IE2motors</b>            If IE1 / IE2 motors are used after selecting a IE3 motor, the motor data in <b>P201 ... P209</b> must be matched to the data on the motor type plate.</p>					
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>				
	0	No change				
	1	No motor In this setting, the FI operates without current control, slip compensation and pre-magnetising time, and is therefore not recommended for operating a motor. The following motor data is set here: 50.0 Hz / 1500 rpm / 15.0 A / 400 V / 0.00 kW / cos $\varphi=0.90$ / Star / R <sub>s</sub> 0.01 $\Omega$ / I <sub>LEER</sub> 6.5 A				
	2	0.25 kW 230V 71SP	10	0.55 kW 230V 80SP	18	1.1 kW 230 V 90SP
	3	0.33 PS 230 V 71SP	11	0.75 PS 230 V 80SP	19	1.5 PS 230 V 90SP
	4	0.25 kW 400 V 71SP	12	0.55 kW 400V 80SP	20	1.1 kW 400 V 90SP
	5	0.33 PS 460 V 71SP	13	0.75 PS 460 V 80SP	21	1.5 PS 460 V 90SP
	6	0.37 kW 230V 71LP	14	0.75 kW 230V 80LP	22	1.5 kW 230 V 90LP
	7	0.5 PS 230 V 71LP	15	1.0 PS 230 V 80LP	23	2.0 PS 230 V 90LP
	8	0.37 kW 400V 71LP	16	0.75 kW 400V 80LP	24	1.5 kW 400 V 90LP
	9	0.5 PS 460 V 71LP	17	1.0 PS 460 V 80LP	25	2.0 PS 460 V 90LP
	26	2.2 kW 230V 100MP	36	5.5 kW 230 V 132SP	46	15.0 kW 400V 160LP
	27	3.0 PS 230 V 100LP	37	7.5 PS 230 V 132SP	47	20.0 PS 460 V 160LP
	28	2.2 kW 400V 100MP	38	5.5 kW 400 V 132SP	48	18.5 kW 400V 180MP
	29	3.0 PS 460 V100LP	39	7.5 PS 460 V 132SP	49	25.0 PS 460 V 180MP
	30	3.0 kW 230V 100AP	40	7.5 kW 230 V 132MP	50	22.0 kW 400V 180LP
	31	3.0 kW 400 V 100 AP	41	10.0 PS 230 V 132MP	51	30.0 PS 460 V 180LP
	32	4.0 kW 230V 112MP	42	7.5 kW 400 V 132MP	52	30.0 kW 400 V 225RP
	33	5.0 PS 230 V 112MP	43	10.0 PS 460 V 132MP	53	40.0 PS 460 V 225RP
	34	4.0 kW 400V 112MP	44	11.0 kW 400V 160MP	54	37.0 kW 400 V 225SP
	35	5.0 PS 460 V 112MP	45	15.0 PS 460 V 160MP	55	50.0PS 460V
	56	45.0 kW 400 V 225MP	66	132.0 kW 400V 315MP	76	15.0 kW 230V 160LP
	57	60.0 PS 460 V 225SP	67	180.0 PS 460 V 315MP	77	20.0 PS 230 V 160LP
	58	55.0 kW 400 V 250WP	68	160.0 kW 400V 315RP	78	18.5 kW 230V 180MP
	59	75.0 PS 460 V 250WP	69	220.0 PS 460 V 315RP	79	25.0 PS 230 V 180MP
	60	75.0 kW 400 V 280SP	70	200.0kW 400V	80	22.0 kW 230V 180LP
	61	100.0 PS 460 V 280SP	71	270.0PS 460V	81	30.0 PS 230 V 180LP
	62	90.0 kW 400 V 280MP	72	250.0kW 400V	82	30.0 kW 230V 225RP
	63	120.0 PS 460 V 280MP	73	340.0PS 460V	83	40.0 PS 230 V 225RP
	64	110.0 kW 400V 315SP	74	11.0 kW 230V 160MP	84	37.0 kW 230V 225SP
	65	150.0 PS 460 V 315SP	75	15.0 PS 230 V 160MP	85	50.0PS 230V

86	0.12kW 115V	96	1.10 kW 230 V 90T1/4	106	2.20 kW 400 V 90T1/4
87	0.18kW 115V	97	1.10 kW 230 V 80T1/4	107	3.00 kW 230 V 100T5/4
88	0.25kW 115V	98	1.10 kW 400 V 80T1/4	108	3.00 kW 230 V 100T2/4
89	0.37kW 115V	99	1.50 kW 230 V 90T3/4	109	3.00 kW 400 V 100T2/4
90	0.55kW 115V	100	1.50 kW 230 V 90T1/4	110	3.00 kW 400 V 90T3/4
91	0.75kW 115V	101	1.50 kW 400 V 90T1/4	111	4.00 kW 230 V 100T5/4
92	1.1kW 115V	102	1.50 kW 400 V 80T1/4	112	4.00 kW 400 V 100T5/4
93	4.0PS 230V	103	2.20 kW 230 V 100T2/4	113	4.00 kW 400 V 100T2/4
94	4.0PS 460V	104	2.20 kW 230 V 90T3/4	114	5.50 kW 400 V 100T5/4
95	0.75 kW 230 V 80T1/4	105	2.20 kW 400 V 90T3/4	117	0.35 kW 400 V 71N1/8
119	0.70 kW 400 V 71x2/8	126	2.20 kW 400 V 90F3/8	141	1.50 kW 230 V 90N2/8
120	1.05 kW 400 V 71x3/8	127	3.00 kW 400 V 90F4/8	142	1.50 kW 230 V 90F2/8
121	1.10 kW 400 V 90N1/8	130	4.00 kW 400 V 90F5/8	143	2.20 kW 230 V 90N3/8
122	1.50 kW 400 V 71F4/8	135	0.35 kW 230 V 71N1/8		
123	1.50 kW 400 V 90N2/8	137	0.70 kW 230 V 71N2/8		
124	1.50 kW 400 V 90F2/8	138	1.05 kW 230 V 71N3/8		
125	2.20 kW 400 V 90N3/8	139	1.10 kW 230 V 90N1/8		

P201	Nominal frequency	S	P
Setting range	10.0 ... 399.9 Hz		
Factory setting	The default setting depends on the nominal power of the FI.		
Description	The nominal motor frequency determines the V/f break point at which the FI supplies the nominal voltage ( <b>P204</b> ) at the output.		

P202	Nominal speed	S	P
Setting range	100 ... 24000 rpm		
Factory setting	The default setting depends on the nominal power of the FI.		
Description	The nominal motor speed is important for correct calculation and control of the motor slip and the speed display ( <b>P001 = 1</b> ).		

P203	Nominal current	S	P
Setting range	0.1 ... 1000.0 A		
Factory setting	The default setting depends on the nominal power of the FI.		
Description	The nominal motor current is a decisive parameter for current vector control.		

P204	Nominal voltage	S	P
Setting range	100 ... 800 V		
Factory setting	The default setting depends on the nominal power of the FI.		
Description	This parameter sets the nominal voltage. In combination with the nominal frequency, the voltage/frequency characteristic curve is produced.		

<b>P205</b>	<b>Nominal power</b>		<b>P</b>
<b>Setting range</b>	0.00 ... 250.00 kW		
<b>Factory setting</b>	The default setting depends on the nominal power of the FI.		
<b>Description</b>	Displays the nominal motor power		
<b>P206</b>	<b>Cos phi</b>		<b>S P</b>
<b>Setting range</b>	0.50 ... 0.98		
<b>Factory setting</b>	The default setting depends on the nominal power of the FI.		
<b>Description</b>	The motor $\cos \varphi$ is a decisive parameter for current vector control.		
<b>P207</b>	<b>Motor circuit</b>		<b>S P</b>
<b>Setting range</b>	0... 1		
<b>Factory setting</b>	The default setting depends on the nominal power of the FI.		
<b>Description</b>	The motor circuit is decisive for stator resistance measurement ( <b>P220</b> ) and therefore for current vector control.		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	Star	
	1	Delta	
<b>P208</b>	<b>Stator resistance</b>		<b>S P</b>
<b>Setting range</b>	0.00 ... 300.00 $\Omega$		
<b>Factory setting</b>	The default setting depends on the nominal power of the FI.		
<b>Description</b>	<p>Motor stator resistance → Resistance of a phase winding with a three-phase motor. The stator resistance has a direct influence on the current control of the FI. A value which is too high may result in overcurrent; a value which is too low may result in low motor torque.</p> <p>The result of the stator resistance measurement (see <b>P220</b>) is shown in <b>P208</b>. However, this value can also be overwritten there.</p>		
<b>Note</b>	For optimum functioning of the current vector control, the stator resistance must be measured automatically by the FI.		

<b>P209</b>		<b>No-load current</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 1000.0 A				
<b>Factory setting</b>	The default setting depends on the nominal power of the FI.				
<b>Description</b>	This value is always calculated automatically from the motor data if there is a change in the parameter <b>P206</b> "Cos φ" and <b>P203</b> "Nominal current".				
<b>Note</b>	If the value is to be entered directly, then it must be set as the last value of the motor data. This is the only way to ensure that the value will not be overwritten.				
<b>P210</b>		<b>Static boost</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 400 %				
<b>Factory setting</b>	{ 100 }				
<b>Description</b>	ASM	The static boost affects the current which generates the magnetic field. This corresponds to the no-load current of the respective motor and therefore does not depend on the load. The no-load current is calculated using the motor data. The factory setting is sufficient for typical applications.			
	PMSM	For permanent magnet synchronous motors (PMSM) the level of the current which is used for identification can be modified as a percentage. The duration of the dwell process can be set via <b>P558</b> .			
<b>P211</b>		<b>Dynamic boost</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 150 %				
<b>Factory setting</b>	{ 100 }				
<b>Description</b>	Dynamic boost affects the torque-generating current and is therefore a load-dependent parameter. Here too, the factory setting is sufficient for typical applications. A value which is too high can result in overcurrent in the FI. Under load, the output current is increased too much. A value which is too low will result in insufficient torque.				
<b>Note</b>	In particular, applications with large inertial masses (e.g. fan operation) may require control according to a V/f characteristic curve. For this, parameters <b>P211</b> and <b>P212</b> must each be set to 0%.				


P212	Slip compensation	S	P
Setting range	0 ... 150 %		
Factory setting	{ 100 }		
Description	<p>Slip compensation increases the output frequency depending on the load, in order to keep the three-phase asynchronous motor speed approximately constant.</p> <p>The factory setting of 100% is optimal for three-phase asynchronous motors if the correct motor data has been set.</p> <p>If several motors (different loads or outputs) are operated with a single FI, the slip compensation <b>P212 = 0%</b> must be set. This also applies to synchronous motors which do not have slip due to their design.</p>		
Note	In particular, applications with large inertial masses (e.g. fan operation) may require control according to a V/f characteristic curve. For this, parameters <b>P211</b> and <b>P212</b> must each be set to 0%.		
Note	When controlling a PMSM, this parameter determines the voltage of the test signal principal ( <b>P330</b> ). The required voltage depends on various factors (ambient and motor temperature, motor size, motor cable length, size of frequency inverter and others). If the rotor position identification is not successful, this parameter can be used to adjust the voltage.		
P213	Amplification ISD control	S	P
Setting range	25 ... 400 %		
Factory setting	{ 100 }		
Description	<p>"<i>ISD control amplification</i>". This parameter influences the control dynamics of the FI current vector control (ISD control). Higher settings make the controller faster, lower settings slower.</p> <p>Dependent on the type of application this parameter can be adjusted, e.g. to avoid unstable operation.</p>		
P214	Torque precontrol	S	P
Setting range	-200 ... 200 %		
Factory setting	{ 0 }		
Description	This function allows a value for the expected torque requirement to be set in the current controller. This function can be used in lifting applications for better load take-up during starting.		
Note	Motor torques with "right" rotation field are entered with a positive sign, generator torques are entered with a negative sign. The reverse applies for the "left" rotation field.		
P215	Boost precontrol	S	P
Setting range	0 ... 200 %		
Factory setting	{ 0 }		
Description	<p>Only advisable with linear characteristic curve (<b>P211 = 0 %</b> and <b>P212 = 0 %</b>).</p> <p>For drives which require a high starting torque, this parameter provides an option for switching in an additional current during the start phase. The application time is limited and can be selected in parameter "Boost precontrol"<b>P216</b>.</p> <p>All current and torque current limits that may have been set <b>P112</b>, <b>P536</b>, <b>P537</b> are deactivated during the boost precontrol.</p>		
Note	With active ISD control ( <b>P211</b> and / or <b>P212 ≠ 0 %</b> ), parameterisation of <b>P215 ≠ 0</b> results in incorrect control.		

<b>P216</b>	<b>Time boost prectrl.</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 10.0 s		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	<p>This parameter is used for 3 functionalities:</p> <ol style="list-style-type: none"> <li>1. Time limit for the boost precontrol: Application time for the increased starting current. Only with linear characteristic curve (<b>P211 = 0%</b> and <b>P212 = 0%</b>).</li> <li>2. Time limit for suppression of pulse disconnection <b>P537</b>: enables start-up under heavy load.</li> <li>3. Time limit for suppression of switch-off on error in parameter <b>P401</b>, setting { 05 } "0 ... 100 % with switch-off on error 2"</li> </ol>		
<b>P217</b>	<b>Oscillation damping</b>	<b>S</b>	
<b>Setting range</b>	0... 400 %		
<b>Factory setting</b>	{ 10 }		
<b>Description</b>	<p>Parameter is a measure of the damping power. Oscillations caused by resonance under no-load conditions can be suppressed with oscillation damping.</p> <p>For oscillation damping the oscillation component is filtered out of the torque current by means of a high pass filter. This is amplified by <b>P217</b>, inverted and switched to the output frequency.</p> <p>The limit for the value switched is also proportional to <b>P217</b>. The time constant for the high pass filter depends on <b>P213</b>. For higher values of <b>P213</b> the time constant is lower.</p> <p>With a set value of 10% for <b>P217</b>, a maximum of <math>\pm 0.045</math> Hz are switched in. At 400% in <b>P217</b>, this corresponds to <math>\pm 1.8</math> Hz</p>		
<b>Note</b>	This function is not active in control mode "CFC closed-loop" (Servo Mode) <b>P300= 1</b> ,		
<b>P218</b>	<b>Modulation depth</b>	<b>S</b>	
<b>Setting range</b>	50 ... 110 %		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>This setting influences the maximum possible output voltage of the FI in relation to the mains voltage. Values &lt;100% reduce the voltage to values which are less than the mains voltage. Values &gt;100 % increase the output voltage to the motor. resulting in increased harmonics in the current, which may cause "hunting", i.e. fluctuating speed in some motors.</p> <p>The parameter should normally be set to 100%.</p>		



<b>P219</b>	<b>Auto. flux adjustment</b>		<b>S</b>
<b>Setting range</b>	25 ... 100 % / 101		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>"Automatic magn. adjustment". With this parameter, the magnetic flux of the motor can be automatically matched to the motor load, so that the energy consumption is reduced to the amount which is actually required. <b>P219</b> is the limiting value, to which the field in the motor can be reduced.</p> <p>Reduction of the field is performed with a time constant of 7.5 s. If the load increases, the field is increased with a time constant of approx. 300 ms. The field is reduced so that the magnetisation current and the torque current are approximately equal, i.e. the motor is operated with "optimum efficiency".</p> <p>This function is suitable for applications with relatively constant torque (e.g. pump and fan applications). Its effect therefore replaces a quadratic curve, as it adapts the voltage to the load.</p>		
<b>Note</b>	<p>For applications with rapid torque fluctuations (e.g. lifting equipment) this parameter should be left at the factory setting (100%). Otherwise, rapid load changes could cause shut-down due to overcurrent or "breakdown".</p> <p>This parameter does not function with synchronous motors (IE4 motors).</p>		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	100	Function disabled	
	101	Automatic	Activation of automatic excitation current control. The ISD controller then operates with a subordinate flux controller, which improves the slippage calculation, especially at higher loads. The control times are considerably faster than with normal ISD control <b>P219 = 100</b> .

**P2xx Control/characteristic curve parameters**



**NOTE:**  
"typical"

Settings for the...

**Current vector control (factory setting)**

- P201 to P209 = Motor data
- P210 = 100%
- P211 = 100%
- P212 = 100%
- P213 = 100%
- P214 = 0%
- P215 = no significance
- P216 = no significance

**Linear V/f characteristic curve**


- P201 to P209 = Motor data
- P210 = 100% (static boost)
- P211 = 0%
- P212 = 0%
- P213 = no significance
- P214 = no significance
- P215 = 0% (boost precontrol)
- P216 = 0s (time dyn. boost)

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P220	Par.-identification		P
<b>Setting range</b>	0 ... 2		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	<p><i>"Parameter identification"</i>. For devices with an output up to 5.5 KW (230 V ≤ 2.2 kW), the motor data is determined automatically by the device via this parameter. Do not switch off the mains voltage during the parameter's identification.</p> <p>Better drive behaviour is often achieved with measured motor data. If there is unfavourable operating behaviour after identification, set the parameters <b>P201... P208</b> manually.</p>		
<b>Note</b>	<ul style="list-style-type: none"> <li>• Before starting parameter identification, check the following motor data according to the name plate: <ul style="list-style-type: none"> <li>– Nominal frequency <b>P201</b></li> <li>– Nominal speed <b>P202</b></li> <li>– Voltage <b>P204</b></li> <li>– Power <b>P205</b></li> <li>– Star Delta con. <b>P207</b></li> </ul> </li> <li>• Parameter identification should only be carried out when the motor is cold (15 ... 25 °C). Warming of the motor during operation is taken into account.</li> <li>• The FI must be in "Ready for operation" condition For bus operation, the bus must be operating without error.</li> <li>• The motor power may only be one power level greater or three power levels lower than the nominal power of the FI.</li> <li>• A maximum motor cable length of 20 m must be complied with for reliable identification.</li> <li>• Take care that the connection to the motor is not interrupted during the measuring process.</li> <li>• If the identification cannot be completed successfully, error message <b>E019</b> is generated.</li> <li>• After parameter identification, <b>P220</b> is = 0 again.</li> <li>• When using synchronous motors, the parameters P241, P243, P244 and P246 must be set up additionally.</li> </ul>		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	No identification	
	1	R <sub>s</sub> identification The stator resistance (display in <b>P208</b> ) is determined by multiple measurements.	
	2	Motor identification This function can only be used with devices up to 5.5 KW (230 V ≤ 2.2 kW). <b>ASM:</b> All motor parameters ( <b>P202, P203, P206, P208, P209</b> ) are determined. <b>PMSM:</b> The stator resistance <b>P208</b> and the inductance <b>P241</b> are determined	

P240		EMF voltage PMSM		S	P										
Setting range	0 ... 800 V														
Factory setting	{ 0 }														
Description	<p>The EMF voltage PMSM describes the self induction voltage of the motor. The value to be set can be found on the data sheet for the motor or on the type plate and is scaled to 1000 rpm. As the rated speed of the motor is not usually 1000 rpm, these details must be converted accordingly:</p> <p><b>Example:</b></p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">E (EMF - constant, type plate):</td> <td style="width: 50%;">89 V</td> </tr> <tr> <td>Nn (rated speed of motor):</td> <td>2100 rpm</td> </tr> </table> <hr/> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%;">Value in P240</td> <td style="width: 50%;">P240 = E * Nn/1000</td> </tr> <tr> <td></td> <td>P240 = 89 V * 2100 rpm / 1000 rpm</td> </tr> <tr> <td></td> <td>P240 = 187 V</td> </tr> </table>					E (EMF - constant, type plate):	89 V	Nn (rated speed of motor):	2100 rpm	Value in P240	P240 = E * Nn/1000		P240 = 89 V * 2100 rpm / 1000 rpm		P240 = 187 V
E (EMF - constant, type plate):	89 V														
Nn (rated speed of motor):	2100 rpm														
Value in P240	P240 = E * Nn/1000														
	P240 = 89 V * 2100 rpm / 1000 rpm														
	P240 = 187 V														
Setting values	Value	Meaning													
	0	ASM is used	"Asynchronous motor used" No compensation												
P241		PMSM inductance		S	P										
Setting range	0.1 ... 200.0 mH														
Arrays	[-01] = Ld		[-02] = Lq												
	[-03] = Unsaturated Ld		[-04] = Unsaturated Lq												
	[-05] = Saturated Ld		[-06] = Saturated Lq												
Factory setting	All { 20.0 }														
Description	<p>The stator inductance of the d or q components of a permanently excited synchronous motor (PMSM). The stator inductances can be measured by the frequency inverter (<b>P220</b>).</p>														
P243		Reluct. angle IPMSM		S	P										
Setting range	0 ... 30°														
Factory setting	{ 0 }														
Description	<p><i>"Reluct. angle IPMSM"</i> In addition to the synchronous torque, synchronous motors with embedded magnets also have a reluctance torque. This is due to the anisotropy (imbalance) between the inductance in the d and the q direction. Due to the superimposition of these two torque components, the optimum efficiency is not at a load angle of 90° as with SPMSMs, but rather with larger values. This additional angle, which can be assumed to be 10° for NORD motors, can be taken into account with this parameter. The smaller the angle, the smaller the reluctance component.</p> <p>The specific reluctance angle for the motor can be determined as follows:</p> <ul style="list-style-type: none"> <li>• Allows drives with constant load ( &gt; 0.5 MN) to run in CFC mode (<b>P300 ≥ 1</b>)</li> <li>• Gradually increase the reluctance angle <b>P243</b> until the current <b>P719</b> reaches a minimum</li> </ul>														

<b>P244</b>	<b>Peak current PMSM</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0.1 ... 1000.0 A			
<b>Arrays</b>	[-01] =	Peak current PMSM	[-02] =	I <sub>max</sub> unsaturated Ld
	[-03] =	I <sub>max</sub> unsaturated Lq	[-04] =	I <sub>min</sub> saturated Ld
	[-05] =	I <sub>min</sub> saturated Lq		
<b>Factory setting</b>	{ 5.0 }			
<b>Description</b>	For PMSMs with non-linear induction characteristic curves, the linearity limits can be entered with parameter <b>P244 [-02] – [-05]</b> . For NORD PMSMs (IE4 and IE5+ motors) the necessary data are saved if the motor is selected in <b>P200</b> .			
<b>P245</b>	<b>Power system stabilisation PMSM VFC</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	5 ... 250 %			
<b>Factory setting</b>	{ 25 }			
<b>Description</b>	"Oscillation damping PMSM VFC". In VFC open-loop mode, PMSM motors tend to oscillate due to insufficient intrinsic damping. With the aid of oscillation damping this tendency to oscillate is counteracted by electrical damping.			
<b>P246</b>	<b>Mass Inertia</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 500 000.0 kg*cm <sup>2</sup>			
<b>Factory setting</b>	{ 31 000 }			
<b>Description</b>	The mass inertia of the drive system can be entered in this parameter. For most applications the default setting is sufficient. However, for highly dynamic systems the actual value should ideally be entered. The values for the motors can be obtained from the technical data. The portion of the external centrifugal mass (gear unit, machine) must be calculated or determined experimentally.			
<b>Note</b>	Parameter applies for ASM and PMSM.			
<b>P247</b>	<b>Switchover frequency VFC PMSM [%]</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	1 ... 100 %			
<b>Factory setting</b>	{ 25 }			
<b>Description</b>	<p>"Switchover frequency VFC PMSM". In order to provide a minimum amount of torque immediately in case of spontaneous load changes, in VFC mode the setpoint of I<sub>d</sub> (magnetisation current) is controlled depending on the frequency (field increase mode)</p> <p>The value of this additional field current is determined by parameter (<b>P210</b>). This reduces linearly to the value "zero", which is reached at the frequency which is governed by <b>P247</b>. In this case, 100 % corresponds to the rated motor frequency from <b>P201</b>.</p>			
				

### 5.1.5 Control parameters

P300		Control method		P
<b>Setting range</b>	0 ... 2			
<b>Factory setting</b>	{ 0 }			
<b>Description</b>	The control method for the motor is defined with this parameter. The following constraints must be observed: In comparison with setting {0}, setting {2} enables higher dynamics and control precision, however, it requires greater effort for parameterisation. Setting {1} operates with speed feedback from an encoder and therefore enables the highest possible quality of speed control and dynamics.			
<b>Note</b>	Commissioning information: (📖 (Chap. 4.2 "Selecting the operating mode for motor control")).			
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>		
	0	VFC open-loop	Speed control without encoder feedback	
	1	CFC closed-loop	Speed control with encoder feedback	
	2	CFC open-loop	Speed control without encoder feedback	
<b>P301</b>		<b>Incremental encoder</b>		
<b>Setting range</b>	0 ... 27			
<b>Arrays</b>	[-01] = TTL	[-02] = HTL	[-03] = Sin/Cos	
<b>Factory setting</b>	{ 6 }	{ 3 }	{ 3 }	
<b>Description</b>	"Encoder resolution". Input of the pulse count per rotation of the connected encoder. If the direction of rotation of the encoder is not the same as the FI, (depending on installation and wiring), this can be taken into account by selecting the corresponding negative pulse numbers.			
<b>Note</b>	<b>P301</b> is also significant for position control via incremental encoders. If an incremental encoder is used for positioning <b>P604 = 1</b> , the setting of the pulse number is made here (see supplementary POSICON manual).			
<b>Setting values</b>	<b>Value</b>	<b>Value</b>		
	0	500 pulses	8	-500 pulses
	1	512 pulses	9	-512 pulses
	2	1000 pulses	10	-1000 pulses
	3	1024 pulses	11	-1024 pulses
	4	2000 pulses	12	-2000 pulses
	5	2048 pulses	13	-2048 pulses
	6	4096 pulses	14	-4096 pulses
	7	5000 pulses	15	-5000 pulses
			16	-8192 pulses
	17	8192 pulses		
	18	16 pulses	23	-16 pulses
	19	32 pulses	24	-32 pulses
	20	64 pulses	25	-64 pulses
	21	128 pulses	26	-128 pulses
	22	256 pulses	27	-256 pulses

<b>P310</b>	<b>Speed controller P</b>		<b>P</b>
<b>Setting range</b>	0 ... 3200 %		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>P-component of the encoder (proportional amplification). Amplification factor, by which the speed difference between the setpoint and actual frequency is multiplied. A value of 100 % means that a speed difference of 10 % produces a setpoint of 10 %. Values that are too high can cause the output speed to oscillate.</p>		
<b>P311</b>	<b>Speed controller I</b>		<b>P</b>
<b>Setting range</b>	0 ... 800 % / ms		
<b>Factory setting</b>	{ 20 }		
<b>Description</b>	<p>I-component of the encoder (Integration component). The integration component of the controller enables complete elimination of any control deviation. The value indicates how large the setpoint change is per ms. Values that are too small cause the controller to slow down (reset time is too long).</p>		
<b>P312</b>	<b>Torque curr. ctrl. P</b>		<b>S P</b>
<b>Setting range</b>	0 ... 1000 %		
<b>Factory setting</b>	{ 400 }		
<b>Description</b>	<p>Current controller for the torque current. The higher the current controller parameters are set, the more precisely the current setpoint is maintained. At low frequencies, excessively high values of <b>P312</b> generally result in high frequency oscillations. On the other hand, excessively high values of <b>P313</b> usually cause low frequency oscillations over the entire speed range</p> <p>If the value "Zero" is set in <b>P312</b> and <b>P313</b>, the torque current control is switched off. In this case, only the lead time for the motor model is used.</p>		
<b>P313</b>	<b>Torque curr. ctrl. I</b>		<b>S P</b>
<b>Setting range</b>	0 ... 800 % / ms		
<b>Factory setting</b>	{ 50 }		
<b>Description</b>	I component of the torque current controller (see <b>P312</b> "Torque curr. ctrl. P").		
<b>P314</b>	<b>Torq curr ctrl limit</b>		<b>S P</b>
<b>Setting range</b>	0 ... 400 V		
<b>Factory setting</b>	{ 400 }		
<b>Description</b>	<p>"Torque curr. Ctrl. limit". Determines the maximum voltage increase of the torque current controller. The higher the value, the greater the maximum effect that can be exercised by the torque current controller. Excessive values in <b>P314</b> can specifically lead to instability during transition to the field weakening range (see <b>P320</b>). The values for <b>P314</b> and <b>P317</b> should always be set approximately the same, so that the field and torque current controllers are balanced.</p>		

<b>P315</b>	<b>Field curr. ctrl. P</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 1000 %		
<b>Factory setting</b>	{ 400 }		
<b>Description</b>	<p>Current controller for the field current. The higher the current controller parameters are set, the more precisely the current setpoint is maintained. At low frequencies, excessively high values of <b>P315</b> generally result in high frequency oscillations. On the other hand, excessively high values of <b>P316</b> usually cause low frequency oscillations over the entire speed range</p> <p>The field current controller is switched off if the value "Zero" is entered in <b>P315</b> and <b>P316</b>. In this case, only the lead time for the motor model is used.</p>		
<b>P316</b>	<b>Field curr. ctrl. I</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 800 % / ms		
<b>Factory setting</b>	{ 50 }		
<b>Description</b>	I component of the field current controller (see <b>P315</b> "Field current controller P").		
<b>P317</b>	<b>Field curr ctrl lim</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 400 V		
<b>Factory setting</b>	{ 400 }		
<b>Description</b>	<p>"Field curr. ctrl. limit". Determines the maximum voltage increase of the field current controller. The higher the value, the greater the maximum effect of the field current controller. Excessive values in <b>P317</b> can specifically lead to instability during transition to the field weakening range (see <b>P320</b>). The values for <b>P314</b> and <b>P317</b> should always be set approximately the same, so that the field and torque current controllers are balanced.</p>		
<b>P318</b>	<b>P weak</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 800 %		
<b>Factory setting</b>	{ 150 }		
<b>Description</b>	<p>The field weakening controller reduces the field setpoint if the synchronous speed is exceeded. In the basic speed range, the field weakening controller has no function; for this reason, the field weakening controller only needs to be set if speeds above the nominal motor speed are set. Excessive values for <b>P318</b> / <b>P319</b> cause controller oscillations. The field is not weakened sufficiently if the values are too small, or during dynamic acceleration and/or delay times. The downstream current controller can no longer read the current setpoint.</p>		
<b>P319</b>	<b>I weak</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0 ... 800 % / ms		
<b>Factory setting</b>	{ 20 }		
<b>Description</b>	Only affects the field weakening range, see <b>P318</b> "P weak"		



P320	Weak border	S	P
<b>Setting range</b>	0 ... 110 %		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>The field weakening limit determines the speed /current at which the controller begins to weaken the field. At a set value of 100 % the controller begins to weaken the field at approximately the synchronous speed.</p> <p>If values much larger than the standard values have been set in <b>P314</b> and/or <b>P317</b>, the field weakening limit should be correspondingly reduced, so that the control range is actually available to the current controller.</p>		

P321	Speed ctr. I brake off	S	P
<b>Setting range</b>	0 ... 4		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	<p>"Speed control I brake off". During the brake release time <b>P107</b> / <b>P114</b>, the I-component of the speed controller is increased. This leads to better load take-up, especially with vertical movements.</p>		
<b>Setting values</b>	<b>Value</b>	<b>Value</b>	<b>Value</b>
	0	P311 speed control I x 1	
	1	P311 speed control I x 2	3 P311 speed control I x 8
	2	P311 speed control I x 4	4 P311 speed control I x 16

P325	Encoder function	S	P
<b>Setting range</b>	0 ... 5		
<b>Arrays</b>	[-01] = TTL	[-02] = HTL	[-03] = Sin/Cos
<b>Factory setting</b> (SK 500P / SK 510P)	{ 0 }	{ 1 }	{ 0 }
<b>Factory setting</b> (SK 530P / SK 550P)	{ 1 }	{ 0 }	{ 0 }
<b>Description</b>	<p>The speed list value supplied by an incremental encoder to the FI can be used for various functions in the FI.</p>		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	Off	
	1	CFC closed-loop	"Servo mode speed measurement": The motor speed list value is used for speed control with encoder feedback. The ISD control cannot be switched off in this function.
	2	Actual PID frequency	The speed list value of a system is used for speed control. This function can also be used for controlling a motor with a linear characteristic curve. It is also possible to use an incremental encoder which is not mounted directly onto the motor for speed control. <b>P413</b> ... <b>P416</b> govern the control.
	3	Frequency addition	The determined speed is added to the actual setpoint value.
	4	Freq. subtraction	The determined speed is subtracted from the actual setpoint.
	5	Maximum frequency	The maximum possible output frequency / speed is limited by the speed of the encoder.

<b>P326</b>	<b>Ratio encoder</b>		<b>S</b>											
<b>Setting range</b>	0.01 ... 100.00													
<b>Arrays</b>	[-01] = TTL	[-02] = HTL	[-03] = Sin/Cos											
<b>Factory setting</b>	{ 1.00 }													
<b>Description</b>	<p>"Ratio encoder". If the incremental encoder is not mounted directly onto the motor shaft, then the respectively correct ratio of motor speed to encoder speed must be set.</p> $P326 = \frac{\text{Motor speed}}{\text{Encoder speed}}$													
<b>Note</b>	Not for <b>P325</b> , setting "CFC closed-loop" (servo mode speed measurement).													
<b>P327</b>	<b>Speed slip error</b>		<b>P</b>											
<b>Setting range</b>	0 ... 3000 rpm													
<b>Arrays</b>	[-01] = permissible deviation during operation (FI enabled)	[-02] = permissible values at a standstill in order to monitor the function / wear of a holding brake (FI ready for switch-on).												
<b>Factory setting</b>	{ 0 }													
<b>Description</b>	<p>"Slip error speed control". The limit value for a permitted maximum slip error can be set. If this limit value is reached, the FI switches off and displays error <b>E013.1</b> if the permissible deviation has been exceeded during operation. Error <b>E013.4</b> is displayed if the permissible deviation has been exceeded during standstill. Slip error monitoring functions with all control methods (<b>P300</b>).</p> <p><i>Relevant settings</i></p> <table border="1"> <thead> <tr> <th>Encoder type</th> <th>Electrical connection</th> <th>Parameter</th> </tr> </thead> <tbody> <tr> <td>TTL encoder</td> <td>Encoder Interface (Terminal X13)</td> <td>P325 = 0</td> </tr> <tr> <td rowspan="2">HTL encoder</td> <td>DIN3 (Terminal X11:23) ...</td> <td>P420 [-02] = 43</td> </tr> <tr> <td>DIN4 (Terminal X11:24) ...</td> <td>P420 [-04] = 44</td> </tr> </tbody> </table>			Encoder type	Electrical connection	Parameter	TTL encoder	Encoder Interface (Terminal X13)	P325 = 0	HTL encoder	DIN3 (Terminal X11:23) ...	P420 [-02] = 43	DIN4 (Terminal X11:24) ...	P420 [-04] = 44
Encoder type	Electrical connection	Parameter												
TTL encoder	Encoder Interface (Terminal X13)	P325 = 0												
HTL encoder	DIN3 (Terminal X11:23) ...	P420 [-02] = 43												
	DIN4 (Terminal X11:24) ...	P420 [-04] = 44												
<b>Setting values</b>	0 = OFF													
<b>P328</b>	<b>Speed slip delay</b>		<b>P</b>											
<b>Setting range</b>	0.0 ... 10.0 s													
<b>Arrays</b>	[-01] = permissible deviation during operation (FI enabled)	[-02] = permissible values at standstill (FI ready for switch-on)												
<b>Factory setting</b>	{ 0.0 }													
<b>Description</b>	<p>"Speed slip delay". If the permissible slip error defined in <b>P327</b> is exceeded, the error message <b>E013.1</b> is suppressed within the time limits which are set here if the permissible deviation has been exceeded during operation. Error <b>E013.4</b> is triggered if the permissible deviation has been exceeded during standstill.</p>													
<b>Setting values</b>	0 = Off													

P330	Ident startrotor pos		S
Setting range	0 ... 7		
Factory setting	{ 0 }		
Description	<p>"Ident startrotor pos". Selection of the method for determination of the starting position of the rotor (initial value of the rotor position) of a PMSM (Permanent Magnet Synchronous Motor). The parameter is only relevant for the control method "CFC closed-loop" (<b>P300</b>, setting {1}).</p>		
Setting values	Value	Meaning	
	0	<p><b>Voltage controlled:</b> With the first start of the motor, a voltage indicator is memorised to ensure that the rotor of the motor is set to the rotor position "zero". This type of identifying starting position of the rotor can only be used if there is no counter-torque from the motor (e.g. flywheel drive) at frequency "zero". If this condition is fulfilled, this method of identifying the position of the rotor is very accurate (&lt;1° electrical). This method is unsuitable for lifting equipment applications, as there is always a counter-torque.</p> <p>For operation without encoders: Up to the switch-over frequency <b>P331</b> the motor (with the nominal current memorised) is operated under voltage control. Once the switch-over frequency has been reached, the method for identifying the rotor position is switched over to the EMF method. If hysteresis (<b>P332</b>) is taken into account, the frequency falls below the value in <b>P331</b>, the frequency inverter switches back from the EMF method to voltage controlled operation.</p>	
	1	<p><b>Test signal method:</b> The starting position of the rotor is determined with a test signal. If this method is also to be used at a standstill with the brake applied, a PMSM with sufficient anisotropy between the inductance of the d and q axes is required. The greater this anisotropy is, the greater the precision of the method. With parameter <b>P212</b> the voltage level of the test signal can be changed and the rotor position controller can be adjusted with parameter <b>P333</b>. For motors which are suitable for use with the test signal method, a rotor position accuracy of 5°...10° electrical can be achieved (depending on the motor and the anisotropy). The conditions for activating the test signal method can be selected with <b>P336</b>.</p>	
	2	<p><b>Value from universal encoder, "Value from universal encoder":</b> With this method, the starting position of the rotor is determined from the absolute position of a universal encoder (Hiperface, EnDat with Sin/Cos track, BISS with Sin/Cos track or SSI with Sin/Cos track). The universal encoder type is set in parameter <b>P604</b>. For this position information to be unique, it must be known (or determined) how this rotor position relates to the absolute position of the universal encoder. This is performed with the offset parameter <b>P334</b>. Motors should either be delivered with a rotor start position "zero" or the rotor starting position must be marked on the motor. If this value is not available, the offset value can also be determined with the settings {0} and {1} of parameter <b>P330</b>. For this, the drive unit is started with the setting {0} or {1} After the first start, the determined offset value is stated in the parameter <b>P334</b>. This value is volatile, i.e. it is only stored in the RAM. In order to save it in the EEPROM, it must be briefly changed and then set back to the determined value. After this, fine tuning can be carried out with the motor running under no load. For this, the drive is operated in closed loop mode (<b>P300=1</b>) at as high a speed as possible below the field weakening point. From the starting point, the offset is gradually adjusted so that the value of the voltage component <math>U_d</math> (<b>P723</b>) is as close as possible to zero. A balance between the positive and negative direction of rotation should be sought. In general, the value "0" cannot be achieved, as the synchronous motor has a slight load due to the fan wheel at high speeds. The universal encoder should be located on the motor shaft.</p> <p><b>Note:</b> If the UART encoder is used for speed control, rotor position coupling via the setting {2} is not possible. Fault <b>E19.1</b> is triggered.</p>	
	3	<p><b>Value from CANopen encoder, "Value from CANopen encoder":</b> As for {2} however a CANopen absolute encoder is used to determine the starting position of the rotor.</p>	
	4	<p><b>Voltage zero track "Voltage encoder zero track":</b> As for setting {0}, however the zero track of the encoder is taken into account. Evaluation of the zero track is activated via <b>P420</b> "Digital inputs". With incremental encoders with a zero track, the zero track is adjusted to the magnet position "0" of the motor during the production of NORD motors Therefore, after the first time that the zero pulse is reached, the inverter adopts this value as a reference value and therefore achieves a high precision. This achieves optimum use of current per torque or optimum efficiency of the motor. Whether the zero track is only to be evaluated once or after each enable can be set via <b>P420</b>.</p>	
	5	<p><b>Test signal zero track:</b> As for setting {1}, however the zero track of the encoder is taken into account. Evaluation of the zero track is activated via <b>P420</b> "Digital inputs".</p>	
	6	<p><b>Voltage zero track sync., "Voltage controlled with zero track sync.":</b> As for setting {4}, however the starting position of the rotor is determined on each enable.</p>	
	7	<p><b>Test sig. Zero track sync., "Test signal method with zero track sync.":</b> As for setting {5}, however the starting position of the rotor is determined on each enable.</p>	

<b>P331</b>	<b>Switch over freq.</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	5.0 ... 100.0 %		
<b>Factory setting</b>	{ 15.0 }		
<b>Description</b>	"Switch over freq.". Definition of the frequency above which, in operation without encoder, the control method is activated according to <b>P300</b> . In this case, 100 % corresponds to the nominal motor frequency from <b>P201</b> .		
<b>Note</b>	The parameter is only relevant for the control method "CFC open-loop" ( <b>P300</b> , setting {2}).		
<b>P332</b>	<b>Hyst. Switchover Freq</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0.1 ... 25.0 %		
<b>Factory setting</b>	{ 5.0 }		
<b>Description</b>	"Hyst Switchover Freq". Difference between the switch-on and switch-off point in order to prevent oscillation on transition of operation without encoder to the control method specified in <b>P330</b> (and vice versa).		
<b>P333</b>	<b>Flux feedb.fact.PMSM</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	5 ... 400 %		
<b>Factory setting</b>	{ 25 }		
<b>Description</b>	" Flux feedback CFC open-loop". This parameter is necessary for the position monitor in CFC open-loop mode. The higher the value which is selected, the lower the slip error from the rotor position monitor. However, higher values also limit the lower limit frequency of the position monitor. The larger the feedback amplification which is selected, the higher the limit frequency and the higher the values which must be set in <b>P331</b> and <b>P332</b> . This conflict of objectives can therefore not be resolved simultaneously for both optimisation objectives.		
<b>Note</b>	The default value is selected so that it typically does not need to be adjusted for NORD synchronous motors.		
<b>P334</b>	<b>Encoder offset PMSM</b>	<b>S</b>	
<b>Setting range</b>	-0,500 ... 0.500 rev		
<b>Factory setting</b>	{ 0,000 }		
<b>Description</b>	Evaluation of the zero track is necessary for closed loop operation of PMSM (Permanent Magnet Synchronous Motors) with incremental encoders. The zero pulse is then used for synchronisation of the rotor position. The value to be set for parameter <b>P334</b> (offset between zero pulse and actual rotor position "Zero") must be determined experimentally or included with the motor.		
<b>Note</b>	NORD motors are delivered so that the zero pulse of the encoder corresponds to the zero pole position of the motor. In case of deviation, this can be obtained from an adhesive label on the motor.		

P336		Mode Rotorpos ident		S
Setting range	0 ... 3			
Factory setting	{ 0 }			
Description	"Mode Rotorpos ident" The precise position of the rotor must be known in order to operate a PMSM. This can be determined by various methods.			
Note	Use of the parameter is only advisable if the test signal method is set ( <b>P330</b> ).			
Setting values	Value		Meaning	
	0	First enable	Identification of the PMSM rotor position is performed when the drive is enabled for the first time.	
	1	Supply voltage	Identification of the PMSM rotor position is performed when the supply voltage is applied for the first time.	
	2	Digital input/Bus input Bit	Identification of the PMSM rotor position is triggered with an external order by means of a binary bit (digital input <b>P420</b> or Bus-in bit <b>P480</b> , setting {79}, "rotor position identification"). Identification of the rotor position is only performed if the FI is in the "ready for switch-on" state and the rotor position is not known (see <b>P434</b> , <b>P481</b> setting {28}).	
	3	Each enable	Identification of the PMSM rotor position is performed on each enable.	
P350		PLC functionality		
Setting range	0 ... 1			
Factory setting	{ 0 }			
Description	Activation of the integrated PLC			
Setting values	Value		Meaning	
	0	Off	The PLC is not active, control of the FI is via IOs.	
	1	On	The PLC is active, control of the FI is via the PLC depending on <b>P351</b>	

P351		PLC set val. select.	
Setting range	0 ... 3		
Factory setting	{ 0 }		
Description	Selection of the source for the control word (CTW) and the main setpoint (MSW) with active PLC functionality <b>P350 = {1}</b> . With the settings <b>P351 = {0}</b> and <b>{1}</b> the main setpoints are defined via <b>P553</b> , but the definition of the auxiliary setpoints remains unchanged via <b>P546</b> . This parameter is only adopted if the frequency inverter is in "Ready for switch-on" status.		
Setting values	Value	Meaning	
	0	STW & HSW = PLC	The PLC provides the control word (CTW) and the main setpoint (MSW) Parameters <b>P509</b> and <b>P510 [-01]</b> have no function.
	1	CTW = P509	The PLC provides the main setpoint (MSW) The control word source (CTW) corresponds to the setting in parameter <b>P509</b> .
	2	MSW = P510[1]	The PLC provides the control word (CTW) The source for the main setpoint (MSV) corresponds to the setting in parameter <b>P510[-01]</b> .
	3	CTW & MSW = P509/510	The source for the control word (CTW) and the main setpoint (MSW) corresponds to the setting in parameter <b>P509 / P510 [-01]</b> .
P353		Bus status via PLC	
Setting range	0 ... 3		
Factory setting	{ 0 }		
Description	This parameter decides whether the control word for the master function and the status word of the frequency inverter are further processed by the PLC.		
Setting values	Value	Meaning	
	0	Off	Control word for the master function <b>P503 ≠ 0</b> and the status word continue to be processed by the PLC.
	1	CTW for broadcast:	The control word for the master value function <b>P503 ≠ 0</b> is set by the PLC. In order to do this, the control word must be redefined in the PLC using process value "34_PLC_Busmaster_Control_word".
	2	Status word (STW) for the bus	The status word of the frequency inverter is set by the PLC. In order to do this, the status word must be redefined in the PLC using process value "28_PLC_status_word".
	3	CTW Broadcast&STWBus:	See setting {1} and {2}
P355		PLC integer setpoint	
Setting range	-32768 ... 32767		
Arrays	[-01] ... [-10]		
Factory setting	All Arrays: { 0 }		
Description	Data can be exchanged with the PLC via this INT array. This data can be used by the appropriate process variables in the PLC.		
P356		PLC long setpoint	
Setting range	-2 147 483 648 ... 2 147 483 647		
Arrays	[-01] ... [-05]		
Factory setting	All Arrays: { 0 }		
Description	Data can be exchanged with the PLC via this DINT array. This data can be used by the appropriate process variables in the PLC.		

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P360	PLC display value
Display range	- 2 147 483.648 ... 2 147 483.647
Arrays	[-01] ... [-05]
Description	Display of PLC data. By means of the relevant process variables, the parameter arrays can be written by the PLC. The values are not saved!

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P370	PLC status	
Display range	0000 ... FFFF (hex)	0000 0000 ... 1111 1111 (bin)
Description	Display of the actual PLC status.	
Display values	Value (Bit)	Meaning
	0	P350=1
	1	PLC active
	2	Stop active
	3	Debug active
	4	PLC error
	5	PLC stopped
	6	Scope Memory in use
		<b>P350</b> has been set to the function "Activate internal PLC".
		The internal PLC is active
		The PLC program is set to "Stop"
		Debugging of the PLC program is running.
		The PLC has an error. However, PLC user errors 23.xx are not displayed here.
		The PLC program has been stopped (single step or breakpoint)
		A function block uses the memory area for the oscilloscope function of the NORDCON software. The oscilloscope function cannot be used.

### 5.1.6 Control terminals

#### Information

The input functions {48} and {58} do not function with the following parameter **P400** without connection of a mains voltage (X1).

P400	Analog input func.		P
<b>Setting range</b>	0 ... 58		
<b>Arrays</b>	[-01] = Analog input 1	Analogue input 1 (AI1) integrated into the FI	
	[-02] = Analog input 2	Analogue input 2 (AI2) integrated into the FI	
	[-03] = Ext. analog input 1	"External analog input 1". Analogue input 1 of the first IO extension	
	[-04] = Ext. analog input 2	"External analog input 2". Analogue input 2 of the first IO extension	
	[-05] = Ext. A. in.1 2.IOE	"External analog input 1 of the 2nd IOE". Analogue input 1 of the second I/O extension	
	[-06] = Ext. A. in.1 2.IOE	"External analog input 2 of the 2nd IOE". Analogue input 2 of the second I/O extension	
	[-07] = Reserved		
	[-08] = Reserved		
	[-09] = Clock input 1	Evaluation of pseudo-analogue impulse signals on DI3 ( <b>P420 [-03]</b> ) if this has been set to {81} / {82}.	
<b>Scope of application</b>	[-01] ... [-02]	<b>SK 500P and higher</b>	
	[-03] ... [-09]	<b>SK 530P and higher</b>	
<b>Factory setting</b>	[-01] = { 1 } All other { 0 }		
<b>Description</b>	"Analog input function". Assignment of analogue functions to internal analogue inputs or the analogue inputs of optional modules.		
<b>Note</b>	The analogue inputs of the frequency inverter (analogue inputs 1 and 2) can alternatively be parameterised to digital functions (see <b>P420 [-13]</b> or <b>[-14]</b> ). To avoid misinterpretation of the signals, the analogue functions can then be connected to the relevant inputs ( <b>P400 [-01]</b> or <b>[-02]</b> )		
<b>Setting values</b>	<b>Value</b>	<b>Description</b>	
	00	Off	The analogue input has no function. After the FI has been enabled via the control terminals, it supplies the set minimum frequency <b>P104</b> .
	01	Set point frequency	The specified analogue range (matching of analogue input) varies the output frequency between the set minimum and maximum frequencies <b>P104</b> / <b>P105</b> .
	02	Torque current limit	Based on the set torque current limit <b>P112</b> , this can be changed by means of an analogue value. The 100 % setpoint corresponds to the set torque current limit <b>P112</b> .
	03	Actual PID frequency <sup>1)</sup>	Needed to set up a control loop. The analogue input (actual value) is compared with the setpoint (e.g. fixed frequency). The output frequency is adjusted as far as possible until the actual value equals the setpoint (see control values <b>P413</b> ... <b>P415</b> ).
	04	Frequency addition <sup>2)</sup>	The supplied frequency value is added to the setpoint.
	05	Frequency subtraction <sup>2)</sup>	The frequency value provided is subtracted from the setpoint.




06	Current limit	Based on the set current limit <b>P536</b> , this can be changed via the analogue input.
07	Maximum frequency	The maximum frequency of the FI is varied. 100 % corresponds to the setting in parameter <b>P411</b> . 0 % corresponds to the setting in parameter <b>P410</b> . The values for the min./max. output frequency <b>P104 / P105</b> cannot be exceeded or undershot.
08	Actual PID frequency limited <sup>1)</sup>	As for function {3}, "Actual frequency PID", however the output frequency cannot fall below the programmed "minimum frequency" value in Parameter <b>P104</b> (no reversal of direction of rotation).
09	Actual frequency PID monitored <sup>1)</sup>	As for Function {3}, "Actual frequency PID", however the FI switches the output frequency off when the minimum frequency <b>P104</b> is reached.
10	Servo mode torque	In the "CFC closed-loop" control method ( <b>P300 = 1</b> ) the motor torque can be set or limited with this function. Here the speed regulation is switched off and a torque control is activated. The analogue input is then the source of the setpoint. In the open-loop method ( <b>P300 ≠ 1</b> ) this function can be used with reduced control quality.
11	Torque precontrol	This function enables a value for the anticipated torque requirement to entered in the controller (interference factor switching). This function can be used to improve the load take-up of lifting equipment with separate load detection.
12	Reserved	
13	Multiplication	The setpoint is multiplied by the analogue value supplied. The analogue value adjusted to 100 % then corresponds to a multiplication factor of 1.
14	Actual value process controller <sup>1)</sup>	Activates the process controller. Activates the process controller, analogue input 1 is connected to the actual value sensor (compensator, air can, flow volume meter, etc.). The mode (0-10 V or 0/4-20 mA) is set in <b>P401</b> .
15	Process controller setpoint <sup>1)</sup>	As for Function {14}, however the setpoint is specified (e.g. by a potentiometer). The actual value must be specified using another input.
16	Process controller precontrol <sup>1)</sup>	Adds an adjustable additional setpoint after the process controller
17	Reserved	
18	Curve travel calculator	The slave communicates the actual speed to the master. From its own speed, the speed of the slave and the specified speed, the master calculates the actual setpoint speed. Therefore neither of the two drives moves faster than the specified speed in the curve.
19	Reserved	
20	Set analog output	Value from <b>P542</b>
21	... 45 Reserved	
46	Process controller	torque setpoint
47	Gear ratio factor	Sets the speed ratio between master and slave
48	Motor temperature	Motor temperature measurement with temperature sensor (e.g. KTY-84), see Section (Chap. 4.4)for details.
49	Ramp time	Acceleration and deceleration
53	d-correction, F process	"Diameter correction, PID process controller frequency"
54	d-correction Torque	"Diameter correction, torque"
55	d-correction, F+torque	"Diameter correction, PID process controller frequency and torque"
56	Acceleration time	Adjustment of the time for the acceleration process. 0 % corresponds to the shortest time possible, 100% corresponds to <b>P102</b>
57	Deceleration time	Adaptation of the time for the deceleration process. 0 % corresponds to the shortest time possible, 100% corresponds to <b>P103</b>
58	Reserved for POSICON	

1) Process controller details: P400 and "Process controller".

2) The limits of these values are set by parameter **P410** "Minimal frequency auxiliary setpoints" and parameter **P411** "Maximum frequency auxiliary setpoints".

**Note:** Overview of scaling in (Chap. 8.10).


P401	Analog input mode		S
<b>Setting range</b>	0 ... 5		
<b>Arrays</b>	[-01] = Analog input 1	Analogue input 1 (AI1) integrated into the FI	
	[-02] = Analog input 2	Analogue input 2 (AI2) integrated into the FI	
	[-03] = Ext. analog input 1	"External analog input 1". Analogue input 1 of the first IO extension	
	[-04] = Ext. analog input 2	"External analog input 2". Analogue input 2 of the first IO extension	
	[-05] = Ext. A. in.1 2.IOE	"External analog input 1 of the 2nd IOE". Analogue input 1 of the second I/O extension	
	[-06] = Ext. A. in.1 2.IOE	"External analog input 2 of the 2nd IOE". Analogue input 2 of the second I/O extension	
	[-07] = Reserved		
	[-08] = Reserved		
		[-09] = Clock input 1	
<b>Scope of application</b>	[-01] ... [-02]	SK 500P and higher	
	[-03] ... [-09]	SK 530P and higher	
<b>Factory setting</b>	All { 0 }		
<b>Description</b>	"Analog input mode". This parameter determines how the frequency inverter is to respond to an analogue signal which is less than the 0 % adjustment ( <b>P402</b> ).		
<b>Setting values</b>	<b>Value</b>	<b>Function</b>	<b>Description</b>
	0	0 – 100 % limited:	An analogue setpoint smaller than the programmed adjustment 0 % ( <b>P402</b> ) does not result in undershooting of the programmed minimum frequency <b>P104</b> , i.e. it does not result in a change of the direction of rotation.
1	0 – 100 %	<p>If a setpoint smaller than the programmed adjustment 0 % (<b>P402</b>) is present, this can cause a change in direction rotation. This allows rotation direction reversal using a simple voltage source and potentiometer.</p> <p>E. g. internal setpoint with reversal of direction of rotation:  <b>P402 = 50 %</b>, <b>P104 = 0 Hz</b>, potentiometer 0 – 10 V → Rotation direction change at 5 V in mid-range setting of the potentiometer.            At the moment of reversing (<b>hysteresis = ± P505</b>) the drive is at a standstill if the minimum frequency <b>P104</b> is smaller than the absolute minimum frequency <b>P505</b>. A brake that is controlled by the FI will be applied in the hysteresis range.</p> <p>If the minimum frequency <b>P104</b> is greater than the absolute minimum frequency <b>P505</b>, the drive reverses when the minimum frequency is reached. In the hysteresis range <b>± P104</b>, the FI supplies the minimum frequency <b>P104</b>; the brake controlled by the FI is not applied.</p>	

2	0 – 100 % monitored:	<p>If the minimum adjusted setpoint <b>P402</b> is undershot by 10 % of the difference value from <b>P403</b> and <b>P402</b>, the FI output switches off. Once the setpoint is greater than <math>P402 - (10\% * (P403 - P402))</math>, it will deliver an output signal. <b>Note:</b> A function for the relevant input must be assigned in <b>P400</b>.</p>  <p>E.g. Setpoint 4 - 20 mA: <b>P402</b>: "Adjustment 0 %" = Setting 20 %; <b>P403</b>: "Adjustment 100 %" = Setting 100 %; 10 % of the difference between <b>P403</b> and <b>P402</b> corresponds to 0.8 V; i.e. 2 V... 10 V (4 ... 20 mA) = normal operating range, 0,8 V ... 2 V = minimum frequency setpoint, less than 0,8 V (2,4 mA) causes the output to switch off.</p>
3	- 100 % – 100 %	<p>If a setpoint smaller than the programmed "adjustment 0 %" (<b>P402</b>) is present, this can cause a change in direction rotation. This allows rotation direction reversal using a simple voltage source and potentiometer.</p> <p>E. g. internal setpoint with reversal of direction of rotation: <b>P402 = 50 %</b>, <b>P104 = 0 Hz</b>, potentiometer 0 – 10 V, rotation direction change at 5 V in mid-range setting of the potentiometer. At the moment of reversing (hysteresis = <math>\pm P505</math>) the drive is at a standstill if the minimum frequency <b>P104</b> is smaller than the absolute minimum frequency <b>P505</b>. A brake which is controlled by the FI has not been applied in the hysteresis range.</p> <p>If the minimum frequency <b>P104</b> is greater than the absolute minimum frequency <b>P505</b>, the drive reverses when the minimum frequency is reached. In the hysteresis range <math>\pm P104</math>, the FI supplies the minimum frequency <b>P104</b>; the brake controlled by the FI is not applied.</p> <p><b>NOTE:</b> The function -100 % - 100 % is a description of the method of function and not a reference to a physical bipolar signal (see example above).</p>
4	0 – 100 % with error 1	<p>"0 – 100 % with shutdown on error 1". If the value of the 0 % adjustment in <b>P402</b> is undershot, the error message <b>E12.8 "Undershoot of Analog In Min"</b> is activated. If the value of the 100 % adjustment in <b>P403</b> is exceeded, the error message <b>E12.9 Analog In Max exceeded</b> is activated. Even if the analogue value is outside the limits defined in <b>P402</b> and <b>P403</b>, the setpoint value is limited to 0 – 100 %.</p> <p>The monitoring function only becomes active if an enable signal is present and the analogue value has reached the valid range (<math>\geq P402</math> bzw. <math>\leq P403</math>) for the first time (e.g. pressure build-up after switching on a pump).</p> <p>Once the function has been activated, it also operates if actuation takes place via a field bus, for example, and the analogue input is not actuated.</p>
5	0 – 100 % with error 2	<p>"0 – 100 % with shutdown on error 2":</p> <p>See setting {4} ("0 – 100 % with error switch off 1"), however: In this setting the monitoring function only becomes active if an enable signal is present and the time during which the error monitoring is suppressed has elapsed. This suppression time is set in parameter <b>P216</b>.</p>

P402	Analog input matching 0%		S								
<b>Setting range</b>	-500.0 ... 500.0 %										
<b>Arrays</b>	[-01] = Analog input 1	Analogue input 1 (AI1) integrated into the FI									
	[-02] = Analog input 2	Analogue input 2 (AI2) integrated into the FI									
	[-03] = Ext. analog input 1	"External analog input 1". Analogue input 1 of the first IO extension									
	[-04] = Ext. analog input 2	"External analog input 2". Analogue input 2 of the first IO extension									
	[-05] = Ext. A. in.1 2.IOE	"External analog input 1 of the 2nd IOE". Analogue input 1 of the second I/O extension									
	[-06] = Ext. A. in.1 2.IOE	"External analog input 2 of the 2nd IOE". Analogue input 2 of the second I/O extension									
	[-07] = Reserved										
	[-08] = Reserved										
		[-09] = Clock input 1									
<b>Scope of Application</b>	[-01] ... [-02]	<b>SK 500P and higher</b>									
	[-03] ... [-09]	<b>SK 530P and higher</b>									
<b>Factory setting</b>	All { 0.0 }										
<b>Description</b>	<p>"Analog input adjustment: 0 %". This parameter sets the value that should correspond with the minimum value of the selected function for the analogue input.</p> <p>Typical setpoints and corresponding settings:</p> <table border="0"> <tr> <td>0 – 10 V</td> <td>0.0 %</td> </tr> <tr> <td>2 – 10 V</td> <td>20.0 % (for function 0 – 100 % monitored)</td> </tr> <tr> <td>0 – 20 mA</td> <td>0.0 % (internal resistance approx. 250Ω)</td> </tr> <tr> <td>4 – 20 mA</td> <td>20.0 % (internal resistance approx. 250Ω)</td> </tr> </table>			0 – 10 V	0.0 %	2 – 10 V	20.0 % (for function 0 – 100 % monitored)	0 – 20 mA	0.0 % (internal resistance approx. 250Ω)	4 – 20 mA	20.0 % (internal resistance approx. 250Ω)
0 – 10 V	0.0 %										
2 – 10 V	20.0 % (for function 0 – 100 % monitored)										
0 – 20 mA	0.0 % (internal resistance approx. 250Ω)										
4 – 20 mA	20.0 % (internal resistance approx. 250Ω)										

P403	Analog input adjustment 100%		S								
<b>Setting range</b>	-500.0 ... 500.0 %										
<b>Arrays</b>	[-01] = Analog input 1	Analog input 1 (AI1) integrated into the FI									
	[-02] = Analog input 2	Analog input 2 (AI2) integrated into the FI									
	[-03] = Ext. analog input 1	"External analog input 1". Analogue input 1 of the first I/O extension									
	[-04] = Ext. analog input 2	"External analog input 2". Analogue input 2 of the first I/O extension									
	[-05] = Ext. A. in.1 2.IOE	"External analog input 1 of the 2nd IOE". Analogue input 1 of the second I/O extension									
	[-06] = Ext. A. in.1 2.IOE	"External analog input 2 of the 2nd IOE". Analogue input 2 of the second I/O extension									
	[-07] = Reserved										
	[-08] = Reserved										
		[-09] = Clock input 1									
<b>Scope of Application</b>	[-01] ... [-02]	SK 500P and higher									
	[-03] ... [-09]	SK 530P and higher									
<b>Factory setting</b>	All { 100.0 }										
<b>Description</b>	<p>"Analog input adjustment: 100 %". This parameter sets the value that should correspond with the maximum value of the selected function for the analogue input.</p> <p>Typical setpoints and corresponding settings:</p> <table border="0"> <tr> <td>0 – 10 V</td> <td>100.0 %</td> </tr> <tr> <td>2 – 10 V</td> <td>100.0 % (for function 0 – 100 % monitored)</td> </tr> <tr> <td>0 – 20 mA</td> <td>100.0 % (internal resistance approx. 250Ω)</td> </tr> <tr> <td>4 – 20 mA</td> <td>100.0 % (internal resistance approx. 250Ω)</td> </tr> </table>			0 – 10 V	100.0 %	2 – 10 V	100.0 % (for function 0 – 100 % monitored)	0 – 20 mA	100.0 % (internal resistance approx. 250Ω)	4 – 20 mA	100.0 % (internal resistance approx. 250Ω)
0 – 10 V	100.0 %										
2 – 10 V	100.0 % (for function 0 – 100 % monitored)										
0 – 20 mA	100.0 % (internal resistance approx. 250Ω)										
4 – 20 mA	100.0 % (internal resistance approx. 250Ω)										

### P400 ... P403



P404		Analog input filter		S
Setting range	1 ... 400 ms			
Arrays	[-01] = Analog input 1	Analogue input 1 (AI1) integrated into the FI		
	[-02] = Analog input 2	Analogue input 2 (AI2) integrated into the FI		
	[-03] = Reserve			
	[-04] = Reserve			
	[-05] = Clock input 1			
Scope of application	[-01] ... [-02]	SK 500P and higher		
	[-03] ... [-05]	SK 530P and higher		
Factory setting	All { 100 }			
Description	Adjustable digital low-pass filter for the analogue signal. Interference peaks are hidden, the response time is extended.			

P405		V/I Analog		S
Setting range	0 ... 1			
Arrays	[-01] = Analog input 1	Analog input 1 (AI1) integrated into the FI		
	[-02] = Analog input 2	Analog input 2 (AI2) integrated into the FI		
	[-03] = Reserve			
Factory setting	{ 0 }			
Description	Selection of the type of analogue signal.			
Setting values	Value	Function	Description	
	0	Voltage	A voltage signal is present at the analogue input.	
	1	Current	A current signal is present at the analogue input.	

P410		Min. freq. aux. setpoint		P
Setting range	-400.0 ... 400.0 Hz			
Factory setting	{ 0.0 }			
Description	<p>"Minimum frequency auxiliary setpoints". The minimum frequency that can act on the setpoint via the auxiliary setpoints. Auxiliary setpoints are all frequencies that are additionally delivered for further functions in the FI:</p> <ul style="list-style-type: none"> <li>• Actual frequency PID</li> <li>• Frequency addition</li> <li>• Frequency subtraction</li> <li>• Auxiliary setpoints via BUS</li> <li>• Process controller</li> <li>• Min. frequency via analogue setpoint (potentiometer)</li> </ul>			

<b>P411</b>	<b>Max. freq. a-in 1/2</b>			<b>P</b>
<b>Setting range</b>	-400.0 ... 400.0 Hz			
<b>Factory setting</b>	{ 50.0 }			
<b>Description</b>	<p>"<i>Maximum frequency auxiliary setpoints</i>". The maximum frequency that can act on the setpoint via the auxiliary setpoints. Auxiliary setpoints are all frequencies that are additionally delivered for further functions in the FI:</p> <ul style="list-style-type: none"> <li>• Actual frequency PID</li> <li>• Frequency addition</li> <li>• Frequency subtraction</li> <li>• Auxiliary setpoints via BUS</li> <li>• Process controller</li> <li>• Max. frequency via analogue setpoint (potentiometer)</li> </ul>			
<b>P412</b>	<b>Nom.val process ctrl</b>			<b>S P</b>
<b>Setting range</b>	-100 ... 100 %			
<b>Factory setting</b>	{ 5 }			
<b>Description</b>	<p>"<i>Process controller setpoint</i>". Fixed specification of a setpoint for the process controller that will only be occasionally altered. Only with <b>P400 = 14 ... 16</b> (process controller), (Chap. 8.2 "Process controller").</p>			
<b>P413</b>	<b>PID control P comp.</b>			<b>S P</b>
<b>Setting range</b>	0.0 ... 400.0 %			
<b>Factory setting</b>	{ 10.0 }			
<b>Description</b>	<p>This parameter is only effective if the function "<i>PID actual frequency</i>" is selected. The P-component of the PID controller determines the frequency jump if there is a control deviation based on the control difference. E.g.: At a setting of <b>P413 = 10 %</b> and a controller deviation of 50 %, 5 % is added to the actual setpoint.</p>			
<b>P414</b>	<b>PID control I comp.</b>			<b>S P</b>
<b>Setting range</b>	0.0 ... 3000.0 % / s			
<b>Factory setting</b>	{ 10.0 }			
<b>Description</b>	<p>This parameter is only effective when the function "<i>PID actual frequency</i>" is selected. The I-component of the PID controller determines the frequency change depending on time.</p>			

P415	PID control D comp.		S	P
<b>Setting range</b>	0 ... 400.0 % / ms			
<b>Factory setting</b>	{ 1.0 }			
<b>Description</b>	<p>This parameter is only effective if the function „<i>PID actual frequency</i>“ is selected.</p> <p>The D-component of the PID controller determines the frequency change depending on time.</p> <p>If a function of the analogue inputs is set to the function “<i>Actual value process controller</i>”, this parameter determines the controller limitation (%) after the PI controller. For further details see (Chap. 8.2 “Process controller”)</p>			
P416	Ramptime PI setpoint		S	P
<b>Setting range</b>	0.00 ... 99.99 sec			
<b>Factory setting</b>	{ 2.00 }			
<b>Description</b>	<p>“<i>Ramptime PI setpoint</i>”. This parameter is only effective when the function “<i>PID actual frequency</i>” is selected.</p> <p>Ramp for PI setpoint</p>			
P417	Offset analog output		S	P
<b>Setting range</b>	-100 ... 100 %			
<b>Arrays</b>	[-01] = Analog output	Analogue output (AO) integrated into the FI		
	[-02] = Reserve			
	[-03] = First IOE	“ <i>External analog output of first IOE</i> “. Analogue output of the first IO extension		
	[-04] = Second IOE	“ <i>External analog output of second IOE</i> “. Analogue output of the second IO extension		
<b>Scope of application</b>	[-01]	<b>SK 500P and higher</b>		
	[-03] ... [-04]	<b>SK 530P and higher</b>		
<b>Factory setting</b>	All { 0 }			
<b>Description</b>	<p>In the “Analog output” function an offset can be set in order to simplify processing of the analogue signal in further devices.</p> <p>If the analogue output has been programmed with a digital function, then the difference between the switch-on point and the switch-off point can be set in this parameter (hysteresis).</p>			



**i Information**

If the following parameter **P418** is to be used in the function of an analogue output, all functions are inactive or the value 0 V is output unless the mains voltage (X1) is applied. However, if **P418** is to be used as a digital output, function {61} must be selected. The digital functions can then be selected via **P434**.

P418	Analog output func.		P
<b>Setting range</b>	0 ... 60		
<b>Arrays</b>	[-01] =	Analogue output 1	Analogue output (AO) integrated into the FI
	[-02] =	Reserve	
	[-03] =	First IOE	"External analogue output of first IOE". Analogue output of the first IO extension
	[-04] =	Second IOE	"External analogue output of second IOE". Analogue output of the second IO extension
<b>Scope of application</b>	[-01]	<b>SK 500P and higher</b>	
	[-02] ... [-04]	<b>SK 530P and higher</b>	
<b>Factory setting</b>	All { 0 }		
<b>Description</b>	<p>"Analogue output function".:</p> <p>An analogue signal can be taken from the control terminals. Various functions are available, where the following basically applies:</p> <p>The analogue value (0 V or 0 mA analogue signal) corresponds to an amount of 0% of the selected function.</p> <p>The analogue value (10 V or 20 mA) corresponds to an amount of 100% of the selected function with the scaling factor <b>P419</b>, e.g.:</p> $\Rightarrow 10 \text{ V} = \frac{\text{Motor rating value} \cdot \text{P419}}{100\%}$		
<b>Setting values</b>	<b>Value</b>	<b>Description</b>	
<b>Analogue functions</b>	0	No function	No output signal at terminals.
	01	Actual frequency	The analogue voltage is proportional to the FI output frequency.
	02	Actual speed	This is the synchronous speed calculated by the FI based on the present setpoint. Load-dependent speed fluctuations are not taken into account. If Servo mode is used, the measured speed will be output via this function.
	03	Current	The effective value of the output current supplied by the FI.
	04	Torque current	Displays the motor load torque calculated by the FI ( <b>100 % = P112</b> ).
	05	Voltage	The output voltage supplied by the FI.
	06	D.c. link voltage	"Link voltage". The DC voltage in the FI. This is not based on the nominal motor data. 10 V with 100 % standardisation, corresponds to 450 V DC (230 V mains) or 850 Volt DC (480 V mains)!
	07	Value of P542	The analogue output can be set using parameter <b>P542</b> independently of the actual operating status of the FI. With bus control, e.g. an analogue value from the controller can be directly tunnelled to the analogue output of the FI.
	08	Apparent power	The actual apparent power calculated by the FI.
	09	Real power	The actual effective power calculated by the FI.

10	Torque [%]	The actual torque calculated by the FI.
11	Field [%]	The actual field in the motor calculated by the FI.
12	Actual frequency $\pm$	The analogue voltage is proportional to the output frequency of the FI, whereby the zero point is shifted to 5 V. For CW direction of rotation, values from 5V to 10 V are output and for CCW rotation values from 5 V to 0 V.
13	Actual speed $\pm$	This is the synchronous rotation speed calculated by the FI, based on the present setpoint, where the zero point has been shifted to 5 V. Values of 5 V to 10 V are output with CW rotation, and values of 5 V to 0 V with left-hand rotation. The measured speed is output via this function if servo mode is used.
14	Torque [%] $\pm$	Is the actual torque calculated by the FI, whereby the zero point is shifted to 5 V. For motor torques, values between 5 V and 10 V are output, and for generator torque, values between 5 V and 0 V.
15	... 28	See digital functions.
29		Reserved POSICON.
30	Setpoint freq. before ramp	" <i>Setpoint frequency before ramp</i> ". Displays the frequency produced by any upstream controllers (ISD, PID, etc.). This is then the setpoint frequency for the power level after it has been adjusted by the start-up or braking ramp <b>P102</b> , <b>P103</b> .
31	Output via BUS PZD	The analogue output is controlled via a bus system. The process data are transferred directly ( <b>P546</b> , <b>P547</b> , <b>P548 = 20</b> ).
32		See digital functions.
33	Freq. of setpt. source,	" <i>Frequency of setpoint source</i> ".
34	... 40	Reserved POSICON.
41	... 52	See digital functions.
53	... 59	Reserved
60	Value from PLC	The analogue output is set by the integrated PLC, independently of the current operating status of the FI.
61	Dig. Funct. P434	" <i>Digital function P434</i> ". If this function is set, the digital functions can be selected as in <b>P434</b> .

P419	Analog output scaling		S	P
<b>Setting range</b>	-500 ... 500 %			
<b>Arrays</b>	[-01] = Analog output 1	Analogue output (AO) integrated into the FI		
	[-02] = Reserve			
	[-03] = First IOE	"External analog output of first IOE": Analogue output of the first IO extension		
	[-04] = Second IOE	"External analog output of second IOE": Analogue output of the second IO extension		
<b>Scope of application</b>	[-01]	<b>SK 500P and higher</b>		
	[-02] ... [-04]	<b>SK 530P and higher</b>		
<b>Factory setting</b>	All { 100 }			
<b>Description</b>	<p>"Scaling of analog output".</p> <p><u>Analogue functions P418</u> (= 0 ... 6 and 8 ... 14, 30)</p> <p>Using this parameter the analogue output can be adjusted to the selected working range. The maximum analogue output (10 V) corresponds to the scaled value of the appropriate selection.</p> <p>Therefore, if this parameter is raised from 100 % to 200 % at a constant operating point, the analogue output voltage is halved. 10 V output signal then corresponds to twice the nominal value.</p> <p>For negative values the logic is reversed. An actual value of 0 % will then produce 10 V at the output and -100 % will produce 0 V.</p> <p><u>digital functions P418</u> (= 15 ... 28, 34 ... 52)</p> <p>The switching threshold can be set using this parameter for the functions "Current limit" (= 17), "Torque current limit" (= 18) and "Frequency limit" (= 19). The 100 % value refers to the corresponding nominal motor value (see <b>P435</b>).</p> <p>With a negative value, the output function is output negated (0/1 → 1/0).</p>			

## Information

With the following parameter **P420**, except for fault acknowledgement via function {1}, “Enable right”, {2} and {3} “Fault acknowledgement”, none of the input functions operate unless a mains voltage (X1) is connected.

P420		Digital inputs			
<b>Setting range</b>	0 ... 84				
<b>Arrays</b>	[-01] = Digital input 1	Digital input 1 (DI1) integrated into the FI			
	[-02] = Digital input 2	Digital input 2 (DI2) integrated into the FI			
	[-03] = Digital input 3	Digital input 3 (DI3) integrated into the FI			
	[-04] = Digital input 4	Digital input 4 (DI4) integrated into the FI			
	[-05] = Digital input 5	Digital input 5 (DI5) integrated into the FI			
	[-06] = Digital input 6	Digital input 6 (DI6) integrated into the FI			
	[-07] = Digital input 7	Digital input 1 (DIO1) integrated into SK CU5			
	[-08] = Digital input 8	Digital input 2 (DIO2) integrated into SK CU5			
	[-09] = Digital input 9	Digital input 3 (DIO3) integrated into SK CU5			
	[-10] = Digital input 10	Digital input 4 (DIO4) integrated into SK CU5			
	[-11] = Reserve				
	[-12] = Reserve				
	[-13] = Digital function Analog1	Analog input 1 (AI1) (digital function) integrated into the FI			
	[-14] = Digital function analog2	Analog input 2 (AI2) (digital function) integrated into the FI			
<b>Scope of application</b>	[-01] ... [-05]	<b>SK 500P and higher</b>			
	[-06] ... [-12]	<b>SK 530P and higher</b>			
	[-13] ... [-14]	<b>SK 500P and higher</b>			
<b>Factory setting</b>	[-01] = { 1 }	[-02] = { 2 }	[-03] = { 8 }	[-04] = { 4 }	All other { 0 }
<b>Description</b>	"Digital input functions". Up to 14 inputs which can be freely programmed with digital functions are available.				
<b>Note</b>	Analogue inputs 1 and 2 of the FI do not comply with EN61131-2 (Type 1 digital inputs)				
	Digital inputs 7... 10 can also be alternatively used as digital outputs 3... 6 (see <b>P434</b> ). For these inputs/outputs it is recommended to parameterise either an input or an output function.				
<b>Setting values</b>	<b>Value</b>	<b>Description</b>			<b>Signal</b>
	00	No function	Input switched off.		---
	01	Enable right	The FI delivers an output signal with the rotation field "Right" if a positive setpoint is present. 0 → 1 Flank ( <b>P428 = 0</b> )		High
	02	Enable left	The FI delivers an output signal with the rotation field "Left" if a positive setpoint is present. 0 → 1 Flank ( <b>P428 = 0</b> )		High
	<b>Note:</b> If the drive is to start up automatically when the mains is switched on (P428 = 1), a permanent "High" level for enabling must be provided (bridge between DIN1 and the control voltage output). If the functions "Enable Right" and "Enable Left" are actuated simultaneously, the device is blocked. If the device is in fault status but the cause of the fault no longer exists, the error message is acknowledged with a 1 → 0 flank.				
03	Phase seq. reversal	Causes the rotation field to change direction (combined with enable "Right" or "Left").		High	

04	Fixed frequency 1 <sup>1)</sup>	The frequency from <b>P429</b> is added to the actual setpoint.	High
05	Fixed frequency 2 <sup>1)</sup>	The frequency from <b>P430</b> is added to the actual setpoint.	High
06	Fixed frequency 3 <sup>1)</sup>	The frequency from <b>P431</b> is added to the actual setpoint.	High
07	Fixed frequency 4 <sup>1)</sup>	The frequency from <b>P432</b> is added to the actual setpoint.	High
<b>Note:</b> If several fixed frequencies are actuated simultaneously, they are added with the correct sign. In addition, the analogue setpoint ( <b>P400</b> ) and, if necessary, the minimum frequency ( <b>P104</b> ) are added.			
08	Param. set switching	First bit of the parameter set switching, selection of the active parameter set 1 ... 4 ( <b>P100</b> ).	High
09	Maintain the freq.	During the acceleration or deceleration phase, a "Low" level will cause the actual output frequency to be "maintained". A "High" level allows the ramp to continue.	Low
10	Voltage disable <sup>2)</sup>	The frequency inverter output voltage is switched off; the motor runs down freely.	Low
11	Quick stop <sup>2)</sup>	The device reduces the frequency according to the quick stop time from <b>P426</b> .	Low
12	Fault acknowledgement <sup>2)</sup>	Fault acknowledgement with an external signal. If this function is not programmed, a fault can also be acknowledged by a Low enable setting ( <b>P506</b> ).	0→1 Flank
13	Temperatur sensor <sup>2)</sup>	Analogue evaluation of signal which is present. Switching threshold approx. 2.5 V, switch-off delay = 2 s, warning after 1 s.  From the SK 530P / SK 550P onwards, there is a separate connection at terminals 38 and 39 which is intended for PTC resistor connection. If there is no PTC resistor on the motor, the function of the PTC resistor input can be switched off in parameter <b>P425</b> .	Level
14	Remote control <sup>2,3)</sup>	With bus system control, Low level switches the control to control via control terminals.	High
15	Jog frequency <sup>1)</sup>	The fixed frequency value can be adjusted using the HIGHER/LOWER and ENTER keys ( <b>P113</b> ), if control is via the ControlBox or ParameterBox.	High
16	Motor potentiometer	As for setting value {09}, however, the frequency is not maintained below the minimum frequency <b>P104</b> and above the maximum frequency <b>P105</b> .	Low
17	ParaSetSwitching 2	Second bit of the parameter set switching, selection of the active parameter set 1 ... 4 ( <b>P100</b> ).	High
18	Watchdog <sup>2)</sup>	The input must see a High flank cyclically ( <b>P460</b> ), otherwise error <b>E012</b> will cause a switch-off. The function starts with the 1st High flank.	0→1 Flank
19	Setpoint 1 on / off	Analogue input switch-on and switch-off 1/2 (High = ON) The Low signal sets the analogue input to 0% which does not lead to shutdown when the minimum frequency <b>P104</b> > than the absolute minimum frequency <b>P505</b> .	High
20	Setpoint 2 on / off		
21	Fixed frequency 5 <sup>1)</sup>	The frequency from <b>P433</b> is added to the actual setpoint.	High
22	... 25	Reserved POSICON.	
26	... 29	Reserved.	
30	Inhibit PID	Switches the PID controller / process controller function on and off (High = PID ON)	Low
31	Inhibit turn right <sup>2,4)</sup>	Blocks "Enable right/left" via a digital input or bus control. Does not depend on the actual direction of rotation of the motor (e.g. following negated setpoint).	Low
32	Inhibit turn left <sup>2,4)</sup>		Low
33	... 40	Reserved.	
41	Track-Z TTL-enc.	Evaluation of the zero track of a TTL encoder. Only connection to digital input 5 (DI5)	
42	Track-Z HTL-encoder	Evaluation of the zero track of an HTL encoder.	
43	Track-A HTL-enc. 3/4	Evaluation of a 24 V HTL encoder for speed measurement (connection of track A and B only possible to digital inputs 3 and 4 (DI3, DI4). For reliable evaluation, the transferable frequencies should be between 50 Hz and 150 kHz.	Pulsed
44	Track-B HTL-enc. 3/4		Pulsed

45	3-W-Ctrl.Start-Right (closing switch for enable right)	"3-Wire-Control". This control function provides an alternative to enable R/L(01, 02), for which permanently applied levels are required.	0→1 Flank
46	3-W-Ctrl.Start-Left (closing key for enable Left)	Here, only a control pulse is required to trigger the function. Control of the FI can therefore be performed entirely with keys. A pulse on the function "Reverse direction of rotation" (see Function 65) inverts the present direction of rotation. This function is reset with a "Stop signal" or by activating a key for the functions {45, 46, 49}.	0→1 Flank
49	3-Wire-Ctrl.Stop (opening key for Stop)		0→1 Flank
47	Motorpot. Freq. +		In combination with enable R/L, the output frequency can be continuously varied. To save a current value in <b>P113</b> , both inputs must have a High voltage for 1.5 s. This value is then used as the next starting value for the same direction of rotation (Enable R/L) otherwise start at $f_{min}$ . Values from other setpoint sources (e.g. fixed frequencies) are not taken into account.
48	Motorpot. Freq. -	High	
50	Bit 0 fixedfreq.Array	Fixed frequency array, binary coded digital inputs to generate up to 32 fixed frequencies. <b>P465 [-01] ... [-31]</b>	High
51	Bit 1 fixedfreq.Array		High
52	Bit 2 fixedfreq.Array		High
53	Bit 3 fixedfreq.Array		High
54	Bit 4 fixedfreq.Array		High
55	... 64	Reserved POSICON.	
65	3-Wire-Direction (closing switch to reverse direction of rotation)	See functions {45, 46, 49}	0→1 Flank
66	... 70	Reserved.	
71	Motorpot.F+ and Save	<i>"Motor potentiometer function frequency +/- with automatic saving"</i> . With this motor potentiometer function, a setpoint (sum) is set via the digital inputs and is simultaneously saved. With controller enabling R/L, this is then started up in the corresponding enable rotation direction. The frequency is retained on change of direction. Simultaneous activation of the +/- function causes the frequency setpoint to be set to zero. The frequency setpoint value can also be displayed or set in the operating value display ( <b>P001 = 30</b> , actual setpoint MP-S) or in <b>P718</b> and can be pre-set in the "Ready to switch-on" operating mode. A set minimum frequency <b>P104</b> is still effective. Other setpoint values, e.g. analogue or fixed frequencies, can be added or subtracted. Adjustment of the frequency setpoint value is performed with the ramps from <b>P102 / 103</b> .	High
72	Motorpot.F- and Save		High
73	Inhibit right+quick <sup>2,4)</sup>	Same as setting {31}, but coupled to the "Quick Stop" function.	Low
74	Inhibit left + quick <sup>2,4)</sup>	Same as setting {32}, but coupled to the "Quick Stop" function.	Low
75	... 76	Reserved.	
77	... 78	Reserved POSICON.	
79	Rotorpos. Ident	Precise knowledge of the rotor position is essential for PMSM operation. Rotor position identification is performed if the following conditions are met: <ul style="list-style-type: none"> <li>• The frequency inverter is in the status "ready to switch-on",</li> <li>• The rotor position is not known (see <b>P434</b>, <b>P481</b>, function {28}),</li> <li>• Function {2} is selected in <b>P336</b>.</li> </ul>	0→1 Flank
80	PLC stop	The program execution of the internal PLC is stopped for as long as the signal is present.	High
81	Freq.Measure input.3	The frequency measured via the analogue input ( <b>P400 [-09]</b> ) is used as the setpoint (2 kHz to 22 kHz) <b>Note:</b> Only functions with DI3.	Pulses
82	Duty measure. inp 3	The duty cycle (20% ... 80% at 2 kHz) measured via the analogue input ( <b>P400 [-09]</b> ) is used as the setpoint. <b>Note:</b> Only functions with DI3.	Pulses

- 1) If neither of the digital inputs is programmed for left or right enable, actuation of a fixed frequency or jog frequency enables the frequency inverter. The rotation field direction depends on the sign of the setpoint.
- 2) Also effective for BUS control (e.g. RS232, RS485, CANbus, CANopen, ...)
- 3) Function cannot be selected via BusIO In Bits
- 4) Notice! When using this function for end position monitoring, it must be ensured that the end position switch cannot be overrun, because as soon as the end position switch has been left, the blocking of the direction of rotation is automatically cancelled. The frequency inverter therefore accelerates again when the enable signal is applied.

<b>P425</b>	<b>Function PTC input</b>			
<b>Setting range</b>	0 ... 1			
<b>Factory setting</b>	{ 1 }			
<b>Scope of application</b>	<b>SK 530P, SK 550P</b>			
<b>Description</b>	A connected thermistor is evaluated by the device. This function must be disabled if no thermistor is connected. Otherwise the device will enter a fault state with an overtemperature message ( <b>E2.0</b> ).			
<b>Note</b>	If monitoring is deactivated, the device no longer provides direct overtemperature protection for the motor.			
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>		
	0	Off	Thermistor input not monitored.	
	1	On	Thermistor input monitoring active	
<b>P426</b>	<b>Quick stop time</b>			<b>P</b>
<b>Setting range</b>	0 ... 320.00 s			
<b>Factory setting</b>	{ 0.10 }			
<b>Description</b>	Setting of the braking time for the quick stop function which can be triggered either via a digital input, the bus control, the keyboard or automatically in case of a fault. The quick stop time is the time for the linear frequency decrease from the set maximum frequency P105 to 0 Hz. If an actual setpoint <100 % is used, the quick stop time is reduced correspondingly.			
<b>P427</b>	<b>Quick stop on Error</b>			<b>S</b>
<b>Setting range</b>	0 ... 3			
<b>Factory setting</b>	{ 0 }			
<b>Description</b>	"Quick stop on Error". Activation of automatic quick stop in case of an error. A quick stop can be triggered by error <b>E2.x</b> , <b>E7.0</b> , <b>E10.x</b> , <b>E12.8</b> , <b>E12.9</b> and <b>E19.0</b> .			
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>		
	0	Off	Automatic quick stop in case of fault is deactivated	
	1	In case of mains supply failure <sup>1)</sup>	Automatic quick stop in case of mains supply failure.	
	2	In case of faults	Automatic quick stop in case of fault	
	3	Fault or mains failure <sup>1)</sup>	Automatic quick stop in case of fault or mains failure	

1) Quick stop in case of mains failure is excluded for DC supply (P538=4).

P428	Automatic starting		S
<b>Setting range</b>	0 ... 1		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	<p><b>WARNING!</b> Danger of injury due to unexpected movements of the drive. Switch-on after an earth fault/short-circuit. Do <b>NOT</b> parameterise this parameter to “On” (<b>P428 = 1</b>), if “Automatic acknowledged.” (<b>P506 = 6</b> “Always”) has been parameterised! Secure drive against movements.</p> <p>This parameter defines how the FI responds to a static enabling signal when the mains voltage is applied (mains voltage On).</p> <p>In the standard setting <b>P428 = 0</b> Off, the FI requires a flank to enable (signal change from Low → High) at the relevant digital input.</p> <p><b>P428 = 1</b> “On” can be set if the FI must start immediately when the mains voltage is switched on. If the enable signal is permanently switched on, or equipped with a cable jumper, the FI starts up immediately.</p>		
<b>Note</b>	The setting “On” ( <b>P428 = 1</b> ) can only be enabled if the frequency inverter has been parameterised to local control ( <b>P509 = 0</b> or <b>P509 = 1</b> ).		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	Off	The device expects a flank (signal change “low → high”) at the digital input which has been parameterised to “Enable” in order to start the drive. If the device is switched on with an active enable signal (mains voltage on), it immediately switches to “Switch-on inhibit”.
	1	On	The device expects a signal level (“high”) at the digital input which has been parameterised to “Enable” in order to start the drive. <b>NOTICE! Risk of injury! Drive starts up immediately!</b>
P429	Fixed frequency 1		P
<b>Setting range</b>	-400.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	<p>Following actuation via a digital input and enabling of the device (right or left), the fixed frequency is used as a setpoint. A negative setting value will cause a phase sequence reversal (based on the <i>Enable rotation direction</i> <b>P420</b>).</p> <p>If several fixed frequencies are actuated simultaneously, the individual values are added with the correct sign. This also applies to combinations with the jog frequency <b>P113</b>, analogue setpoint (if <b>P400 = 1</b>) or minimum frequency <b>P104</b>.</p> <p>If none of the digital inputs are programmed for enable (right or left), the simple fixed frequency signal results in an enable. A positive fixed frequency corresponds to a right enable, a negative to a left enable.</p>		
<b>Note</b>	The frequency limits <b>P104 = f<sub>min</sub></b> or <b>P105 = f<sub>max</sub></b> cannot be overshoot or undershot.		



<b>P430</b>	<b>Fixed frequency 2</b>		<b>P</b>
<b>Setting range</b>	-400.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	For a description of the function of the parameter, see <b>P429</b> "Fixed frequency 1".		
<b>P431</b>	<b>Fixed frequency 3</b>		<b>P</b>
<b>Setting range</b>	-400.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	For a description of the function of the parameter, see <b>P429</b> "Fixed frequency 1".		
<b>P432</b>	<b>Fixed frequency 4</b>		<b>P</b>
<b>Setting range</b>	-400.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	For a description of the function of the parameter, see <b>P429</b> "Fixed frequency 1".		
<b>P433</b>	<b>Fixed frequency 5</b>		<b>P</b>
<b>Setting range</b>	-400.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	For a description of the function of the parameter, see <b>P429</b> "Fixed frequency 1".		

## Information

For the following parameter **P434** all functions are disabled or 0V is output unless the mains voltage (X1) is applied. This does not include the following functions: {7}, {8}, {12}, {30} – {37}, {38} and {50} – {59}.

P434	Digital out function		P	
<b>Setting range</b>	0 ... 59			
<b>Arrays</b>	[-01] = Binary output.1 / MFR1	Multi-function relay 1 (K1) integrated into the FI		
	[-02] = Binary output.2 / MFR2	Multi-function relay 2 (K2) integrated into the FI		
	[-03] = Digital output 1	Digital output 1 (DO1) integrated into the FI		
	[-04] = Digital output 2	Digital output 2 (DO2) integrated into the FI		
	[-05] = Digital output 3	Digital output 1 (DIO1) integrated into SK CU5		
	[-06] = Digital output 4	Digital output 2 (DIO2) integrated into SK CU5		
	[-07] = Digital output 5	Digital output 3 (DIO3) integrated into SK CU5		
	[-08] = Digital output 6	Digital output 4 (DIO4) integrated into SK CU5		
	[-09] = Digital function Analog1	Digital output 1 (AO1) (digital function) integrated into the FI		
		[-10] = Reserve		
	[-11] = Digital function Analog3	Analogue output 3 (AO3) (IOE) (digital function)		
	[-12] = Digital function Analog4	Analogue output 4 (AO4) (IOE) (digital function)		
<b>Scope of application</b>	<b>[-01] ... [-02] SK 500P and higher</b>			
	<b>[-03] ... [-08] SK 530P and higher</b>			
	<b>[-09] ... [-10] SK 500P and higher</b>			
	<b>[-11] ... [-12] SK 530P and higher</b>			
<b>Factory setting</b>	[-01] = { 1 }      [-02] = { 7 }      All other { 0 }			
<b>Description</b>	"Digital output function". Up to 10 outputs (2 of which are relays) are available. These can be freely programmed with digital functions. These can be seen in the following table.			
<b>Note</b>	With settings 3 to 5 and 11 the two relays (K1, K2) work with 10 % hysteresis, i.e. the relay contact closes (setting 11: opens) on reaching the limiting value and opens (setting 11: closes) if a 10 % lower value is undershot. This behaviour can be inverted with a negative value in <b>P435</b> .			
	Alternatively, digital outputs 3... 6 can also be used as digital inputs 7... 10 (see <b>P420</b> ). For these inputs/outputs it is recommended to parameterise either an input or an output function. However, if an input function and an output function are parameterised, a High signal from the output function will result in activation of the input function. This IO connection is hence used as a kind of "flag".			
<b>Setting values</b>	<b>Value</b>	<b>Description</b>	<b>Signal</b>	
	00	No function	Input switched off.	Low
	01	External brake	For control of a mechanical brake on the motor. The relay switches at a programmed absolute minimum frequency <b>P505</b> . For typical brakes a setpoint delay of 0.2 ... 0.3 s (see <b>P107</b> ) should be programmed. A mechanical brake can be directly switched with AC. (Note the technical specification of the relay contact!)	High
	02	Inverter is working	The closed relay contact indicates voltage at the inverter output (U - V - W) (as well as DC run-on <b>P559</b> ).	High
	03	Current limit	Based on the nominal motor current setting in <b>P203</b> . This value can be adjusted with scaling <b>P435</b> .	High

04	Torque current limit	Based on motor data settings in <b>P203</b> and <b>P206</b> . Signals a corresponding torque load on the motor. This value can be adjusted with scaling <b>P435</b> .	High
05	Frequency limit	Based on the motor frequency setting in <b>P201</b> . This value can be adjusted by scaling <b>P435</b> .	High
06	Setpoint reached	Indicates that the FI has completed the frequency increase or decrease. Setpoint frequency = actual frequency! From a difference of 1 Hz → Setpoint not reached - contact opens.	High
07	Fault	General fault message, fault is active or not yet acknowledged. Fault: Contact opens, ready for operation: Contact closes.	Low
08	Warning	General warning - a limit value has been reached which could result in a later shutdown of the FI.	Low
09	Overcurrent warning	At least 130 % of the nominal FI current was supplied for 30 seconds.	Low
10	Mot.overtemp.warning *	" <i>Motor overtemperature (Warning)</i> ". The motor temperature is evaluated via the thermistor input or a digital input. → Motor is too hot. The warning is given immediately, overtemperature switch-off after 2 seconds.	Low
11	Torque current limit *	" <i>Torque current limit/Current limit active (Warning)</i> ". The limit value in <b>P112</b> or <b>P536</b> has been reached. A negative value in <b>P435</b> inverts the behaviour. Hysteresis = 10 %	Low
12	Value of P541	The output can be set using parameter <b>P541</b> independently of the actual operating status of the FI.	High
13	Torq.curr. limit gen. *	Limit value in <b>P112</b> has been reached in the generator range. Hysteresis = 10 %	High
14	Effect. power limit	Ratio of the stated mechanical power to the nominal power of the motor.	
15	Freq.+ current limit		
16	Quick stop active	A quick stop ( <b>P427</b> ) has been triggered.	High
17	Quick Stop or STO enabled	A quick stop ( <b>P427</b> ) is triggered if STO " <i>Block voltage</i> " or " <i>Quick stop</i> " are enabled.	High
18	Inverter ready	The device is ready for operation. After being enabled it delivers an output signal.	High
19	Gen. torque limit	As for {13}, however a limit value can be set via <b>P435</b> .	High
20	... 27	Reserved POSICON.	
28	Rotorpos PMSM ok	The PMSM rotor position is known.	High
29	Motor stopped	Speed less than <b>P505</b>	High
30	BusIO In Bit 0	Control by Bus In Bit 0 ( <b>P546</b> ...)	High
31	BusIO In Bit 1	Control by Bus In Bit 1 ( <b>P546</b> ...)	High
32	BusIO In Bit 2	Control by Bus In Bit 2 ( <b>P546</b> ...)	High
33	BusIO In Bit 3	Control by Bus In Bit 3 ( <b>P546</b> ...)	High
34	BusIO In Bit 4	Control by Bus In Bit 4 ( <b>P546</b> ...)	High
35	BusIO In Bit 5	Control by Bus In Bit 5 ( <b>P546</b> ...)	High
36	BusIO In Bit 6	Control by Bus In Bit 6 ( <b>P546</b> ...)	High
37	BusIO In Bit 7	Control by Bus In Bit 7 ( <b>P546</b> ...)	High

38	Value Bus setpoint	Value from Bus setpoint (P546 ...)	High
39	STO inactive	The relay / bit deactivates if STO or Safe Stop are active.	High
40	Output via PLC	The output is set by the integrated PLC	High
41	Comparison value AI1,	Comparison of AIN1 with the value which can be set in the adjustment value P435.	
42	Comparison value AI2,	Comparison of AIN 2 with the value which can be set in the adjustment value P435.	
43	STO o. OUT2/3 inact.	Neither safe stop, voltage disable nor quick stop are active.	High
50	State digital In 1	A signal is present at digital input 1.	High
51	State digital In 2	A signal is present at digital input 2.	High
52	State digital In 3	A signal is present at digital input 3.	High
53	State digital In 4	A signal is present at digital input 4.	High
54	State digital In 5	A signal is present at digital input 5.	High
55 <sup>1)</sup>	State digital In 6	A signal is present at digital input 6.	High
56 <sup>1)</sup>	State digital In 7	A signal is present at digital input 7.	High
57 <sup>1)</sup>	State digital In 8	A signal is present at digital input 8.	High
58 <sup>1)</sup>	State digital In 9	A signal is present at digital input 9.	High
59 <sup>1)</sup>	State digital In 10	A signal is present at digital input 10.	High
<b>Note:</b> For relay contacts (High = "Contact closed", Low = "Contact open")			

1) SK 530P and above

P435	Dig. out scaling	P
<b>Setting range</b>	-400 ... 400 %	
<b>Arrays</b>	[-01] = Binary output.1 / MFR1	Multi-function relay 1 (K1) integrated into the FI
	[-02] = Binary output.2 / MFR2	Multi-function relay 2 (K2) integrated into the FI
	[-03] = Digital output 1	Digital output 1 (DO1) integrated into the FI
	[-04] = Digital output 2	Digital output 2 (DO2) integrated into the FI
	[-05] = Digital output 3	Digital output 3 (DO3) integrated into SK CU5
	[-06] = Digital output 4	Digital output 4 (DO4) integrated into SK CU5
	[-07] = Digital output 5	Digital output 5 (DO5) integrated into SK CU5
	[-08] = Digital output 6	Digital output 6 (DO6) integrated into SK CU5
	[-09] = Digital function Analog1	Digital output 1 (AO1) (digital function) integrated into the FI
		[-10] = Reserve
<b>Scope of application</b>	[-01] ... [-02]	SK 500P and higher
	[-03] ... [-08]	SK 530P and higher
	[-09] ... [-10]	SK 500P and higher
<b>Factory setting</b>	All { 100 }	
<b>Description</b>	<p>"Scaling of digital outputs". Adjustment of the limiting values of the digital functions. For a negative value, the output function will be output negative.</p> <p>Reference to the following values:</p> <p style="text-align: center;">Current limit (P434 = 3) = x [%] · P203 "Nominal current"</p> <p style="text-align: center;">Torque current limit (P434 = 4) = x [%] · P203 · P206 (calculated nominal motor torque)</p> <p style="text-align: center;">Frequency limit (P434 = 5) = x [%] · P201 "Nominal frequency"</p>	

<b>P436</b>	<b>Dig. out. hysteresis</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	1 ... 100 %			
<b>Arrays</b>	[-01] = Binary output.1 / MFR1	Multi-function relay 1 (K1) integrated into the FI		
	[-02] = Binary output.2 / MFR2	Multi-function relay 2 (K2) integrated into the FI		
	[-03] = Digital output 1	Digital output 1 (DO1) integrated into the FI		
	[-04] = Digital output 2	Digital output 2 (DO2) integrated into the FI		
	[-05] = Digital output 3	Digital output 3 (DO3) integrated into SK CU5		
	[-06] = Digital output 4	Digital output 4 (DO4) integrated into SK CU5		
	[-07] = Digital output 5	Digital output 5 (DO5) integrated into SK CU5		
	[-08] = Digital output 6	Digital output 6 (DO6) integrated into SK CU5		
	[-09] = Digital function Analog1	Digital output 1 (AO1) (digital function) integrated into the FI		
	[-10] = Reserve			
<b>Scope of application</b>	[-01] ... [-02]	<b>SK 500P and higher</b>		
	[-03] ... [-08]	<b>SK 530P and higher</b>		
	[-09] ... [-10]	<b>SK 500P and higher</b>		
<b>Factory setting</b>	All { 10 }			
<b>Description</b>	"Digital output hysteresis" Difference between switch-on and switch-off point to prevent oscillation of the output signal.			

<b>P460</b>	<b>Watchdog time</b>		<b>S</b>
<b>Setting range</b>	-250.0 ... 250.0 s		
<b>Factory setting</b>	{ 10.0 }		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0.1 ... 250.0	The time interval between the expected watchdog signals (programmable function of the digital inputs <b>P420</b> ). If this time interval elapses without an impulse being registered, switch-off and error message <b>E012</b> are actuated.	
	0.0	<b>Customer error:</b> As soon as a High-Low flank or a Low signal is registered on a digital input (Function 18), the FI switches off with error message <b>E012</b> .	
	-0.1 ... -250.0	<b>Rotor run watchdog:</b> In this setting the rotor run watchdog is active. The time is defined by the set value. There is no watchdog message when the FI is switched off. After each enable, a pulse must first come before the watchdog is activated.	

P464		Fixed frequency mode		S
Setting range	0 ... 1			
Factory setting	{ 0 }			
Description	This parameter determines the form in which fixed frequencies are to be processed.			
Note	The highest active fixed frequency is added to the setpoint value of the motor potentiometer if functions 71 or 72 are selected for two digital inputs.			
Setting values	Value	Meaning		
	0	Add to main setvalue	Fixed frequencies and the fixed frequency array are added to each other. That means, they are added together, or added to an analogue setpoint to which limits are assigned according to <b>P104</b> and <b>P105</b> .	
	1	Equal main setvalue	Fixed frequencies are not added - neither together, nor to main analogue setpoints. If for example, a fixed frequency is switched to an existing analogue setpoint, the analogue setpoint will no longer be considered. Programmed frequency addition or subtraction to one of the analogue inputs or bus setpoints is still possible and valid, as is the addition to the setpoint of a motor potentiometer function (function of digital inputs: 71/72). If several fixed frequencies are selected simultaneously, the frequency with the highest value has priority (example: <b>20</b> > 10 or <b>20</b> > -30).	
P465		Fixed freq. Array		
Setting range	-400.0 ... 400.0 Hz			
Arrays	[-01] = Fixed frequency array 1			
	[-02] = Fixed frequency array 2			
	...			
	[-31] = Fixed frequency array 31			
Factory setting	{ 0.0 }			
Description	In the array levels, up to 31 different fixed frequencies can be set, which in turn can be encoded for the functions 50... 54 in binary code for the digital inputs.			
P466		Minimum freq. proc. control		S P
Setting range	0.0 ... 400.0 Hz			
Factory setting	{ 0.0 }			
Description	"Minimum freq. proc. control". With the aid of the minimum process controller frequency the control ratio can also be kept to a minimum ratio, even with a master value of "zero", in order to enable adjustment of the compensator. Further details can be found in <b>P400</b> and (Chap. 8.2 "Process controller").			

P475	Delay on/off switch		S
<b>Setting range</b>	-30,000 ... 30,000 s		
<b>Arrays</b>	[-01] = Digital input 1	Digital input 1 (DI1) integrated into the FI	
	[-02] = Digital input 2	Digital input 2 (DI2) integrated into the FI	
	[-03] = Digital input 3	Digital input 3 (DI3) integrated into the FI	
	[-04] = Digital input 4	Digital input 4 (DI4) integrated into the FI	
	[-05] = Digital input 5	Digital input 5 (DI5) integrated into the FI	
	[-06] = Digital input 6	Digital input 6 (DI6) integrated into the FI	
	[-07] = Digital input 7	Digital input 7 (DI7) integrated into SK CU5	
	[-08] = Digital input 8	Digital input 8 (DI8) integrated into SK CU5	
	[-09] = Digital input 9	Digital input 9 (DI9) integrated into SK CU5	
	[-10] = Digital input 10	Digital input 10 (DI10) integrated into SK CU5	
	[-11] = Reserve		
	[-12] = Reserve		
	[-13] = Digital function Analog 1	Analogue input 1 (AI1) (digital function) integrated into the FI	
	[-14] = Digital function Analog 2	Analogue input 2 (AI2) (digital function) integrated into the FI	
<b>Scope of application</b>	[-01] ... [-05]	<b>SK 500P and higher</b>	
	[-06] ... [-12]	<b>SK 530P and higher</b>	
	[-13] ... [-14]	<b>SK 500P and higher</b>	
<b>Factory setting</b>	All { 0,000 }		
<b>Description</b>	"Digital function switch on/off delay". Adjustable switch-on/off delay for digital inputs and digital functions of analogue inputs. Use as a switch-on filter or simple process control is possible.		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	Positive values	Switch-on delayed	
	Negative values	Switch-off delayed	

**i Information**

With the following parameter **P480** the Bus IO bits are regarded as digital inputs by **P420**. Therefore, the input functions {8}, {13}, {17}, {18}, {61} and {80} – {82} do not operate without the application of a mains voltage (X1).

P480	Bus IO In Bits function					S
<b>Setting range</b>	0 ... 82					
<b>Arrays</b>	[-01] = Bus / 2nd IOE Dig In1		In Bit 0 ... 3 via Bus or digital input 1 ... 4 of the 2nd IO extension			
	[-02] = Bus / 2nd IOE Dig In2					
	[-03] = Bus / 2nd IOE Dig In3					
	[-04] = Bus / 2nd IOE Dig In4					
	[-05] = Bus / 1st IOE Dig In1		In Bit 4 ... 7 via Bus or digital output 1 ... 4 of the 1st IO extension			
	[-06] = Bus / 1st IOE Dig In2					
	[-07] = Bus / 1st IOE Dig In3					
	[-08] = Bus / 1st IOE Dig In4					
	[-09] = Flag 1		See "Use of flags" at the end of the description of parameter P481			
	[-10] = Flag 2					
	[-11] = Bit 8 Bus control word		Assignment of a function for Bit 8 or 9 of the control word			
	[-12] = Bit 9 Bus control word					
<b>Factory setting</b>	[-01] = { 1 }	[-02] = { 2 }	[-03] = { 4 }	[-04] = { 5 }	All other { 0 }	
<b>Description</b>	<p>"Bus IO In Bits function". The Bus I/O In Bits are perceived as digital inputs P420. They can be set to the same functions.</p> <p>In order to use this function, one of the bus setpoints P546 must be set to "Bus I/O In Bits 0-7". The required function must then be assigned to the relevant bit.</p>					
<b>Note</b>	<p>For the possible functions of the Bus In Bits, please refer to the table of digital input functions. Function 14 "Remote control" is not possible.</p>					
	<p>The last eight bits of the control word can be freely assigned if setting {3} is selected in <b>P551</b>. Bits 8-11 of the control word can be defined via <b>P480 [-01] – [-04]</b> and Bit 12 - 15 via <b>P480 [-05] – [-08]</b>.</p>					



 **Information**

With the following parameter **P481** the Bus IO bits are regarded as digital inputs by **P434**. Therefore, none of the functions operate without the application of a mains voltage. An exception to this is if one of the following functions has been selected: {7}, {8}, {12}, {30} – {37}, {38} und {50} – {59}.

P481	Funct-BusIO Out Bits	S
<b>Setting range</b>	0 ... 59	
<b>Arrays</b>	[-01] = Bus / Dig Out 1	Out Bit 0 ... 3 via Bus
	[-02] = Bus / Dig Out 2	
	[-03] = Bus / Dig Out 3	
	[-04] = Bus / Dig Out 4	
	[-05] = Bus / 1.IOE Dig Out 1	Out Bit 4 ... 5 via Bus or Digital output 1 ... 2 of the 1st IO extension.
	[-06] = Bus / 1.IOE Dig Out 2	
	[-07] = Bus / 2.IOE Dig Out 1	Out Bit 6 ... 7 via Bus or Digital output 1 ... 2 of the 2nd IO extension.
	[-08] = Bus / 2.IOE Dig Out 2	
	[-09] = Flag 1	See "Use of Flags" at the end of the description of parameter P481.
	[-10] = Marker 2	
	[-11] = Bit10 Bus status word Bit10	Assignment of a function for Bit 10 or 13 of the status word. <b>Note:</b> Not available with <b>P551</b> setting {3}.
	[-12] = Bit13 Bus status word Bit10	
	[-13]... [-18]	Reserve
<b>Factory setting</b>	All { 0 }	
<b>Description</b>	<p>"Bus IO Out Bits function ". The bus I/O Out bits are perceived as digital outputs <b>P434</b>. They can be set to the same functions.</p> <p>In order to use this function, one of the bus actual values <b>P543</b> must be set to "BusIO Out Bits". The required function must then be assigned to the relevant bit.</p>	
<b>Note</b>	The possible functions for the Bus Out Bits can be found in the table of functions for the digital outputs or relays.	
	The last eight bits of the status word can be freely assigned if setting {3} is selected in <b>P551</b> . Bits 8-11 of the status word can be defined via <b>P481 [-01] – [-04]</b> , Bit 12 - 13 via <b>P481 [-05] – [-06]</b> and Bit 14-15 via <b>P481 [-07] – [-08]</b> .	

## P480 ... P481 Use of Flags

With the aid of the two flags it is possible to define simple logical sequences of functions.

For this, in parameter **P481** the “trigger” of a function is defined in the arrays [-09] “Flag 1” and [-10] “Flag 2” (e.g. an overtemperature warning from the motor PTC)

In arrays [-09] and [-10] of parameter **P480**, the function which the frequency inverter is to perform if the “trigger” is active is assigned in arrays [-11] and [-12] of parameter P480. I.e. parameter **P480** determines the response of the frequency inverter.

*Example:*

In an application, the frequency inverter is to reduce the actual speed immediately (e.g. with an active fixed frequency) if the motor is in the overtemperature range (“Overtemp. motor PTC”). This is to be implemented by “Deactivation of analog input 1” via the setpoint used in this example.

This is to ensure that the load on the motor drops and the temperature can stabilise again, and that the drive systematically reduces its speed to a defined amount before a fault shutdown occurs.

Step	Description	Function
1	Specify trigger Set Flag 1 to function “Motor overtemperature warning”	P481 [-09] → Function“ 10“
2	Specify the response Set Flag 1 to the function “Setpoint 1 on/off	P480 [-09] → Function“ 19“

Depending on the function selected in **P481** the function must be inverted by adjusting the scaling **P482**.

P482	Norm. BusIO Out Bits	S
<b>Setting range</b>	-400 ... 400 %	
<b>Arrays</b>	[-01] = Bus / Dig Out 1	Out Bit 0 ... 3 via Bus
	[-02] = Bus / Dig Out 2	
	[-03] = Bus / Dig Out 3	
	[-04] = Bus / Dig Out 4	
	[-05] = Bus / 1st IOE Dig Out1	Out Bit 4 ... 5 via Bus or Digital output 1 ... 2 of the 1st IO extension.
	[-06] = Bus / 1st IOE Dig Out2	
	[-07] = Bus / 2nd IOE Dig Out1	Out Bit 6 ... 7 via Bus or Digital output 1 ... 2 of the 2nd IO extension.
	[-08] = Bus / 2nd IOE Dig Out2	
	[-09] = Flag 1	See "Use of Flags" at the end of the description of parameter P481.
	[-10] = Flag 2	
	[-11] = Bit 10 Bus status word	Bit 10 or 13 of status word
	[-12] = Bit 13 Bus status word	
	[-13] = Reserve	
	[-14] = Reserve	
	[-15] = Reserve	
	[-16] = Reserve	
	[-17] = Reserve	
	[-18] = Reserve	
<b>Factory setting</b>	All { 100 }	
<b>Description</b>	<p><i>"Scaling of Bus IO Out Bits"</i>. Adjustment of the limit values of the bus Out bits. For a negative value, the output function will be output negative.</p> <p>Reference to the following values:</p> <p style="padding-left: 40px;">Current limit (P481 = 3) = <math>x [\%] \cdot P203</math> "Nominal current"</p> <p style="padding-left: 40px;">Torque current limit (P481 = 4) = <math>x [\%] \cdot P203 \cdot P206</math> (calculated nominal motor torque)</p> <p style="padding-left: 40px;">Frequency limit (P481 = 5) = <math>x [\%] \cdot P201</math> "Nominal frequency"</p>	

P483	Hyst. BusIO Out Bits		S
<b>Setting range</b>	1 ... 100 %		
<b>Arrays</b>	[-01] = Bus / Dig Out 1	Out Bit 0 ... 3 via Bus	
	[-02] = Bus / Dig Out 2		
	[-03] = Bus / Dig Out 3		
	[-04] = Bus / Dig Out 4		
	[-05] = Bus / 1st IOE Dig Out1	Out Bit 4 ... 5 via Bus or Digital output 1 ... 2 of the 1st IO extension.	
	[-06] = Bus / 1st IOE Dig Out2		
	[-07] = Bus / 2nd IOE Dig Out1	Out Bit 6 ... 7 via Bus or Digital output 1 ... 2 of the 2nd IO extension.	
	[-08] = Bus / 2nd IOE Dig Out2		
	[-09] = Flag 1	See "Use of Flags" at the end of the description of parameter P481.	
	[-10] = Flag 2		
	[-11] = Bit 10 Bus status word	Bit 10 or 13 of status word	
	[-12] = Bit 13 Bus status word		
		[-13] = Reserve	
	[-14] = Reserve		
	[-15] = Reserve		
	[-16] = Reserve		
	[-17] = Reserve		
	[-18] = Reserve		
<b>Factory setting</b>	All { 10 }		
<b>Description</b>	"Hysteresis Bus IO Out Bits". Difference between switch-on and switch-off point to prevent oscillation of the output signal.		

**5.1.7 Additional parameters**

<b>P501</b>	<b>Inverter name</b>			
<b>Setting range</b>	A ... Z (char)			
<b>Arrays</b>	[-01] ... [-20]			
<b>Factory setting</b>	{ 0 }			
<b>Description</b>	Free input of a designation (name) for the device (max. 20 characters). With this, the frequency inverter can be uniquely identified for setting with NORDCON software or within a network.			

<b>P502</b>	<b>Value Masterfunction</b>			<b>S</b>	<b>P</b>	
<b>Setting range</b>	0 ... 57					
<b>Arrays</b>	[-01] = Master value 1	[-02] = Master value 2	[-03] = Master value 3			
	[-04] = Master value 4	[-05] = Master value 5				
<b>Factory setting</b>	all { 0 }					
<b>Description</b>	Selection of master values of a Master for output to a bus system (see <b>P503</b> ). These master values are assigned to the slave via <b>P546</b> .					
<b>Note</b>	For details regarding processing of setpoints and actual values, please refer to (Chap. 8.10).					
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>

00 = Off	10 = Reserved POSICON	21 = Act freq. w/o slip Master value; "Actual frequency without slip"
01 = Actual frequency	11 =	
02 = Actual speed	12 = BusIO Out Bits0-7	22 = Speed encoder
03 = Current	13 =	23 = Act. freq. with slip "Actual frequency with slip"
04 = Torque current	... Reserved POSICON	24 = Master value actual frequency with slip "Master value Actual frequency with slip"
05 = Digital IO status	16 =	53 = Actual value 1 PLC
06 = Reserved POSICON	17 = Value analog input 1	... ..
07 =	18 = Value analog input 2	57 = Actual value 5 PLC
08 = Set point frequency	19 = Setpoint frequency master value "Setpoint frequency master value"	58 = Clock input 1
09 = Error code	20 = Setpoint frequency master value after ramp; "Setpoint frequency master value after ramp"	

P503	Leading func. output		S
<b>Setting range</b>	0 ... 5		
<b>Factory setting</b>	{ 0 }		
<b>Description</b>	For master-slave applications this parameter specifies on which bus system the master transmits the control word and the master values <b>P502</b> for the slave. On the slave, parameters P509, P510, P546 define the source from which the slave obtains the control word and the master values from the master and how these are to be processed by the slave.		
Setting values	Value	Meaning	
	0	Off	No output of control word and master values.
	1	USS	Output of control word and master values to USS
	2	CAN	Output of control words and master values to CAN (up to 250kBaud).
	3	CANopen	Output of control words and master values to CANopen.
	4	System bus active	No output of STW and master values, however all participants which are set to "System bus active" are visible via the ParameterBox or NORDCON.
	5	CANopen + System bus active	Output of control word and master values on CAN open via the ParameterBox or NORDCON; all participants which are set on the System bus active are visible.

P504	Pulse frequency		S
<b>Setting range</b>	16.4 kHz		
<b>Factory setting</b>	{ 6.0 }		
<b>Description</b>	The internal pulse frequency for controlling the power unit can be changed with this parameter. A higher setting value reduces motor noise, but leads to increased EMC emissions and reduction of the possible motor torque.		
<b>Note</b>	The best possible degree of interference suppression for the device is achieved by using the default value and taking the wiring directives into consideration.		
	Raising the pulse frequency leads to a reduction of the possible output current, depending on the time ( $I^2t$ curve). When the temperature warning limit <b>C001</b> is reached, the pulse frequency is gradually lowered to the default value (see also <b>P537</b> ). If the inverter temperature drops by a sufficient amount, the pulse frequency is increased to the original value.		
	The pulse frequency must not change if a sine filter is used. Otherwise, "Module errors" ( <b>E4.0</b> ) can be triggered. See setting {16.2 } and {16.3}.		
<b>Setting values</b>	<b>Value</b>		<b>Meaning</b>
	min. ... 16.0	Pulse frequency min.... 16.0 kHz	The value which is set is used as the standard pulse frequency. With increasing overload the frequency inverter automatically gradually reduces the pulse frequency to the default value.
	16.1	Automatic setting of the maximum possible pulse frequency	The frequency inverter continuously determines and automatically sets the highest possible pulse frequency.
	16.2	Pulse frequency 6 kHz	Fixed pulse frequency setting. This value remains constant even in case of overload (suitable for operation with a sine filter). <b>NB:</b> With these settings, short circuits at the output which occur before enabling may possibly not be detected correctly.
	16.3	Pulse frequency 8 kHz	
	16.4	Automatic load adjustment	The pulse frequency is automatically adjusted between a minimum value (highest load reserve) and a maximum value (lowest load reserve) depending on the load. During an acceleration phase and if high power is required ( $\geq$ rated power) the minimum value is set. With constant speed and a power requirement $\leq$ 80 % rated power, the high pulse frequency is set.

P505	Absolute mini. freq.	S	P
Setting range	0.0 ... 10.0 Hz		
Factory setting	{ 2 }		
Description	<p>"<i>Absolute minimum frequency</i>". Specifies the frequency value that cannot be undershot by the FI. If the setpoint becomes smaller than the absolute minimum frequency, the FI switches off or changes to 0.0 Hz.</p> <p>At the absolute minimum frequency, braking control <b>P434</b> and the setpoint delay <b>P107</b> are executed. If the setting value "Zero" is selected, the brake relay or the digital output, which is assigned the function { 1 } in <b>P434</b>, does not switch during reversing. When controlling lift equipment without speed feedback, this value should be set to a minimum of 2 Hz. With 2 Hz and above, the current control of the FI operates and a connected motor can supply sufficient torque.</p>		
Note	Output frequencies < 4.5 Hz result in current limitation (Chap. 8.4 "Reduced output power").		

P506	Automatic acknowledged.	S
Setting range	0 ... 7	
Factory setting	{ 0 }	
Description	<p>"<i>Automatic fault acknowledgement</i>" In addition to manual fault acknowledgement, automatic acknowledgement can also be selected.</p>	
Note	<p>Automatic fault acknowledgement is performed three seconds after the error can be acknowledged.</p> <p><b>NOTICE!</b> This parameter must not be set to 6 "Always" if <b>P428</b> is set to "On". Otherwise, after an active fault (e.g. earth fault/short circuit), the device continually switches on again. This would result in destruction of the device and could possibly endanger the system.</p>	
Setting values	Value	Meaning
	0	No automatic fault acknowledgement
	1 ... 5	Number of permissible automatic fault acknowledgements within one mains-on cycle. After mains off and switch on again, the full amount is available again.
	6	Always, a fault message will always be acknowledged automatically if the cause of the error is no longer present, see note.
	7	Quit disable, acknowledgement is only possible using the OK / ENTER key or by switching off the mains. No acknowledgement is implemented by removing the enable!



<b>P509</b>	<b>Control word source</b>	
<b>Setting range</b>	0 ... 10	
<b>Factory setting</b>	{ 0 }	
<b>Description</b>	Selection of the interface via which the frequency inverter receives its control word (for enabling, direction of rotation, etc.).	
<b>Note</b>	<p>Note P510!</p> <p>For parameterisation via the bus: Set P509 and if necessary P899 to the relevant bus system.</p>	
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>
	0	Control terminals or keyboard <sup>1)</sup> "Control terminal or keyboard control". Control is via the optional control display (SK TU5-CTR) (if <b>P510 = 0</b> ) or via the digital and analogue inputs or via BUS I/O Bits.
	1	Only control terminals <sup>2)</sup> Control is via the digital and analogue input signals or via the Bus I/O Bits.
	2	USS / Modbus <sup>2)</sup> The control word is expected via the RS 485 interface. The frequency inverter automatically detects whether this is a USS protocol or a Modbus protocol.
	3	CAN <sup>2)</sup> The control word is expected via the CAN interface.
	4	USB <sup>2, 3)</sup> The control word is expected via the USB interface.
	5	Reserved
	6	CANopen <sup>2)</sup> The control word is expected via the CANopen system bus interface.
	7	Reserved
	8	Ethernet <sup>2, 4)</sup> The control word is expected via the Ethernet based interface, which was selected according to <b>P899</b> . (see <a href="#">BU 0620</a> ).
	9	CAN Broadcast <sup>2)</sup> The control word is expected via the CAN interface.
	10	CANopen Broadcast <sup>2)</sup> The control word is expected via the CANopen system bus interface.

- 1) With keyboard control: If a communication error occurs (timeout 0.5 s), the FI is disabled without an error message.
- 2) Keyboard control (SK TU5-CTR) is disabled, parameterisation is still possible.
- 3) **SK 530P** and higher.
- 4) **SK 550P** and higher.



P513	Telegram time-out		S
<b>Setting range</b>	-0.1 ... 100.0 sec		
<b>Arrays</b>	[-01] = USS / Modbus	[-02] = USB	
	[-03] = CANopen / CAN	[-04] = Ethernet	
<b>Scope of application</b>	<b>[-01] SK 500P and higher</b>	<b>[-02] SK 530P and higher</b>	
	<b>[-03] SK 500P and higher</b>	<b>[-04] SK 550P and higher</b>	
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	<p>Monitoring function of the active bus interface. Following receipt of a valid telegram, the next telegram must arrive within the set period. Otherwise, the FI reports a fault and switches off with the error message <b>E010</b> "Bus Timeout".</p> <p>A communication failure during remote control with NORDCON shuts down the frequency inverter without triggering an error.</p>		
<b>Note</b>	<p>The process data channels for USS, CAN/CANopen and CANopen Broadcast are monitored independently of each other. The decision concerning which channel is monitored is made by the setting in parameters <b>P509</b> or <b>P510</b>.</p> <p>For example, in this way it is possible to register the interruption of a CAN Broadcast communication, although the FI is still communicating with a Master via CAN.</p>		
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	-0.1	No error	Even if communication between the bus interface and the FI is interrupted, the FI continues to operate without change.
	0	Off	Monitoring is switched off.
	0.1	... 100.0	Setting of telegram downtime

P514	CAN bus baud rate					
<b>Setting range</b>	0 ... 7					
<b>Factory setting</b>	{ 5 }					
<b>Description</b>	Used to set the transfer rate (transfer speed) via the CAN bus interface. All bus participants must be set to the same baud rate.					
<b>Note</b>	Optional modules of the SK CU4-... or SK TU4-... series exclusively work with a transfer rate of 250 kBd. If the frequency inverter is connected to such a module, the factory setting (250 kBd) must be retained.					
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>
	0	10 kBaud	3	100 kBaud	6	500 kBaud
	1	20 kBaud	4	125 kBaud	7	1 MBaud <sup>1)</sup>
	2	50 kBaud	5	250 kBaud		(Only for test purposes)

1) Reliable operation cannot be guaranteed.

P515	CAN bus address	
<b>Setting range</b>	0 ... 255	
<b>Arrays</b>	[-01] = Slave address	Receipt address for CAN and CANopen system bus
	[-02] = Broadcast slave address	Broadcast receipt address for CANopen system bus (slave)
	[-03] = Master address	Broadcast transmission address for CANopen system bus (Master)
<b>Factory setting</b>	All { 32 }	
<b>Description</b>	Setting of the basic CANbus address for CAN and CANopen.	
<b>Note</b>	If several frequency inverters are to communicate with each other via the system bus, the addresses must be set as follows: FI 1 = 32, FI 2 = 34 ...	

P516	Skip frequency 1	S	P
<b>Setting range</b>	0.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	The output frequency around the frequency in the range between +P517 and -P517 set here is not displayed. This range is transmitted with the set deceleration and acceleration ramp; it cannot be continuously supplied to the output.		
<b>Note</b>	Frequencies below the absolute minimum frequency should not be set.		
<b>Setting values</b>	0.0	Skip frequency inactive	

<b>P517</b>	<b>Skip freq. area 1</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 50.0 Hz		
<b>Factory setting</b>	{ 2.0 }		
<b>Description</b>	Skip range for "Skip freq. area 1" <b>P516</b> . This frequency value is added and subtracted from the skip frequency. Skip range 1: ( <b>P516 - P517</b> ) ... ( <b>P516</b> ) ... ( <b>P516 + P517</b> )		
<b>P518</b>	<b>Skip frequency 2</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 400.0 Hz		
<b>Factory setting</b>	{ 0.0 }		
<b>Description</b>	The output frequency around the set frequency in the range between <b>+P519</b> and <b>-P519</b> set here is not displayed. This range is transmitted with the set deceleration and acceleration ramp; it cannot be continuously supplied to the output.		
<b>Note</b>	Frequencies below the absolute minimum frequency should not be set.		
<b>Setting values</b>	0.0      Skip frequency inactive		
<b>P519</b>	<b>Skip range 2</b>	<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 50.0 Hz		
<b>Factory setting</b>	{ 2.0 }		
<b>Description</b>	Skip range for "Skip frequency 2" <b>P518</b> . This frequency value is added to and subtracted from the skip frequency. Skip range 2: ( <b>P518 - P519</b> ) ... ( <b>P518</b> ) ... ( <b>P518 + P519</b> )		

P520	Flying start		S	P												
<b>Setting range</b>	0 ... 4															
<b>Factory setting</b>	{ 0 }															
<b>Description</b>	This function is required to connect the FI to motors which are already rotating, e.g. for fan drives.															
<b>Note</b>	<p>For physical reasons, flying start only operates above 1/10 of the nominal motor frequency <b>P201</b>, however not below <u>10 Hz</u>.</p> <p>Motor frequencies &gt;100 Hz are only picked up in speed controlled mode (<b>P300 = 1</b>).</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th style="background-color: #d9e1f2;">Example 1</th> <th style="background-color: #d9e1f2;">Example 2</th> </tr> </thead> <tbody> <tr> <td style="background-color: #d9e1f2;"><b>P201</b></td> <td>50 Hz</td> <td>200 Hz</td> </tr> <tr> <td style="background-color: #d9e1f2;"><b>f = 1/10* P201</b></td> <td>F = 5 Hz</td> <td>F = 20 Hz</td> </tr> <tr> <td style="background-color: #d9e1f2;"><b>Result f<sub>Fang</sub> =</b></td> <td>The flying start functions above f<sub>Fang</sub>=10Hz.</td> <td>The flying start functions above f<sub>Fang</sub>=20Hz.</td> </tr> </tbody> </table> <p>PMSM: The catch function automatically determines the direction of rotation. Therefore, if function 2 is set, the device behaves identically to function 1. If function 4 is set, the device behaves identically to function 3.</p> <p>PMSM: In CFC closed loop mode, flying start can only be executed if the rotor position is known in relation to the incremental encoder. For this purpose, the motor cannot initially rotate when it is switched on for the first time after a "mains on" of the FI. This restriction does not apply if the zero track of the incremental encoder is used.</p> <p>PMSM: The flying start does not function if fixed pulse frequencies (setting 16.2 and 16.3) are used in <b>P504</b>.</p>					Example 1	Example 2	<b>P201</b>	50 Hz	200 Hz	<b>f = 1/10* P201</b>	F = 5 Hz	F = 20 Hz	<b>Result f<sub>Fang</sub> =</b>	The flying start functions above f <sub>Fang</sub> =10Hz.	The flying start functions above f <sub>Fang</sub> =20Hz.
	Example 1	Example 2														
<b>P201</b>	50 Hz	200 Hz														
<b>f = 1/10* P201</b>	F = 5 Hz	F = 20 Hz														
<b>Result f<sub>Fang</sub> =</b>	The flying start functions above f <sub>Fang</sub> =10Hz.	The flying start functions above f <sub>Fang</sub> =20Hz.														
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>														
	0	Switched off No flying start														
	1	Both directions The FI searches for a speed in both directions.														
	2	In the setpoint direction Searches only in the direction of the present setpoint value.														
	3	Both directions after failure As for 1, however only after mains failure or fault.														
	4	Setpoint direction after failure As for 2, however only after mains failure or fault.														
P521	Flying start Resolution		S	P												
<b>Setting range</b>	0.02 ... 2.50 Hz															
<b>Factory setting</b>	{ 0.05 }															
<b>Description</b>	"Flying start resolution". The flying start circuit search increment size can be adjusted using this parameter. Values that are too large affect accuracy and cause the FI to cut out with an overcurrent message. If the values are too small, the search time is greatly extended.															

<b>P522</b>	<b>Flying start offset</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	-10.0 ... 10.0 Hz			
<b>Factory setting</b>	{ 0.0 }			
<b>Description</b>	"Flying start offset". A frequency value that can be added to the frequency value found, e.g. to remain in the motor range and so avoid the generator range and therefore the chopper range.			

<b>P523</b>	<b>Factory setting</b>			
<b>Setting range</b>	0 ... 3			
<b>Factory setting</b>	{ 0 }			
<b>Description</b>	With the selection and activation of the relevant value, the selected parameter range is set to the factory setting. Once this setting is made, the parameter value automatically changes back to 0.			
<b>Note</b>	With the setting "Load factory settings" the safety-relevant parameters <b>P423</b> , <b>P424</b> , <b>P499</b> are not reset. These must be reset manually.			

<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	
	0	No change	Does not change the parameterisation.
	1	Load factory setting	"Load factory setting". The entire parameterisation of the FI is reset to the factory setting. All originally parameterised data are lost.
	2	Fact.setng.w.out bus	"Load factory setting without bus". All FI parameters, however <i>not</i> the CAN-, CANopen-, USS-, and system bus parameters are reset to the factory setting (including Ethernet).
	3	Fact. without motor data	"Load factory setting without motor parameter". All parameters of the frequency inverter, with the <i>exception</i> of the motor data, are reset to the factory setting.
	4	Fact.set only Ethernet	"Load factory settings, only Ethernet parameters". Only the FI parameters for the Ethernet settings are reset to the factory setting

<b>P525</b>	<b>Load monitoring max</b>		<b>S</b>	<b>P</b>		
<b>Setting range</b>	1 ... 400 % / 401					
<b>Arrays</b>	Selection of up to 3 auxiliary values:					
	[-01] =	Auxiliary value 1	[-02] =	Auxiliary value 2	[-03] =	Auxiliary value 3
<b>Factory setting</b>	All { 401 }					
<b>Description</b>	"Load monitoring maximum value". Setting of the upper limit of load monitoring. Up to 3 values can be specified. Prefixes are not taken into account, only the integer values are processed (motor / generator torque, right/left rotation). The array elements <b>[-01]</b> , <b>[-02]</b> and <b>[-03]</b> of parameters <b>P525 ... P527</b> , or the entries which are made there always belong together.					
<b>Note</b>	Setting <b>401 = Off</b> → Monitoring is not performed.					

P525 ... P529	Load monitoring
	<p>With load monitoring, a range can be specified within which the load torque may change depending on the output frequency. There are three auxiliary values for the maximum permissible torque and three auxiliary values for the minimum permissible torque. A frequency is assigned to each of these auxiliary values. No monitoring is carried out below the first and above the third frequency. In addition, monitoring can be deactivated for minimum and maximum values. As standard, monitoring is deactivated.</p>
	<p>The graph illustrates the load torque current <math>I_{sq}</math> on the y-axis versus the output frequency <math>f_{soll}</math> on the x-axis. The permissible range is defined by a green area above and a yellow area below. The green area is bounded by P525 [-01] (top), P525 [-03] (middle), and P525 [-02] (bottom). The yellow area is bounded by P526 [-02] (top) and P526 [-01] (bottom). Frequency markers on the x-axis are P527 [-01], P527 [-02], and P527 [-03].</p>
	<p>The time after which a fault is triggered can be set with parameter (<b>P528</b>). If the permissible range is exceeded (<i>Example diagram: Infringement of the area marked in yellow or green</i>), the error message <b>E12.5</b> is generated if parameter <b>P529</b> does not suppress triggering of an error.</p>
	<p>A warning <b>C12.5</b> is always given after the elapse of half of the set error triggering time <b>P528</b>. This also applies if a mode is selected for which no fault message is generated. If only a maximum or minimum value is to be monitored, the other limit must be deactivated or must remain deactivated. The torque current and not the calculated torque is used as the reference value. This has the advantage that monitoring outside of the "field weakened range" without servo mode is usually more accurate. Naturally however, it cannot display more than the physical torque in the weakened field range.</p>
	<p>All parameters depend on parameter sets. No differentiation is made between motor and generator torque, therefore the value of the torque is considered. As well as this, there is no differentiation between "left" and "right" running. The monitoring is therefore independent of the prefix of the frequency. There are four different load monitoring modes <b>P529</b>.</p>
	<p>The frequencies and the minimum and maximum values belong together within the various array elements. The frequencies do not need to be sorted according to their magnitude in elements 0, 1 and 2. This is performed automatically by the frequency inverter.</p>



<b>P526</b>	<b>Load monitoring min.</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0 / 1 ... 400 %			
<b>Arrays</b>	Selection of up to 3 auxiliary values:			
	[-01] =	Auxiliary value 1	[-02] =	Auxiliary value 2
			[-03] =	Auxiliary value 3
<b>Factory setting</b>	All { 0 }			
<b>Description</b>	<p>"<i>Load monitoring, minimum value</i>" Setting of the lower limit value of load monitoring. Up to 3 values can be specified. Prefixes are not taken into account, only the integer values are processed (motor / generator torque, right/left rotation). The array elements <b>[-01]</b>, <b>[-02]</b> and <b>[-03]</b> of parameters <b>P525 ... P527</b>, or the entries which are made there always belong together.</p>			
<b>Note</b>	Setting <b>0 = Off</b> → Monitoring is not performed.			
<b>P527</b>	<b>Load control freq.</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0.0 ... 400.0 Hz			
<b>Arrays</b>	Selection of up to 3 auxiliary values:			
	[-01] =	Auxiliary value 1	[-02] =	Auxiliary value 2
			[-03] =	Auxiliary value 3
<b>Factory setting</b>	All { 25.0 }			
<b>Description</b>	<p>"<i>Load control frequency</i>" Definition of up to 3 frequency points, which define the monitoring range for load control. The auxiliary frequency values do not need to be entered in order of size. Prefixes are not taken into account, only the integer values are processed (motor / generator torque, right/left rotation). The array elements <b>[-01]</b>, <b>[-02]</b> and <b>[-03]</b> of parameters <b>P525 ... P527</b>, or the entries which are made there always belong together.</p>			
<b>P528</b>	<b>Load control delay</b>		<b>S</b>	<b>P</b>
<b>Setting range</b>	0.10 ... 320.00			
<b>Factory setting</b>	{ 2.00 }			
<b>Description</b>	<p>"<i>Load control delay</i>". Parameter <b>P528</b> defines the delay time for which an error message "<b>E12.5</b>" is suppressed on infringement of the defined monitoring range <b>P525 ... P527</b>. A warning <b>C12.5</b> is triggered after half of this time has elapsed. According to the selected control mode <b>P529</b> an error message can also be generally suppressed.</p>			

P529	Mode load control		S	P
Setting range	0 ... 3			
Factory setting	{ 0 }			
Description	Specifies the response on infringement of the monitoring range (P525 ... P527).			
Setting values	Value	Meaning		
	0	Fault and warning	Infringement of the monitoring range produces a warning "E12.5" after the elapse of the time defined in parameter P528. A warning C12.5 is triggered after half of this time has elapsed.	
	1	Warning	After the elapse of half of the time defined in P528 infringement of the monitoring range produces a warning C12.5.	
	2	Error and warning, constant travel	"Fault and warning during constant travel". As for setting{0} however monitoring is inactive during acceleration phases.	
	3	Warning during constant travel	"Warning only during constant travel". As for setting {1} however monitoring is inactive during acceleration phases	

P533	Factor I <sup>2</sup> t Motor		S
Setting range	50 ... 150 %		
Factory setting	{ 100 }		
Description	Weighting of motor current for I <sup>2</sup> t motor monitoring (P535). Larger factors permit larger currents.		

P534	Torque disconn. limit		S	P
Setting range	0 ... 400 % / 401			
Arrays	[-01] = Motor switch-off limit		[-02] = Generator switch-off limit	
Factory setting	All { 401 }			
Description	"Torque switch-off limit". Setting for a maximum permissible torque limit. A warning (C12.1 or C12.2) is given above 80% of the set limit. The drive shuts down at 100% of the set limit value. An error message (E12.1 or E12.2) is given.			
Note	Setting 401 = Off → the function is disabled.			

P535	I <sup>2</sup> t motor																																																															
<b>Setting range</b>	0 ... 24																																																															
<b>Factory setting</b>	{ 0 }																																																															
<b>Description</b>	<p>The motor temperature is calculated depending on the output current, the time and the output frequency (cooling). If the temperature limit value is reached, then switch-off occurs with error message <b>E2.1</b>. Possible positive or negative ambient conditions are not taken into account.</p> <p>Eight characteristic curves with trigger times of &lt; 60 s, 120 s and 240 s are available for the function I<sup>2</sup>t motor. The triggering times are based on classes 5, 10 and 20 for semiconductor switching devices. The recommended setting for standard applications is <b>P535 = 5</b>.</p> <p>All characteristic curves run from 0 Hz to half of the nominal frequency <b>P201</b>. The full nominal current is available from above half of the nominal frequency.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #d9e1f2;"> <th colspan="2">Switch-off class 5, 60 s at (1.5 x I<sub>N</sub> x P533)</th> <th colspan="2">Switch-off class 10, 120 s at (1.5 x I<sub>N</sub> x P533)</th> <th colspan="2">Switch-off class 20, 240 s at (1.5 x I<sub>N</sub> x P533)</th> </tr> <tr style="background-color: #d9e1f2;"> <th>I<sub>N</sub> at 0 Hz</th> <th>P535</th> <th>I<sub>N</sub> at 0 Hz</th> <th>P535</th> <th>I<sub>N</sub> at 0 Hz</th> <th>P535</th> </tr> </thead> <tbody> <tr><td>100%</td><td>1</td><td>100%</td><td>9</td><td>100%</td><td>17</td></tr> <tr><td>90%</td><td>2</td><td>90%</td><td>10</td><td>90%</td><td>18</td></tr> <tr><td>80%</td><td>3</td><td>80%</td><td>11</td><td>80%</td><td>19</td></tr> <tr><td>70%</td><td>4</td><td>70%</td><td>12</td><td>70%</td><td>20</td></tr> <tr><td><b>60%</b></td><td><b>5</b></td><td>60%</td><td>13</td><td>60%</td><td>21</td></tr> <tr><td>50%</td><td>6</td><td>50%</td><td>14</td><td>50%</td><td>22</td></tr> <tr><td>40%</td><td>7</td><td>40%</td><td>15</td><td>40%</td><td>23</td></tr> <tr><td>30%</td><td>8</td><td>30%</td><td>16</td><td>30%</td><td>24</td></tr> </tbody> </table>				Switch-off class 5, 60 s at (1.5 x I <sub>N</sub> x P533)		Switch-off class 10, 120 s at (1.5 x I <sub>N</sub> x P533)		Switch-off class 20, 240 s at (1.5 x I <sub>N</sub> x P533)		I <sub>N</sub> at 0 Hz	P535	I <sub>N</sub> at 0 Hz	P535	I <sub>N</sub> at 0 Hz	P535	100%	1	100%	9	100%	17	90%	2	90%	10	90%	18	80%	3	80%	11	80%	19	70%	4	70%	12	70%	20	<b>60%</b>	<b>5</b>	60%	13	60%	21	50%	6	50%	14	50%	22	40%	7	40%	15	40%	23	30%	8	30%	16	30%	24
Switch-off class 5, 60 s at (1.5 x I <sub>N</sub> x P533)		Switch-off class 10, 120 s at (1.5 x I <sub>N</sub> x P533)		Switch-off class 20, 240 s at (1.5 x I <sub>N</sub> x P533)																																																												
I <sub>N</sub> at 0 Hz	P535	I <sub>N</sub> at 0 Hz	P535	I <sub>N</sub> at 0 Hz	P535																																																											
100%	1	100%	9	100%	17																																																											
90%	2	90%	10	90%	18																																																											
80%	3	80%	11	80%	19																																																											
70%	4	70%	12	70%	20																																																											
<b>60%</b>	<b>5</b>	60%	13	60%	21																																																											
50%	6	50%	14	50%	22																																																											
40%	7	40%	15	40%	23																																																											
30%	8	30%	16	30%	24																																																											
<b>Note</b>	<p>Switch-off classes 10 and 20 are provided for applications with heavy starting. When using these switch-off classes, it must be ensured that the FI has a sufficiently high overload capacity.</p> <p>Disable monitoring for multiple motor operation.</p> <p><b>0 = Off</b> → Monitoring is not performed.</p> <p>When switching on for the first time, there may be a delay of a few milliseconds</p>																																																															
P536	Current limit			S																																																												
<b>Setting range</b>	0.1 .... 2.0 / 2.1																																																															
<b>Factory setting</b>	{ 1.5 }																																																															
<b>Description</b>	The output current is limited to the rated current of the frequency inverter (see technical data) taking into account the factor which is set in <b>P536</b> . When the limit value is reached, the FI reduces the actual output frequency.																																																															
<b>Note</b>	Setting <b>2.1 = Off</b> → The parameter is disabled.																																																															

P537		Pulse Disconnection	S
Setting range	10 ... 200 % / 201		
Factory setting	{ 150 }		
Description	This function prevents rapid shutdown of the FI according to the load. With the pulse switch-off enabled, the output current is limited to the set value. This limitation is implemented by briefly switching off individual output stage transistors; the actual output frequency remains unchanged.		
Note	The value set here can be undershot by a smaller value in <b>P536</b> . For smaller output frequencies (< 4.5 Hz) or higher pulse frequencies (> 6 kHz or 8 kHz, P504), pulse switch-off by power reduction (Chap. 8.4 "Reduced output power") can be undershot.		
	If the function is disabled and a high pulse frequency is selected in parameter <b>P504</b> , the frequency inverter automatically reduces the pulse frequency when the power limits are reached. If the load on the inverter is reduced, the pulse frequency increases back to the original value.		
Setting values	Value		Meaning
	10 ... 200 %		Limit value in relation to nominal FI current
	201		The function is so to speak disabled; the FI supplies the maximum possible current. However, at the current limit the pulse switch off can still be active.
P538		Mains voltage Monitoring	S
Setting range	0 ... 4		
Factory setting	{ 3 }		
Description	<i>"Mains voltage monitoring"</i> . For reliable operation of the frequency inverter the power supply must have a certain quality. If there is a brief interruption of a phase or the voltage supply falls below a particular limit value, the inverter will output an error. Under certain operating conditions, it may be necessary to suppress this error message. In this case, the input monitoring can be modified.		
Note	Operation with an impermissible mains voltage can destroy the frequency inverter!		
	With 1/3~230 V or 1~115 V devices, the phase error monitoring does not function!		
Setting values	Value		Meaning
	0	Off	No monitoring of supply voltage.
	1	Phase error	Only phase errors will produce an error message.
	2	Mains voltage	Only low voltage will produce an error message.
	3	Phase err. + mains voltage	<i>"Phase error and mains voltage"</i> . A phase error or undervoltage triggers an error message.
	4	DC supply	The input voltage is fixed at 480 V for the direct supply of direct current. Phase error and low mains voltage monitoring are deactivated.

P539	Check output voltage		S	P
Setting range	0 ... 3			
Factory setting	{ 0 }			
Description	The output current at the U-V-W terminals is monitored and checked for plausibility. In case of error, the error message <b>E016</b> is output.			
Note	This function can be used as an additional protective function for lifting applications, but is not permissible on its own as protection for persons.			
Setting values	Value	Meaning		
	0	Off	Monitoring is not performed.	
	1	Motor Phases only	The output current is measured and checked for symmetry. If an asymmetry is present, the FI switches off and outputs error message <b>E016</b> .	
	2	Magnetisation only	At the moment the FI is switched on, the level of the excitation current (field current) is checked. If insufficient excitation current is present, the FI switches off with the error message <b>E016</b> . A motor brake is not released in this phase.	
	3	Motor Phas.+Magnet.	Monitoring according to settings {1} and {2}.	

P540	Mode phase sequence		S	P
Setting range	0 ... 7			
Factory setting	{ 0 }			
Description	For safety reasons, this parameter can be used to prevent a rotation direction reversal and therefore prevent an incorrect rotation direction.			
Note	This function influences the function of the position control (P600 ≠ 0).			
Setting values	Value	Meaning		
	0	No restriction	No restriction of direction of rotation	
	1	Direction key disabled	The rotation direction key on the ControlBox SK TU5-CTR is blocked.	
	2	Right running only <sup>1)</sup>	Only the "right" field of rotation is possible. Selection of the "incorrect" rotation direction results in the output of the minimum frequency <b>P104</b> with the field of rotation R.	
	3	Left running only <sup>1)</sup>	Only the left direction is possible. Selection of the "incorrect" rotation direction results in the output of the minimum frequency <b>P104</b> with the field of rotation L.	
	4	Only enable direction	Rotation direction is only possible according to the enable signal, otherwise 0 Hz is output.	
	5	Only Right direction monitored <sup>1)</sup>	<i>"Only Right direction monitored"</i> Only Right direction is possible. Selection of the "incorrect" rotation direction leads to the FI switching off (control block). If necessary, an adequately large setpoint value (>fmin) must be observed.	
	6	Only Left running monitored <sup>1)</sup>	<i>"Only Left running monitored"</i> . Only Left direction is possible. Selection of the "incorrect" rotation direction leads to the FI switching off (control block). If necessary, an adequately large setpoint value (>fmin) must be observed.	
	7	Only enable direction monitored	<i>"Only enable direction monitored"</i> Rotation direction is only possible according to the enable signal, otherwise the FI is switched off.	

1) Applies for control via control terminals and keyboard (SK TU5-CTR). In addition the direction key of the ControlBox is disabled.

P541	Set digital out		S	
<b>Setting range</b>	0000 ... 3FFF (hex)			
<b>Arrays</b>	[-01] = Internal (Set relays)	[-02] = Set Bus / IOE Out		
<b>Factory setting</b>	{ 0000 }			
<b>Description</b>	<p>"Set relays and digital outputs". This function provides the option of controlling the relay and the digital outputs independently of the frequency inverter status. For this, the corresponding output (e.g. multi-function relay 1: <b>P434</b> [-01]) must be set to Function {12}, "Value of P541".</p> <p>This function can either be used manually or in combination with a bus control.</p>			
<b>Note</b>	The setting is not saved in the EEPROM and is lost when the frequency inverter is switched off!			
<b>Setting values</b>	[-01]= Internal (Set relays)	[-02] = Set Bus / IOE Out		
	Bit 0	Binary output.1 / MFR1	Bit 0	Bus/IOE – Dig-Out1
	Bit 1	Binary output.2 / MFR2	Bit 1	Bus/IOE – Dig-Out2
	Bit 2	Binary output 3 / Digital output 1 <sup>1)</sup>	Bit 2	Bus/IOE – Dig-Out3
	Bit 3	Binary output 4 / Digital output 2 <sup>1)</sup>	Bit 3	Bus/IOE – Dig-Out4
	Bit 4	Binary output 5 / Digital output 3 (CU5) <sup>1)</sup>	Bit 4	Bus/IOE – Dig-Out5
	Bit 5	Binary output 6 / Digital output 4 (CU5) <sup>1)</sup>	Bit 5	Bus/IOE – Dig-Out6
	Bit 6	Binary output 7 / Digital output 5 (CU5) <sup>1)</sup>	Bit 6	Bus/IOE – Dig-Out7
	Bit 7	Binary output 8 / Digital output 6 (CU5) <sup>1)</sup>	Bit 7	Bus/IOE – Dig-Out8
	Bit 8	Digital function Analog1		
	Bit 9	Reserve		
	Bit 10	Analog output 3...IOE1 IOE1 <sup>1)</sup>		
	Bit 11	Analog output 4...IOE2 IOE1 <sup>1)</sup>		

1) SK 530P and higher

P542	Set analog output		S
<b>Setting range</b>	0 ... 100 %		
<b>Arrays</b>	[-01] = Analog output	Analog output (AO) integrated into the FI	
	[-02] = Reserved		
	[-03] = First IOE	Analog output of first IO extension	
	[-04] = Second IOE	Analog output of second IO extension	
<b>Scope of application</b>	[-01] ... [-02]	<b>SK 500P and higher</b>	
	[-03] ... [-04]	<b>SK 530P and higher</b>	
<b>Factory setting</b>	All { 0 }		
<b>Description</b>	<p>"Set analog output". This function enables the setting of the analogue outputs of the FI or the connected IO- extension module regardless of the actual operating statuses. For this, the relevant analogue output must be set to the function "External control" (e.g.: <b>P418 = 7</b>).</p> <p>This function can either be used manually or in combination with a bus control. After confirmation the value set here is output to the analogue output.</p>		
<b>Note</b>	The setting is not saved in the EEPROM and is lost when the frequency inverter is switched off!		

### Information

The input functions {10}, {11}, {13} to {16}, {53} to {57} and {58} do not function with the following parameter **P543** without connection of a mains voltage (X1).

P543	Bus actual value		S	P
<b>Setting range</b>	0 ... 57			
<b>Arrays</b>	[-01] = Actual bus value 1	[-02] = Actual bus value 2	[-03] = Actual bus value 3	
	[-04] = Actual bus value 4	[-05] = Actual bus value 5		
<b>Factory setting</b>	[-01] = { 1 }	[-02] = { 4 }	[-03] = { 9 }	[-04] = { 0 } [-05] = { 0 }
<b>Description</b>	Setting of the return values for bus control.			
<b>Setting values</b>	<b>Value / Meaning</b>			
0	Off	18	Value analog input 2	
1	Actual frequency	19	Setpoint frequency master value <b>P503</b>	
2	Actual speed	20	Setpoint master value after ramp, "Setpoint master value after ramp"	
3	Current			
4	Torque current ( <b>100 % = P112</b> )	21	Act. freq. w/o slip, "Master value, actual frequency without slip"	
5	State of digital-IO <sup>1)</sup>			
6, 7	Reserved POSICON	22	Speed encoder	
8	Set point frequency	23	Actual frequency with slip, "Actual frequency with slip"	
9	Error code	24	Master value, actual freq. with slip, "Master value, actual frequency with slip"	
10, 11	Reserved POSICON	53	Actual value 1 PLC	
12	BusIO Out Bits 0-7	...	...	
13	Reserved POSICON	57	Actual value 5 PLC	
...		58	Clock input 1	
16				
17	Value analog input 1			

#### 1) Digital input assignments:

Bit 0 (FI):	DI 1	Bit 4 (FI):	DI 5	Bit 8 (FI):	AI 2	Bit 12 (FI):	K1
Bit 1 (FI):	DI 2	Bit 5 (FI):	DI 6	Bit 9 (CU5):	DI 2	Bit 13 (FI):	K2
Bit 2 (FI):	DI 3	Bit 6 (CU5):	DI 1	Bit 10 (CU5):	DI 3	Bit 14 (FI):	DO 1
Bit 3 (FI):	DI 4	Bit 7 (FI):	AI 1	Bit 11 (CU5):	DI 4	Bit 15 (FI):	DO 2

**i Information**

The input functions {21} to {46}, {48} and {58} do not function with the following parameter **P546** without connection of a mains voltage (X1).

P546	Funct. Bus set point			S	P
<b>Setting range</b>	0 ... 57				
<b>Arrays</b>	[-01] = Bus set point 1		[-02] = Bus set point 2		[-03] = Bus set point 3
	[-04] = Bus set point 4		[-05] = Bus set point 5		
<b>Factory setting</b>	[-01] = { 1 }		All other { 0 }		
<b>Description</b>	Assignment of a function to a bus set point value.				
<b>Setting values</b>	Value				
	0	Off	18	Curve control	
	1	Setpoint frequency	19	Set Relais, "Output status" (as for <b>P541</b> )	
	2	Torque current limit <b>P112</b>			
	3	PID current freq.	20	Set Analog Out (as for <b>P542</b> )	
	4	Frequency addition	21	Reserved POSICON	
	5	Frequency subtract.	...		
	6	Current limit <b>P536</b>	24		
	7	Maximum frequency <b>P105</b>	46		
	8	PID ltd.current.freq			
	9	PID suprvsd.cur.freq	47	Reserved POSICON	
	10	Servo-Mode Torque <b>P300</b>	48	Motor temperature	
	11	Pre-tension Torque <b>P214</b>	49	Ramp time (acceleration / deceleration)	
	12	Reserved	53	d-corr. F Process	
	13	Multiplication	54	d-corr. Torque	
	14	Cur.val process ctrl	55	d-corr. F+Torque	
	15	Nom.val process ctrl	56	Acceleration time	
	16	Add. process control	57	Deceleration time	
	17	BusIO In Bits 0-7			



P549	Pot Box function				S
Setting range	0 ... 16				
Factory setting	{ 0 }				
Description	This parameter provides the option of adding a correction value (fixed frequency, analogue value, bus) to the actual setpoint value by means of the ControlBox keyboard. An explanation can be found in the description of <b>P400</b> .				
Setting values	Value	Meaning	Value	Meaning	
	0	Off	4	Frequency addition	
	5	Freq. subtraction			

P550	µSD orders			
Setting range	0 ... 10			
Factory setting	{ 0 }			
Scope of application	<b>SK 530P, SK 550P</b>			
Description	If a Micro SD card is present in slot X18, entire parameter sets (each consisting of the parameter sets 1 – 4) can be exchanged between the microSD card and the frequency inverter. <b>Note:</b> This does not include Ethernet-related parameters.			
Note	5 storage areas are available on the microSD card. Therefore data sets from a total of 5 different frequency inverters can be archived on the card.			
	<b>NB:</b> Do not remove the microSD card during data transfer (loss of data! + Error <b>E026</b> )			
	<b>NOTICE!</b> The existing data will be overwritten.			
	<b>NOTICE!</b> The data to be copied are not checked for plausibility. When writing to the frequency inverter, take care that the correct data set for the FI is transferred, otherwise frequency inverter malfunctions may occur.			
Setting values	Value	Meaning		
	0	No change	No copying	
	1	FI → µSD 1	The data set is copied from the frequency inverter to storage area 1 of the microSD card.	
	2	FI → µSD 2	As for 1, however to storage area 2.	
	3	FI → µSD 3	As for 1, however to storage area 3.	
	4	FI → µSD 4	As for 1, however to storage area 4.	
	5	FI → µSD 5	As for 1, however to storage area 5.	
	6	µSD 1 → FI	The data set is copied from storage area 1 of the microSD card to the frequency inverter.	
	7	µSD 2 → FI	As for 6, however to storage area 2.	
	8	µSD 3 → FI	As for 6, however to storage area 3.	
	9	µSD 4 → FI	As for 6, however to storage area 4.	
	10	µSD 5 → FI	As for 6, however to storage area 5.	
11	Format µSD			

P551	Drive profile		S
Setting range	0 ... 3		
Factory setting	{ 0 }		
Description	Activation of a process data profile.		
Setting values	Value	Meaning	
	0	USS	No specific drive profile.
	1	CANopen DS402	CANopen drive profile according to DS402.
	2	Reserve	
	3	Nord-Custom	Drive profile with freely assignable bits. <b>Note:</b> The free bits are set via parameters <b>P480 / P481</b>

### P551{ 3} Free bit assignment in the control and status word for NORD custom

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
P480	P480	P480	P480	P480	P480	P480	P480	FR	P2	P1	SPE	EO	QS	EV	SO
[ -07]	[ -06]	[ -05]	[ -04]	[ -03]	[ -02]	[ -01]	[ -00]								

Control word

**SO** = Switched On  
**EV** = Enable Voltage  
**QS** = Quick Stop  
**EO** = Enable Operation  
**SPE** = Setpoint Enable  
**P1 / P2** = Parameter Set Switch  
**FR** = Fault Reset  
**P480 [0...7]** = NORD User Bit

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
P481	P481	P481	P481	P481	P481	P481	P481	WARN	P2	P1	TARG	FAULT	QS	OE	RTSO
[ -07]	[ -06]	[ -05]	[ -04]	[ -03]	[ -02]	[ -01]	[ -00]								

Status word

**RTSO** = Ready To Switch On  
**OE** = Operation Enabled  
**QS** = Quick Stop  
**FAULT** = Error occurred  
**TARG** = Target Reached  
**P1 / P2** = Current Parameter Set  
**WARN** = Warning  
**P481 [0...7]** = NORD User Bit

<b>P552</b>	<b>CAN master cycle</b>	<b>S</b>
<b>Setting range</b>	0 ... 100 ms	
<b>Arrays</b>	[-01] =	CAN master function, CAN master cycle 1
	[-02] =	CANopen absolute encoder, CANopen absolute encoder, CAN master cycle 2
<b>Factory setting</b>	All { 0 }	
<b>Description</b>	In this parameter, the cycle time for the CAN/CANopen master mode and to the CANopen encoder is set (see <b>P503/ P514/ P515</b> ).	
	Depending on the baud rate which is set, there are different minimum values for the actual cycle time:	
	<b>Baud rate</b>	<b>Minimum value t<sub>z</sub></b> <b>Default CAN Master</b> <b>Default CANopen Abs.</b>
	10 kBaud	10 ms                    50 ms                    20 ms
	20 kBaud	10 ms                    25 ms                    20 ms
	50 kBaud	5 ms                      10 ms                    10 ms
	100 kBaud	2 ms                      5 ms                      5 ms
	125 kBaud	2 ms                      5 ms                      5 ms
	250 kBaud	1 ms                      5 ms                      2 ms
	500 kBaud	1 ms                      5 ms                      2 ms
1000 kBaud	1 ms                      5 ms                      2 ms	
<b>Note</b>	The range of values which can be set is between 0 and 100ms. With the setting {0} "Auto" the default value (see table) is used. In this setting the monitoring function for the CANopen absolute encoder is no longer triggered at 50 ms but rather at 150 ms.	

P553		PLC set values		
<b>Setting range</b>	0 ... 57			
<b>Arrays</b>	[-01] = PLC setpoint 1	[-02] = PLC setpoint 2	[-03] = PLC setpoint 3	
	[-04] = PLC setpoint 4	[-05] = PLC setpoint 5		
<b>Factory setting</b>	All { 0 }			
<b>Description</b>	Assignment of functions for the various PLC control bits.			
<b>Note</b>	Condition: <b>P350 = 1</b> and <b>P351 = 0</b> or <b>1</b> .			
<b>Setting values</b>	Value	Meaning	Value	Meaning
	0	Off	18	Curve control
	1	Setpoint frequency	19	Set Relais, "Output status" (as for <b>P541</b> )
	2	Torque current limit <b>P112</b>		
	3	PID current freq.	20	Set Analog Out (as for <b>P542</b> )
	4	Frequency addition	21	Reserved POSICON
	5	Frequency subtract.	...	
	6	Current limit <b>P536</b>	24	
	7	Maximum frequency <b>P105</b>	46	Setval.torque p.reg., "Setpoint torque process controller"
	8	PID ltd.current.freq		
	9	PID suprvsd.cur.freq	47	Reserved POSICON
	10	Servo-Mode Torque <b>P300</b>	48	Motor temperature
	11	Pre-tension Torque <b>P214</b>	49	Ramp time (acceleration / deceleration)
	12	Reserved	53	d-corr. F Process
	13	Multiplication	54	d-corr. Torque
	14	Cur.val process ctrl	55	d-corr. F+Torque
	15	Nom.val process ctrl	56	Acceleration time
	16	Add. process control	57	Deceleration time
	17	BusIO In Bits 0-7		

P554		Min. chopper Chop.		S
<b>Setting range</b>	65 ... 102 %			
<b>Factory setting</b>	{ 65 }			
<b>Description</b>	"Minimum chopper threshold". Adjustment of the switching threshold of the brake chopper.			
<b>Note</b>	<p>An increase in this setting leads to a faster overvoltage FI switch off.</p> <p>For applications where pulsating energy is returned (crank drives) the braking resistor power dissipation can be minimised by increasing this setting.</p> <p>In case of an FI error the brake chopper is generally disabled.</p>			
<b>Setting values</b>	Value	Meaning		
	65 ... 100	Brake chopper switching threshold.		
	101	In case of an FI error the brake chopper is always disabled. Monitoring is also active if the FI is not enabled. Chopper activation at 65%, e.g. in the event of an increase in the link circuit voltage due to a mains fault.		
	102	Chopper always switched on, except for active chopper overcurrent (error <b>E003.4</b> ).		

P555	P chopper limit		S
<b>Setting range</b>	5 ... 100 %		
<b>Factory setting</b>	{ 100 }		
<b>Description</b>	<p>"Chopper power limit". With this parameter it is possible to program a manual (peak) power limit for the braking resistor. The switch-on delay (modulation level) for the chopper can only rise to a certain maximum specified limit. Once this value has been reached, irrespective of the level of the link circuit voltage, the inverter switches off the current to the resistor.</p> <p>The result would be an overvoltage switch-off of the FI.</p>		
	$k[\%] = \frac{R * P_{\max BW}}{U_{\max}^2} * 100\%$		
	The correct percentage value is calculated as follows:		
	R =	Resistance of the braking resistor	
	P <sub>maxBW</sub> =	Momentary peak power of the braking resistor	
	U <sub>max</sub> =	FI chopper switching threshold	
		1~ 115/230 V	⇒ 440 V =
		3~ 230 V	⇒ 500 V =
		3~ 400 V	⇒ 1000 V =
P556	Braking resistor		S
<b>Setting range</b>	1 ... 400 Ω		
<b>Factory setting</b>	{ 120 }		
<b>Description</b>	Value of the braking resistor for calculation of the maximum brake power in order to protect the resistor.		
<b>Note</b>	Once the maximum continuous output <b>P557</b> including overload (200 % für 60 s) is reached, an I <sup>2</sup> t limit error <b>E003.1</b> is triggered. For further details see <b>P737</b> .		
P557	Brake resistor type		S
<b>Setting range</b>	0.00 ... 320 kW		
<b>Factory setting</b>	{ 0.00 }		
<b>Description</b>	Continuous power (nominal power) of the resistor, to display the actual utilisation in <b>P737</b> . For a correctly calculated value, the correct value must be entered into <b>P556</b> and <b>P557</b> .		
<b>Setting values</b>	0.00    Monitoring disabled		

P558		Flux delay		S	P
Setting range	0, 1, 2... 5000 ms				
Factory setting	{ 1 }				
Description	ASM	The ISD control can only function correctly if there is a magnetic field in the motor. For this reason, a DC current is applied before starting the motor to provide excitation of the stator winding. The duration depends on the size of the motor and is automatically set in the factory setting of the FI. For time-critical applications the flux delay can be set or disabled.			
	PMSM	When used with PMSM, the dwell time can be set via this parameter during rotor position identification using the dwell method. Total dwell duration = 2.5 x P558 [ms]			
Note	Setting values that are too low can reduce the dynamics and starting torque.				
Setting values	Value		Meaning		
	0	Switched off			
	1	Automatic calculation			
	2 ... 5000	Time set in [ms]			
P559		DC Run-on time		S	P
Setting range	0.00 ... 30.00 sec				
Factory setting	{ 0.50 }				
Description	<p>After a stop signal and elapse of the brake ramp, direct current is applied to the motor for a short time. This should completely stop the drive. Depending on the inertia, the time for which the current is applied can be set in this parameter.</p> <p>The current level depends on the previous braking procedure (current vector control) or the static boost (linear characteristic).</p>				
Note	This function is not possible in closed-loop mode with PMSM!				
P560		Parameter, Saving mode		S	
Setting range	0 ... 2				
Factory setting	{ 1 }				
Description	<i>"Parameter saving mode"</i> .				
Note	If BUS communication is used to implement parameter changes, it must be ensured that the maximum number of write cycles to the EEPROM (100,000 x) is not exceeded.				
Setting values	Value		Meaning		
	0	Only in RAM	Changes to the parameter settings are not written to the EEPROM. All saved settings which were made before changing the saving mode are retained, even if the FI is disconnected from the mains.		
	1	RAM and EEPROM	All parameter changes are automatically written to the EEPROM and remain stored there even if the FI is disconnected from the mains supply.		
	2	OFF	Saving in RAM <u>and</u> EEPROM not possible. (No parameter changes are adopted)		

P583	Motor phase sequence		S	P
<b>Setting range</b>	0 ... 2			
<b>Factory setting</b>	{ 0 }			
<b>Description</b>	The motor phase control sequence (U – V – W) can be changed with this parameter. This enables the direction of rotation of the motor to be changed without changing the motor connections.			
<b>Note</b>	If there is a voltage on the output terminals (U – V – W) (e.g. on enabling) the parameter setting or the parameter set may be changed by setting parameter <b>P583</b> . Otherwise the frequency inverter switches off with error message <b>E016.2</b> .			
<b>Setting values</b>	<b>Value</b>		<b>Meaning</b>	
	0	Normal	No change	
	1	Inverted	"Invert motor phase sequence" The direction of rotation of the motor is changed. The counting direction of the encoder for speed detection (if present) remains unchanged.	
	2	Inverted by encoder	As for setting {1}, however in addition the counting direction of the encoder is changed.	

### 5.1.8 Positioning

Parameter group P6xx is used to adjust the POSICON positioning control. A detailed description of these parameters can be found in manual [BU 0610](#).

### 5.1.9 Information

<b>P700</b>	<b>Actual operating status</b>		
<b>Display range</b>	0.0 ... 99.9		
<b>Arrays</b>	[-01] = Actual error	Indicates the presently active (unacknowledged) fault.	
	[-02] = Actual warning	Indicates a present warning message.	
	[-03] = Reason for switch-on inhibit	Indicates the reason for active switch-on inhibit.	
	[-04] = Extended actual error (DS402)	Displays the present active error according to DS402 terminology.	
<b>Description</b>	Messages (coded) for the actual operating status of the frequency inverter such as faults, warnings or the cause of a switch-on inhibit (Chap. 6.2 "Messages").		
<b>Note</b>	Display of bus-level error messages is in decimal integer format. The displayed value must be divided by 10 in order to correspond with the correct format. Example: Display: 20 → Error number: 2.0		
	The error number range from 50.0 to 99.9 displays messages from any extension modules. The meaning of these numbers is explained in the relevant documentation for the extension module.		
<b>P701</b>	<b>Last fault</b>		
<b>Display range</b>	0.0 ... 999.9		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Last fault 1 ... 10". This parameter stores the last 10 faults (Chap. 6.2 "Messages").		
<b>P702</b>	<b>Freq. last error</b>		<b>S</b>
<b>Display range</b>	-400.0 ... 400.0 Hz		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Frequency last error 1 ... 10". This parameter stores the output frequency that was being delivered at the time the fault occurred. The values of the last 10 errors are stored.		
<b>P703</b>	<b>Current last error</b>		<b>S</b>
<b>Display range</b>	0.0 ... 500 A		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Current last error 1 ... 10". This parameter stores the output current that was being delivered at the time the fault occurred. The values of the last 10 errors are stored.		



<b>P704</b>	<b>Volt. last error</b>		<b>S</b>
<b>Display range</b>	0... 500 V AC		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Last voltage error 1 ... 10". This parameter stores the output voltage that was being delivered at the time the fault occurred. The values of the last 10 errors are stored.		
<b>P705</b>	<b>Dc.Ink volt. last er.</b>		<b>S</b>
<b>Display range</b>	0 ... 1000 V DC		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Link circuit voltage last error 1 ... 10". This parameter stores the link circuit voltage that was being delivered at the time the error occurred. The values of the last 10 errors are stored.		
<b>P706</b>	<b>P set last error</b>		<b>S</b>
<b>Display range</b>	0 ... 3		
<b>Arrays</b>	[-01] ... [-10]		
<b>Description</b>	"Parameter set last error 1 ... 10". This parameter stores the parameter set code that was active when the error occurred. Data for the previous 10 faults are stored.		
<b>P707</b>	<b>Software version</b>		
<b>Display range</b>	0.0 ... 9999.9		
<b>Arrays</b>	[-01] = IO Version	[-02] = IO Revision	
	[-03] = IO Special version	[-04] = RG Version	
	[-05] = RG Revision	[-06] = RG Special version	
	[-07] = IO Loader Version	[-08] = RG Loader Version	
	[-09] = FW update File version		
<b>Description</b>	"Software version / Revision". This parameter shows the software and revision numbers in the FI. This can be significant when different FIs are assigned the same settings. Array [-03] provides information about any special versions of the hardware or software. A zero stands for the standard version.		

<b>P708</b>	<b>Digital input status</b>					
<b>Display range</b>	0000 ... 1FFF (hex)					
<b>Arrays</b>	[-01] = Status of digital inputs of the frequency inverter [-02] = Status of digital inputs of extension modules					
<b>Description</b>	"State of digital inputs". Displays the status of the digital inputs in hexadecimal code.					
		Bits 15-12	Bits 11-8	Bits 7-4	Bits 3-0	
<b>Minimum value</b>	0000	0000	0000	0000	0000	Binary <b>0</b> hex
<b>Maximum value</b>	0001	1111	1111	1111	1111	Binary <b>1</b> <b>F</b> hex
<b>Display values</b>	<b>Array [-01]</b>			<b>Array [-02]</b>		
	<b>Value</b>	<b>Meaning</b>		<b>Value</b>	<b>Meaning</b>	
	Bit 0	Digital input 1 (DI1)		Bit 0	Bus / 1st IOE Dig In1	
	Bit 1	Digital input 2 (DI2)		Bit 1	Bus / 1st IOE Dig In2	
	Bit 2	Digital input 3 (DI3)		Bit 2	Bus / 1st IOE Dig In3	
	Bit 3	Digital input 4 (DI4)		Bit 3	Bus / 1st IOE Dig In4	
	Bit 4	Digital input 5 (DI5)		Bit 4	Bus / 2nd IOE Dig In1	
	Bit 5	Digital input 6 (DI6) <sup>1)</sup>		Bit 5	Bus / 2nd IOE Dig In2	
	Bit 6	Digital input 7 (DI7) <sup>2)</sup>		Bit 6	Bus / 2nd IOE Dig In3	
	Bit 7	Digital input 8 (DI8) <sup>2)</sup>		Bit 7	Bus / 2nd IOE Dig In4	
	Bit 8	Digital input 9 (DI9) <sup>2)</sup>				
	Bit 9	Digital input 10 (DI10) <sup>2)</sup>				
	Bit 10	Safety digital input 11 (DI11) <sup>3)</sup>				
	Bit 11	Reserve				
	Bit 12	Digital function, analog input 1 (AI1)				
	Bit 13	Digital function, analog input 2 (AI2)				

- 1) SK 530P and higher
- 2) Only with CU5-MLT
- 3) For SK 510P, SK 540P and SK 530P, SK 550P with CU5-MLT

<b>P709</b>		<b>V/C analog inputs</b>	
<b>Display range</b>	-100.0 ... 100.0 %		
<b>Arrays</b>	[-01] = Analog input 1	Analogue input 1 (AI1) integrated into the FI	
	[-02] = Analog input 2	Analogue input 2 (AI2) integrated into the FI	
	[-03] = Ext. analog input 1	"External analog input 1". Analogue input 1 of first IO extension	
	[-04] = Ext. analog input 2	"External analog input 2". Analogue input 2 of first IO extension	
	[-05] = Ext. A. in.1 2.IOE	"External analog input 1 of 2nd IOE". Analogue input 1 of second I/O extension	
	[-06] = Ext. A. in.1 2.IOE	"External analog input 2 of the 2nd IOE". Analogue input 2 of second I/O extension	
	[-07] = Reserve		
	[-08] = Reserve		
	[-09] = Clock input 1		
	[-10] = Reserve		
<b>Scope of application</b>	[-01] ... [-02]	<b>SK 500P and higher</b>	
	[-03] ... [-10]	<b>SK 530P and higher</b>	
<b>Description</b>	"Voltage of analog inputs". Displays the measured customer unit input value.		
<b>Note</b>	100 % = 10.0 V or 20.0 mA		
<b>P710</b>		<b>V/I analogue outputs</b>	
<b>Display range</b>	0 ... 100 %		
<b>Arrays</b>	[-01] = Analogue output	Analogue output (AO) integrated in the FI	
	[-02] = Reserved		
	[-03] = First IOI	"External analogue output of first IOE". Analogue input of the first IO extension	
	[-04] = Second IOE	"External analogue output of second IOE": Analogue output of the first IO extension	
<b>Scope of Application</b>	[-01]	<b>SK 500P and higher</b>	
	[-02] ... [-04]	<b>SK 530P and higher</b>	
<b>Description</b>	„Analogue output voltage“. Displays the delivered value of analogue output.		
<b>Note</b>	100 % = 10.0 V or 20.0 mA		

P711	Digital output status					
<b>Display range</b>	0000 ... 0FFF					
<b>Description</b>	"State of digital outputs". Displays the status of the digital outputs in hexadecimal code.					
		Bits 15-12	Bits 11-8	Bits 7-4	Bits 3-0	
<b>Minimum value</b>	0000	0000	0000	0000	0000	Binary <b>hex</b>
	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	
<b>Maximum value</b>	0000	1111	1111	1111	1111	Binary <b>hex</b>
	<b>0</b>	<b>F</b>	<b>F</b>	<b>F</b>	<b>F</b>	
<b>Setting values</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>		
	Bit 0	Multi-function relay 1 (K1)	Bit 7	Digital output 6 (DO2) <sup>2)</sup>		
	Bit 1	Multi-function relay 2 (K2)	Bit 8	Analogue output 1 (AO1) - digital function AO1		
	Bit 2	Digital output 1 (DO1) <sup>1)</sup>	Bit 9	Reserved		
	Bit 3	Digital output 2 (DO2) <sup>1)</sup>	Bit 10	Digital output 1/1.IOE		
	Bit 4	Digital output 3 (DO3) <sup>2)</sup>	Bit 11	Digital output 2/1.IOE		
	Bit 5	Digital output 4 (DO4) <sup>2)</sup>	Bit 12	Digital output 1/2.IOE		
	Bit 6	Digital output 5 (DO5) <sup>2)</sup>	Bit 13	Digital output 2/2.IOE		

1) SK 530P and higher  
2) For SK 530P and higher with SK CU5-MLT

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P712	Energy consumption
<b>Display range</b>	0.00 ... 19 999 999.99 kWh
<b>Description</b>	Displays the energy consumption (cumulative energy consumption over the life of the FI).

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P713	Braking resistor energy
<b>Display range</b>	0.00 ... 19 999 999.99 kWh
<b>Description</b>	"Energy output via braking resistor". Displays the energy consumption of the braking resistor (cumulative energy consumption over the life of the device).

P714	Operating time
<b>Display range</b>	0.00 ... 19999999.99 h
<b>Description</b>	Duration of the device's operational readiness and availability of mains voltage (cumulative value over the service life of the device).

P715	Running time
<b>Display range</b>	0.00 ... 19999999.99 h
<b>Description</b>	Period of time during which the device was enabled and delivered power at the output (cumulative value over the service life of the device).

 **Information**

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P716</b>	<b>Actual frequency</b>			
<b>Display range</b>	-400.0 ... 400.0 Hz			
<b>Description</b>	Displays the actual output frequency.			

 **Information**

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P717</b>	<b>Actual speed</b>			
<b>Display range</b>	-9999 ... 9999 rpm			
<b>Description</b>	Displays the actual motor speed calculated by the FI.			

<b>P718</b>	<b>Current set freq.</b>			
<b>Display range</b>	-400.0... 400.0 Hz			
<b>Arrays</b>	[-01] = Actual setpoint frequency from the setpoint source			
	[-02] = Actual setpoint frequency after processing in the FI status machine			
	[-03] = Actual setpoint frequency after frequency ramp			
<b>Description</b>	Displays the frequency specified by the setpoint.			

<b>P719</b>	<b>Actual current</b>			
<b>Display range</b>	0.0... 500.0 A			
<b>Description</b>	Displays the actual output current.			

<b>P720</b>	<b>Act. torque current</b>			
<b>Display range</b>	-500.0 ... 500.0 A			
<b>Description</b>	Displays the actual calculated torque-developing output current (active current). Basis for calculation is the motor data <b>P201... P209</b> . <ul style="list-style-type: none"> <li>• Negative values = generator</li> <li>• Positive values = motor</li> </ul>			

<b>P721</b>	<b>Actual field current</b>			
<b>Display range</b>	-999.9 ... 999.9 A			
<b>Description</b>	Displays the actual calculated field current (reactive current). Basis for calculation is the motor data <b>P201 ... P209</b> .			

<b>P722</b>	<b>Actual voltage</b>			
<b>Display range</b>	0 ... 500 V			
<b>Description</b>	Displays the actual AC voltage supplied by the FI output.			
<b>P723</b>	<b>Voltage -d</b>			<b>S</b>
<b>Display range</b>	-500 ... 500 V			
<b>Description</b>	"Actual voltage component $U_d$ ". Displays the actual field voltage component.			
<b>P724</b>	<b>Voltage -q</b>			<b>S</b>
<b>Display range</b>	-500 ... 500 V			
<b>Description</b>	"Actual voltage component $U_q$ ". Displays the actual torque voltage component.			

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P725</b>	<b>Present cos phi</b>			
<b>Display range</b>	0.00 ... 1.00			
<b>Description</b>	Displays the actual calculated $\cos \varphi$ of the drive.			
<b>P726</b>	<b>Apparent power</b>			
<b>Display range</b>	0.00 ... 300.00 kVA			
<b>Description</b>	Displays the actual calculated apparent power. Basis for calculation is the motor data <b>P201 ... P209</b> .			
<b>P727</b>	<b>Mechanical Power</b>			
<b>Display range</b>	-99.99 ... 99.99 kW			
<b>Description</b>	Displays the actual calculated effective power of the motor. Basis for calculation is the motor data <b>P201 ... P209</b> .			
<b>P728</b>	<b>Input voltage</b>			
<b>Display range</b>	0 ... 1000 V			
<b>Description</b>	"Mains voltage". Displays the actual mains voltage at the FI input. This is directly determined from the amount of the intermediate circuit voltage			
<b>P729</b>	<b>Torque</b>			
<b>Display range</b>	-400 ... 400 %			
<b>Description</b>	Displays the actual calculated torque. Basis for calculation is the motor data <b>P201 ... P209</b> .			

<b>P730</b>	<b>Field</b>			
<b>Display range</b>	0 ... 100 %			
<b>Description</b>	Displays the actual field in the motor calculated by the inverter. Basis for calculation is the motor data <b>P201 ... P209</b> .			

<b>P731</b>	<b>Parameter set</b>			
<b>Display range</b>	0 ... 3			
<b>Description</b>	Displays the actual operating parameter set.			
<b>Display values</b>	<b>Value</b>	<b>Meaning</b>	<b>Value</b>	<b>Meaning</b>
	0	Parameter set 1	2	Parameter set 3
	1	Parameter set 2	3	Parameter set 4

<b>P732</b>	<b>Phase U current</b>		<b>S</b>
<b>Display range</b>	0.0 ... 999.9 A		
<b>Description</b>	Displays the actual U phase current.		
<b>Note</b>	This value can deviate from the value in <b>P719</b> due to the measurement procedure used, even with symmetrical output currents.		

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

<b>P733</b>	<b>Phase V current</b>		<b>S</b>
<b>Display range</b>	0.0 ... 999.9 A		
<b>Description</b>	Displays the actual V phase current.		
<b>Note</b>	This value can deviate from the value in <b>P719</b> due to the measurement procedure used, even with symmetrical output currents.		

<b>P734</b>	<b>Phase W current</b>		<b>S</b>
<b>Display range</b>	0.0 ... 999.9 A		
<b>Description</b>	Displays the actual W phase current.		
<b>Note</b>	This value can deviate from the value in <b>P719</b> due to the measurement procedure used, even with symmetrical output currents.		

P735	Speed encoder		S
Display range	-9999 ... 9999 rpm		
Arrays	[-01] = TTL encoder	[-03] = Sin/Cos encoder	
	[-02] = HTL encoder	[-04] = Value from speed monitor (The speed is determined by alternative measuring methods and by calculation)	
Scope of application	[-01], [-03]	SK 530P and higher	
	[-02], [-04]	SK 500P and higher	
Description	Displays the actual speed supplied by the encoder. <b>P301 / P605</b> must be set correctly, depending on the encoder which is used.		

P736	Link voltage			
Display range	0 ... 1000 V			
Description	"Link voltage". Displays the actual link circuit voltage.			

P737	Usage rate brakeres.			
Display range	0 ... 1000%			
Description	"Actual braking resistor usage rate". In generator mode, this parameter provides information about the actual usage rate of the braking resistor (on condition that <b>P556</b> and <b>P557</b> are parameterised) or the actual modulation rate of the brake chopper (on condition that <b>P557 = 0</b> ).			

P738	Usage rate motor			
Display range	0 ... 1000 %			
Arrays	[-01] = relative to $I_{Nenn}$	[-02] = relative to $I^2t$		
Description	"Actual usage rate of motor". Displays the actual motor usage. Basis for the calculation is the motor data <b>P203</b> and the current which is actually consumed.			

### Information

If the mains voltage is not connected (X1) the following parameter shows the value 0 and not the actual correct operating value.

P739	Temperature				
Display range	-40 ... 150 °C				
Arrays	[-01] = Heat sink	Actual temperature of the heat sink. This value is used for overtemperature switch-off <b>E001.0</b>			
	[-02] = Ambient temperature UZW	Actual temperature of the interior of the power section of the inverter. This value is the basis for overtemperature switch-off <b>E001.1</b> .			
	[-03] = Motor KTY:	Displays the actual motor temperature when monitoring with a temperature sensor.			
	[-04] = Microcontroller	Actual temperature of the microprocessor in the control section of the inverter. This value is the basis for overtemperature switch-off <b>E001.1</b> .			
Description	Displays the actual temperature values at various measuring points.				



**i Information**

With the following parameter **P740** arrays **[-18]** to **[-27]** do not provide the actual correct operating value unless a mains voltage is applied (X1).

P740	PZD bus in	S
<b>Display range</b>	0000 ... FFFF (hex)	
<b>Arrays</b>	[-01] = Control word	Control word, source from <b>P509</b>
	[-02] = Setpoint 1 ...	Setpoint data from main setpoint <b>P510 [-01]</b>
	[-06] = Setpoint 5	
	[-07] = Res. stat.InBit P480	The displayed value depicts all Bus In Bit sources linked with an "OR".
	[-08] = Parameter data In 1 ...	Data during parameter transfer: Order label (AK), Parameter number (PNU), Index (IND), Parameter value (PWE 1/2)
	[-12] = Parameter data In 5	
	[-13] = Setpoint 1 ...	Setpoint data ( <b>P510 [-02]</b> ) from the master function value (Broadcast) if <b>P509 = {9/10}</b>
	[-17] = Setpoint 5	
	[-18] = Control word PLC	Control word, source PLC
	[-19] = Setpoint 1 PLC ...	Setpoint data from the PLC.
	[-23] = Setpoint 5 PLC	
[-24] = Main setpoint	Main setpoint from PLC.	
		The first byte of the auxiliary control word with defined special functionalities for IO control via PLC. 0 x 01 Fixed frequency 1 0 x 02 Fixed frequency 2 0 x 04 Fixed frequency 3 0 x 08 Fixed frequency 4 0 x 10 Fixed frequency 5 0 x 20 Jog frequency 0 x 40 Maintain the freq. with motor potentiometer 0 x 80 Remove enable via analogue input
		The second byte of the auxiliary control word with defined special functionalities for IO control via PLC. 0 x 01 Fixed frequency array Bit 0 0 x 02 Fixed frequency array Bit 1 0 x 04 Fixed frequency array Bit 2 0 x 08 Fixed frequency array Bit 3 0 x 10 Fixed frequency array Bit 4 0 x 20 Motor potentiometer function activated 0 x 40 Increase motor potentiometer frequency 0 x 80 Reduce motor potentiometer frequency
	[-25] = Control byte 1 PLC	
	[-26] = Control byte 2 PLC	
	[-27] = Res: Control word FI	<i>"Resulting control word"</i> – Control word for the frequency inverter which is formed from variable control words (depending on <b>P551</b> ).
<b>Description</b>	This parameter provides information about the actual control word and the setpoints that are transferred via the bus systems.	
<b>Note</b>	For display values, a bus system must be selected in <b>P509</b> . Scaling: (Chap. 8.10 "Scaling of setpoint/actual values")	

**i Information**

With the following parameter **P741** arrays **[-07]** and **[-18]** to **[-24]** do not provide the actual correct operating value unless a mains voltage is applied (X1).

P741	PZD bus out	S
<b>Display range</b>	0000 ... FFFF (hex)	
<b>Arrays</b>	[-01] = Status word bus	Status word corresponding to selection in <b>P551</b>
	[-02] = Bus actual value 1	Actual values according to <b>P543</b>
	... ..	
	[-06] = Bus actual value 5	
	[-07] = Res.stat.OutBit <b>P481</b>	The displayed value depicts all Bus OUT Bit sources linked with an "OR".
	[-08] = Parameter data Out1	Data during parameter transfer.
	... ..	
	[-12] = Parameter data Out5	
	[-13] = Master function actual value 1	Actual value of master function <b>P502 / P503</b> .
	... ..	
	[-17] = Master function actual value 5	
	[-18] = Status word PLC	Status word via PLC
[-19] = Actual value 1 PLC	Actual value via PLC	
... ..		
[-23] = Actual value 5 PLC		
[-24] = Res: FI status word	" <i>Resulting status word</i> " – Status word from the frequency inverter.	
<b>Description</b>	This parameter provides information about the actual status word and the actual values that are transferred via the bus systems.	
<b>Note</b>	Scaling: (Chap. 8.10 "Scaling of setpoint/actual values")	

P742	Data base version	S
<b>Display range</b>	0 ... 9999	
<b>Description</b>	Displays the internal database version of the FI.	

P743	Inverter type
<b>Display range</b>	0.00 ... 250.00 kW
<b>Description</b>	Displays the rated power of the frequency inverter.

P744	Configuration	
<b>Display range</b>	0000 ... FFFF (hex)	
<b>Arrays</b>	[-01] =	Device version Display of the device version
	[-02] =	XU5 extension Displays customer unit (SK XU5-...)
	[-03] =	CU5 extension Displays customer unit (SK CU5-...)
	[-04] =	Additional interfaces Displays communication interfaces
	[-05] =	Functionalities Displays device functions
<b>Description</b>	Displays the configuration of the device.	
<b>Display values</b>	<b>Value</b>	<b>Meaning</b>
<b>Array [-01] - device version</b>		
0200	Basic	
0201	Advanced	
0202	PNT	
0203	ECT	
0204	EIP	
0205	POL	
<b>Array [-02] – XU5 extension</b>		
0000	No extension	
0001	STO	
0002	Industrial Ethernet	
<b>Array [-03] CU5 extension</b>		
0000	No extension	
0001	STO	
0002	ENC (Encoder)	
0003	MLT = (Multi IO)	
0004	RES (Resolver)	
0005	SAF (ProfiSafe module)	
0006	SS1	
<b>Array [-04] Additional interfaces</b>		
Bit 0	Interface for IOE present	
Bit 1	TTL encoder interface	
Bit 2	HTL encoder functionality for DIN	
Bit 3	RS-232/ RS-485 Diagnostic interface (RJ12)	
Bit 4	External 24V supply	
Bit 5	CAN/CANopen interface	
Bit 6	CAN absolute encoder interface (ABS)	
Bit 7	microSD card Interface	
Bit 8	USB port	
Bits 9-15	Reserved	
<b>Array [-05] Functionalities</b>		
Bit 0	POSICON functionality (POS)	
Bit 1	PLC functionality	
Bit 2	Operation of PMSM possible	
Bit 3	Operation of a reluctance motor possible (SRM)	
Bit 4 ... 15	Reserved	

<b>P745</b>	<b>Module version</b>					
<b>Display range</b>	-3276.8 ... 3276.7					
<b>Arrays</b>	[-01] = TU5 version		[-07] = XU5 version			
	[-02] = TU5 version		[-08] = XU5 version			
	[-03] = TU5 special version		[-09] = XU5 special version			
	[-04] = CU5 version		[-10] = XU5 Stack 1			
	[-05] = CU5 version		[-11] = XU5 Stack 2			
	[-06] = CU5 special version					
<b>Scope of Application</b>	[-01] ... [-03] <b>SK 500P and higher</b>					
	[-04] ... [-06] <b>SK 530P and higher</b>					
	[-07] ... [-11] <b>SK 550P and higher</b>					
<b>Description</b>	Software version for optional hardware extensions. Have this data available in case of technical queries.					
<b>P746</b>	<b>Option status</b>					<b>S</b>
<b>Display range</b>	0000 ... FFFF (hex)					
<b>Arrays</b>	[-01] = TU5		[-02] = CU5		[-03] = XU5	
<b>Scope of Application</b>	[-01] <b>SK 500P and higher</b>		[-02] <b>SK 530P and higher</b>		[-03] <b>SK 550P and higher</b>	
<b>Description</b>	Displays the actual status of the optional hardware extensions. 0 = Not ready 1 = Standby					
<b>P747</b>	<b>Inverter Volt Range</b>					
<b>Display range</b>	0 ... 3					
<b>Description</b>	"Inverter voltage range". Indicates the mains voltage range for which this device is specified.					
<b>Display values</b>	0 = 100 V.. 200 V		1 = 200 V.. 240 V		2 = 380 V.. 480 V	
	3 = 400 V.. 500 V					

P748	CANopen status			S												
<b>Display range</b>	0000 ... FFFF (hex)															
<b>Arrays</b>	[-01] = CANopen status	[-02] = Reserve	[-03] = Reserve													
<b>Description</b>	Shows the status of the system bus (CANopen).															
<b>Display values</b>	<b>Value</b>	<b>Designation</b>	<b>Meaning</b>													
	Bit 0	24 V bus supply	24 V supply (Bus) present													
	Bit 1	Bus Warning	CANbus in "Bus Warning" status													
	Bit 2	Bus Off	CANbus in "Bus Off" status													
	Bit 3	Sysbus → Bus module online	External bus module (e.g. SK TU4-...) online													
	Bit 4	Sysbus → ZBG1 online	External IO extension 1 (e.g. SK EBIOE-...) online													
	Bit 5	Sysbus → ZBG2 online	External IO extension 2 (e.g. SK EBIOE-...) online													
	Bit 6	0 = CAN / 1 = CANopen	Active protocol													
	Bit 7	Reserved														
	Bit 8	Bootsup message sent	Initialisation complete													
	Bit 9	CANopen NMT State	<table border="1"> <thead> <tr> <th>CANopen NMT State</th> <th>Bit 10</th> <th>Bit 9</th> </tr> </thead> <tbody> <tr> <td>Stopped =</td> <td>0</td> <td>0</td> </tr> <tr> <td>Pre-Operational =</td> <td>0</td> <td>1</td> </tr> <tr> <td>Operational =</td> <td>1</td> <td>0</td> </tr> </tbody> </table>	CANopen NMT State	Bit 10	Bit 9	Stopped =	0	0	Pre-Operational =	0	1	Operational =	1	0	
CANopen NMT State	Bit 10	Bit 9														
Stopped =	0	0														
Pre-Operational =	0	1														
Operational =	1	0														
	Bit 10	CANopen NMT State														
P750	Error statistics			S												
<b>Display range</b>	0 ... 9999															
<b>Arrays</b>	[-01] ... [-25]															
<b>Description</b>	Display of the error messages which have occurred during operation ( <b>P714</b> ).															
<b>Note</b>	Depending on the frequency of the errors, the entries in the arrays are displayed in descending order. Therefore Array [-01] shows the error message which has occurred most frequently.															

P751	Counter statistics	S
Display range	0 ... 9999	
Arrays	[-01] ... [-25]	
Description	Display of the frequency with which the errors according to <b>P750</b> have occurred.	
Note	The arrays of parameters <b>P750</b> and <b>P751</b> are directly related. Example: In <b>P751 [-01]</b> , the number of error messages according to <b>P750 [-01]</b> are displayed.	
P752	Last extended error	
Display range	0 ... 65535	
Arrays	[-01] ... [-10]	
Description	This parameter stores the last 10 errors from <b>P700 [4]</b>	
Note	Depending on the frequency of the errors, the entries in the arrays are displayed in descending order. Therefore Array [-01] shows the error message which has occurred most frequently.	
P780	Device id	
Display range	0 ... 9 and A ... Z (char)	
Arrays	[-01] = ... [-12]	
Description	Display of the device's serial number (12-digit)	
Note	<ul style="list-style-type: none"> <li>• Display via NORDCON: as a contiguous serial number of the device</li> <li>• Display via bus: ASCII code (decimal). Each array must be read out separately.</li> </ul>	
P799	Op.-time last error	
Display range	0.00 ... 19 999 999.99 h	
Arrays	[-01] ... [-10]	
Description	"Operating time, last fault". If a fault occurs, a time stamp is set on the basis of the operating hours counter <b>P714</b> and saved in <b>P799</b> . Array [-01]. [10] corresponds to the last faults 1 ... 10.	

### 6 Operating status messages

In case of deviations from the normal operating status, a message is output.

There are:

- **Error messages**

Faults cause the device to switch off.

- **Warning messages**

A limit value was reached. The device will continue to run.

- **Blocking message** (switch-on block)

External influences prevent the start.

The messages will be indicated as follows:

- **LED indicators**

- **Control panel** (optional)

- **Information parameter (P700)**

## 6.1 Display of messages

### LED indicators

There are two areas with LED indicators on the frequency inverter.

- The LED indicators **(1)** relate to the frequency inverter and are labelled as follows:
  - DEV: Device status
  - BUS: System bus communication status
  - USB: USB connection status
- The LED indicators **(2)** are not labelled and relate to the communication in Industrial Ethernet for the SK 550P, see [BU 0620](#).



The LED labelled "**DEV**" indicates the general device status.

Status	Meaning
Off	<ul style="list-style-type: none"> <li>• FI not ready for operation, no mains or control voltage</li> </ul>
Lights up green	<ul style="list-style-type: none"> <li>• FI is enabled</li> </ul>
Flashing green (4 Hz)	<ul style="list-style-type: none"> <li>• FI is in switch-on inhibit</li> </ul>
Flashing green (0.5 Hz)	<ul style="list-style-type: none"> <li>• FI is ready to switch-on but not enabled</li> </ul>
Flashing green (variable frequency)	<ul style="list-style-type: none"> <li>• FI works in overload range</li> <li>• Flashing sequence indicates the degree of overload</li> </ul>
Flashing green and red alternately (4 Hz)	<ul style="list-style-type: none"> <li>• Warning</li> </ul>
Flashing red (2 Hz/ 1 Hz)	<ul style="list-style-type: none"> <li>• Output of the error group (e.g. 3x flashing = error group E003).</li> </ul>
Flashing green and red	<ul style="list-style-type: none"> <li>• FI in Update mode</li> </ul>
Flashing green and red simultaneously	<ul style="list-style-type: none"> <li>• Update data are communicated</li> </ul>



The LED labelled “**BUS**” indicates the status of communication at the system bus level.

Status	Meaning
Off	<ul style="list-style-type: none"> <li>No process data communication</li> </ul>
Lights up green	<ul style="list-style-type: none"> <li>Process data communication active</li> </ul>
Flashing green (4 Hz)	<ul style="list-style-type: none"> <li>Bus warning</li> </ul>
Flashing red (4 Hz)	<ul style="list-style-type: none"> <li>Monitoring error P120 or P513 (E10.0/E10.9)</li> </ul>
Flashing red (1 Hz)	<ul style="list-style-type: none"> <li>Field bus interface telegram timeout (E10.2/E10.3)</li> </ul>
Lights up red	<ul style="list-style-type: none"> <li>System bus in state “Bus off”</li> </ul>

The LED labelled “**USB**” indicates the status of the USB connection.

Status	Meaning
Orange off	<ul style="list-style-type: none"> <li>USB driver in PC not correctly initialised</li> </ul>
Orange lights up	<ul style="list-style-type: none"> <li>USB connection active</li> </ul>
Lights up red	<ul style="list-style-type: none"> <li>USB connection error</li> </ul>

### ControlBox Display

The ControlBox displays an error with its number and the prefix "E". In addition, the present fault can be displayed in array element [-01] of parameter (P700). The last error messages are stored in parameter (P701). Further information about the frequency inverter status at the moment of the fault can be obtained from parameters (P702) to (P706) / (P799)

If the cause of the error is no longer present, the error display in the ControlBox flashes and the error can be acknowledged with the Enter key.

In contrast, warning messages are prefixed with "C" ("Cxxx") and cannot be acknowledged. They disappear automatically when the reason for them is no longer present or the frequency inverter has switched to the "Error" state. Display of the message is suppressed if the warning appears during parameterisation.

The present warning message can be displayed in detail at any time in array element [-02] of parameter (P700).

The reason for an existing disabled switch on cannot be displayed with the ControlBox.


## ParameterBox display

The ParameterBox displays the messages in plain text.

## Control panel

The following options are available:

- Mounted control panel with 7-Segment display (ControlBox SK TU5-CTR)
- Cable-connected control panel with 7-Segment display (SimpleControlBox SK CSX-3E and SK CSX-3H)
- Cable-connected control panel with plain text display (ParameterBox SK PAR-3E and SK PAR-3H)

	ControlBox SK TU5-CTR	SimpleControlBox SK CSX-3E/H	ParameterBox SK PAR-3E/H
<b>Fault</b>			
Labelling	e.g. E001.1	e.g. E001	E.g. "Inverter overtemp"
Actual fault details	P700 [-01]	P700 [-01]	P700 [-01]
Last faults	P701 [-01] ... [-05]	P701 [-01] ... [-05]	P701 [-01] ... [-05]
Additional information on last faults	P702 to P706/ P799, each [-01] ... [-05]	P702 to P706/ P799, each [-01] ... [-05]	P702 to P706/ P799, each [-01] ... [-05]
Acknowledgement	The fault display flashes if the fault is no longer present. Acknowledge the message with the Enter or OK key.		
<b> WARNING</b>			
<b>Automatic starting</b>			
The device may be started and therefore start the drive and the connected machinery on acknowledgement of the message. This can result in severe or fatal injuries.			
<ul style="list-style-type: none"> <li>• Secure the drive against movement (e.g. by mechanical blocking).</li> <li>• Ensure that there are no persons within the area of action and the danger area of the system.</li> </ul>			
<b>Warnings (only displayed as long as the cause is present.)</b>			
Labelling	e.g. C001.1	e.g. C001	E.g. "Inverter overtemp"
Details	P700 [-02]	P700 [-02]	P700 [-02]
<b>Blocking message (switch-on block)</b>			
Labelling	Underscores flash slowly	No display	"Disable voltage from IO"
Details	P700 [-03]	P700 [-03]	P700 [-03]

### 6.2 Messages

#### Error messages

Display in the SimpleBox / ControlBox		Fault Text in the ParameterBox	Cause • Remedy
Group	Details in P700 [-01] / P701		
E001	1.0	<b>Inverter overtemp.</b>	Temperature monitoring of the inverter Temperature range has been exceeded or undershot. <ul style="list-style-type: none"> <li>• Reduce or increase ambient temperature</li> <li>• Check fan or cabinet ventilation</li> <li>• Check the device for dirt</li> </ul> Further notes: <ul style="list-style-type: none"> <li>• see (<b>P739</b>) for temperature display</li> </ul>
E001	1.1	<b>Intern. inverter temp</b>	Temperature monitoring of the inverter Temperature range has been exceeded or undershot. <ul style="list-style-type: none"> <li>• Reduce or increase ambient temperature</li> <li>• Check fan or cabinet ventilation</li> <li>• Check the device for dirt</li> </ul> Further notes: <ul style="list-style-type: none"> <li>• see (<b>P739</b>) for temperature display</li> </ul>
E002	2.0	<b>Motor overtemp.PTC</b>	Motor temperature sensor (PTC resistor), the separate PTC resistor input (X4) or KTY / PT1000 have triggered at the analogue input (P400 = 48) <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Increase motor speed</li> <li>• Install external motor fan or check the function</li> </ul> Further notes: <ul style="list-style-type: none"> <li>• Check parameter setting (<b>P425</b>)</li> </ul>
E002	2.1	<b>Motor overtemp.I<sup>2</sup>t</b>	The inverter has detected an impermissible motor temperature (motor I <sup>2</sup> t). <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Increase motor speed</li> <li>• Repeat stator resistance measurement (Chap. 5.1.4 "Motor data / characteristic curve parameters")</li> </ul>
E002	2.2	<b>Overtemp. DIN</b>	The digital input function <b>P420 / P480 {13}</b> "PTC resistor input" has triggered. The digital input is "low". <ul style="list-style-type: none"> <li>• Check connection and thermostat</li> </ul>

E003	3.0	<b>Overcurrent I<sup>2</sup>t lim.</b>	<p>The current limit (I<sup>2</sup>t) has been exceeded (e.g more than 1.5x the rated current for 60 s).</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> <li>• Check rotary encoder settings (resolution, defect, connection)</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Adjust the current limit by changing the pulse frequency (<b>P504</b>).</li> </ul>
E003	3.1	<b>Overcurrent chopper</b>	<p>The current limit (I<sup>2</sup>t) of the brake chopper has been exceeded (e.g more than 1.5 x rated current for 60 s).</p> <ul style="list-style-type: none"> <li>• Avoid overcurrent in braking resistor</li> <li>• Check braking resistor values (<b>P555, P556, P557</b> and <b>P554</b>, if available)</li> </ul>
E003	3.2	<b>Overcurrent IGBT</b>	<p>The drive is running above its possible power (125% overcurrent for 50 ms).</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check the available inverter power via derating tables (e.g. increased pulse frequency)</li> </ul>
E003	3.3	<b>Overcurrent IGBT fast</b>	<p>The drive is running above its possible power (200% overcurrent).</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check available inverter power via derating tables (e.g. increased pulse frequency)</li> </ul>
E003	3.4	<b>Overcurrent chopper</b>	<p>Brake chopper current too high</p> <ul style="list-style-type: none"> <li>• Avoid overcurrent in braking resistor</li> </ul>
E003	3.7	<b>Power limit input</b>	<p>Input current too high. Continuous overload at FI Input. Shutdown for 150% overload within 60 s.</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Shortening of the shutdown time due to <ul style="list-style-type: none"> <li>– Higher loads</li> <li>– Frequent overloads</li> </ul> </li> <li>• If the mains voltage is in the lower tolerance range, the input current increases</li> </ul>

E004	4.0	<b>Module overcurrent</b>	<p>Module error (short-term)</p> <ul style="list-style-type: none"> <li>• Short circuit or earth fault at the FI output (motor cable or motor)</li> <li>• Optional braking resistor, defect/check</li> <li>• Optional motor choke, defect/check</li> </ul> <p>Further notes</p> <ul style="list-style-type: none"> <li>• Other causes of error: <ul style="list-style-type: none"> <li>– Wrong size of braking resistor</li> <li>– Motor cable too long</li> </ul> </li> <li>• For devices with Safe Pulse Block:: <ul style="list-style-type: none"> <li>– Cable resistance too high or voltage at Safe Pulse Block too low</li> </ul> </li> <li>• Do not disconnect <b>P537!</b></li> </ul> <p><b>Note: The error may significantly reduce the service life of the device or even destroy it</b></p>
E004	4.1	<b>Overcurrent measurem.</b>	<p>Pulse switch-off (<b>P537</b>) has been reached three times within 50 ms.</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Error message is only possible if (<b>P112</b>) and (<b>P536</b>) are switched off</li> <li>• Check motor data settings on the device (<b>P201 ... P209</b>) and check motor dimensioning</li> <li>• Check ramp times (<b>P102/P103</b>)</li> </ul>

E005	<b>5.0</b>	<b>Overvoltage Ud</b>	<p>DC link voltage is too high.</p> <p>→ The drive is overloaded during the braking process.</p> <p>→ The braking resistor itself or connections and cables to the braking resistor are defective.</p> <ul style="list-style-type: none"> <li>• Check dimensioning of the braking resistor</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Extend deceleration time (<b>P103</b>)</li> <li>• Extend quick stop time (<b>P426</b>)</li> <li>• Speed fluctuation (for example due to high inertia loads) → if necessary set the &lt;U/f characteristic curve (<b>P211</b>, <b>P212</b>)</li> <li>• Set switch-off mode (<b>P108</b>) with delay (not permissible for lifting equipment)</li> </ul>
E005	<b>5.1</b>	<b>Mains overvoltage</b>	<p>Mains voltage is too high.</p> <ul style="list-style-type: none"> <li>• Check if the device is suitable for electrical connection to the supply network (Chap. 7)</li> </ul>
E006	<b>6.0</b>	<b>Charging error</b>	<p>DC link voltage is too low.</p> <ul style="list-style-type: none"> <li>• Check if the device is suitable for electrical connection to the supply network (see (Chap. 7))</li> </ul>
E006	<b>6.1</b>	<b>Mains low voltage</b>	<p>Mains voltage is too low.</p> <ul style="list-style-type: none"> <li>• Check if the device is suitable for electrical connection to the supply network (see (Chap. 7))</li> </ul>
E007	<b>7.0</b>	<b>Mains Phase Failure</b>	<p>Error at mains connection side</p> <ul style="list-style-type: none"> <li>• Check all mains phases for availability (see technical data (Chap. 7))</li> <li>• Mains is asymmetrical</li> </ul>
E007	<b>7.1</b>	<b>Phasefailure dc-link</b>	<p>Mains phase error</p> <ul style="list-style-type: none"> <li>• Check all mains phases for availability (see technical data (Chap. 7))</li> </ul>
E008	<b>8.0</b>	<b>Parameter loss</b> (maximum EEPROM value exceeded)	<p>Error in EEPROM data</p> <ul style="list-style-type: none"> <li>• Software version of the stored data set not compatible with the software version of the FI</li> </ul> <p><b>Note:</b> Faulty parameters are automatically reloaded (factory setting).</p> <ul style="list-style-type: none"> <li>• EMC interferences (see also <b>E020</b>)</li> </ul>
E008	<b>8.1</b>	<b>Inverter ID error</b>	<ul style="list-style-type: none"> <li>• EEPROM faulty</li> </ul>
E008	<b>8.4</b>	<b>Internal EEPROM error</b> (Database version incorrect)	<p>The configuration of the frequency inverter was not correctly identified.</p> <ul style="list-style-type: none"> <li>• Switch the mains voltage off and on again.</li> </ul>
E008	<b>8.7</b>	<b>EEPROM copy differs</b>	<p>The configuration of the frequency inverter was not correctly identified.</p> <ul style="list-style-type: none"> <li>• Switch the mains voltage off and on again</li> </ul>
E009	<b>9.0 – 9.9</b>	<b>Communication error</b>	Reserved For SK TU5-CTR

## 6 Operating status messages

E010	10.0	<b>Bus time-out</b>	<p>Telegram time-out of bus system (CAN, CANopen, USS): Voltage supply for the bus system is missing.</p> <ul style="list-style-type: none"> <li>• Check data cable connections</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Data transfer defective Check (<b>P513</b>).</li> <li>• Check the program sequence of the bus protocol</li> <li>• Check the bus master</li> <li>• Check the 24 V supply of the internal CAN/CANopen Bus</li> <li>• Node guarding error (internal CANopen)</li> <li>• Bus-Off error (internal CANbus)</li> </ul>
E010	10.1	Reserved	
E010	10.2	<b>Bus Time-out XU5</b>	<p>Bus module telegram time-out by PLC</p> <ul style="list-style-type: none"> <li>• Telegram transmission defective</li> <li>• Check the physical bus connections</li> <li>• Check the program sequence of the bus protocol</li> <li>• Check the bus master</li> <li>• PLC is in "STOP" or "ERROR" status</li> </ul>
E010	10.3	<b>Bus Time-out XU5</b>	<p>Bus module telegram time-out by (<b>P513</b>)</p> <ul style="list-style-type: none"> <li>• Timeout triggered by parameter (<b>P513</b>).</li> </ul>
E010	10.4	<b>Init-error option</b>	<p>Bus module initialisation failure</p> <ul style="list-style-type: none"> <li>• Restart the frequency inverter (switch the power supply off and on again)</li> <li>• DIP switch of a connected I/O extension defective</li> </ul>
E010	10.5	<b>System error option</b>	<ul style="list-style-type: none"> <li>• External bus module</li> <li>• netX &amp; control system controller software not compatible</li> <li>• Error when changing the XU5 field bus protocol</li> <li>• Package length to XU5 too long</li> <li>• Condition for changing the XU5 of field bus protocol not present</li> <li>• Check whether 24 V is present on terminal X6</li> </ul>
E010	10.6	<b>Ethernet cable</b>	<ul style="list-style-type: none"> <li>• Ethernet cable not connected or connection defective</li> </ul>
E010	10.7	Reserved	
E010	10.8	<b>System bus error</b>	<ul style="list-style-type: none"> <li>• Error between bus interface and frequency inverter</li> </ul>
E010	10.9	<b>Module missingP120</b>	<p>The module stated in parameter (<b>P120</b>) is not present.</p> <ul style="list-style-type: none"> <li>• Check connections and cables on both sides</li> </ul>

E011	11.0	<b>Control terminals</b>	<p>Communication error to CU module</p> <ul style="list-style-type: none"> <li>• Internal customer unit (internal data bus) defective or interference due to radio radiation (EMC).</li> <li>• Check control connections for short circuit.</li> <li>• Minimise EMC interferences by separate routing of control and power cables.</li> <li>• Earth device and screening well.</li> </ul> <p><b>Note:</b> With this error, it may be possible that the stored position (<b>P619</b>) is no longer correct and that the rotor position may be lost with a PMSM.</p>
E011	11.1	<b>CU Not Compatible</b>	<p>The SK CU5 customer unit firmware is not compatible.</p> <ul style="list-style-type: none"> <li>• A customer unit firmware update is required.</li> </ul>
E012	12.0	<b>External watchdog</b>	<p>The “<i>Watchdog</i>” function is selected for a digital input and the pulse to the associated digital input has not been absent for longer than the time selected in parameter <b>P460</b> (“<i>Watchdog time</i>“</p> <ul style="list-style-type: none"> <li>• Check connections and digital inputs</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check setting in <b>P460</b></li> </ul>
E012	12.1	<b>Limit moto./Customer</b>	<p>The drive switch-off limit has triggered.</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check settings <b>P534 [-01]</b></li> </ul>
E012	12.2	<b>Limit gen.</b>	<p>The machine drives the motor and puts it into generator operation. The generator switch-off limit has triggered.</p> <ul style="list-style-type: none"> <li>• Reduce (generator) motor load</li> <li>• Check system for overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check settings <b>P534 [-02]</b></li> </ul>
E012	12.3	<b>Torque limit</b>	<p>A parameterised limit value for the torque has been reached.</p> <ul style="list-style-type: none"> <li>• Limit from potentiometer or setpoint source has switched off (<b>P400 = 12</b>)</li> </ul>
E012	12.4	<b>Current limit</b>	<p>Limit from potentiometer or setpoint source has switched off (<b>P400 = 14</b>).</p>
E012	12.5	<b>Load monitor</b>	<p>Switch-off due to overshooting or undershooting of permissible load torques (<b>P525 ... P529</b>) for the time set in (<b>P528</b>).</p> <ul style="list-style-type: none"> <li>• Adjust load</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Change limit values (<b>P525 ... P527</b>)</li> <li>• Increase delay time (<b>P528</b>)</li> <li>• Change monitoring mode (<b>P529</b>)</li> </ul>
E012	12.8	<b>Analog in. minimum</b>	<p>Switch-off due to undershooting of the 0 % adjustment value (<b>P402</b>) with setting (<b>P401</b>) "0-10V with switch-off on error 1" or "...2".</p>
E012	12.9	<b>Analog in. maximum</b>	<p>Switch-off due to undershooting of the 100 % adjustment value (<b>P403</b>) with setting (<b>P401</b>) "0-10V with switch-off on error 1" or "...2".</p>



E013	13.0	<b>Encoder error</b>	<p>No signal from encoder</p> <ul style="list-style-type: none"> <li>• Check connections and cables on both sides</li> <li>• Check mechanical installation of encoder</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check encoder type and parameterisation</li> <li>• Check voltage supply</li> <li>• Check cable routing (EMC)</li> <li>• After reaching a slip error the encoder does not deliver pulses (Example: the motor shaft is at a standstill)</li> </ul>
E013	13.1	<b>Speed slip error</b>	<p>The difference between measured and calculated speed has exceeded a limit value.</p> <ul style="list-style-type: none"> <li>• Check mechanical installation of encoder</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check limit values (<b>P327</b>) and (<b>P328</b>)</li> <li>• Increase acceleration times</li> </ul> <p>The inverter is in derating mode. The current required for acceleration is not available (see FAQ).</p>
E013	13.2	<b>Disconnect. control</b>	<p>The slip error switch-off monitoring has triggered. The motor could not follow the setpoint.</p> <ul style="list-style-type: none"> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check motor data (<b>P201</b> ... <b>P209</b>)</li> <li>• Check motor circuit</li> <li>• Check encoder settings (<b>P300</b>) and following in servo mode</li> <li>• Increase value for torque current limit in (<b>P112</b>)</li> <li>• Increase value for current limit in (<b>P536</b>)</li> <li>• Check deceleration time (<b>P103</b>) and extend if necessary</li> </ul>
E013	13.3	<b>Slipfault encoder</b>	<p>Incorrect direction of rotation</p> <ul style="list-style-type: none"> <li>• Check connections</li> </ul>
E013	13.4	<b>HTL slip error</b>	<p>In the operating state "Ready for switch-on" (FI not enabled), the frequency inverter has detected a speed <math>\neq 0</math> of the encoder.</p> <ul style="list-style-type: none"> <li>• Check mechanical installation of encoder</li> <li>• Check system for overload</li> <li>• Check function of the holding brake if present</li> </ul>
E013	13.5	Reserved	POSICON → error message see supplementary manual BU 0610
E013	13.6	Reserved	POSICON → error message see supplementary manual BU 0610
E013	13.8	<b>Limit switch right</b>	POSICON → error message see supplementary manual BU 0610
E013	13.9	<b>Limit switch left</b>	POSICON → error message see supplementary manual BU 0610
E014	---	Reserved	POSICON → error message see supplementary manual BU 0610
E015	---	Reserved	

E016	<b>16.0</b>	<b>Motor phase failure</b>	<p>A motor phase is not connected.</p> <ul style="list-style-type: none"> <li>• Check connections and cables on both sides</li> <li>• Check the motor</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check (<b>P539</b>)</li> </ul>
E016	<b>16.1</b>	<b>Magn. current watch</b>	<p>Required exciting current not achieved at moment of switch-on.</p> <ul style="list-style-type: none"> <li>• Check connections and cables on both sides</li> <li>• Check the motor</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check (<b>P539</b>)</li> <li>• Check motor data (<b>P201 ... P209</b>)</li> </ul>
E016	<b>16.2</b>	<b>Change phase direct.</b>	<p>The motor phase sequence (U – V – W) has been changed during operation (enable).</p> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check parameter values in (<b>P583</b>)</li> <li>• Has parameter set (<b>P100</b>) been switched over?</li> </ul>
E017	<b>17.0</b>	<b>Change assembly grp.</b>	<p>The customer unit (SK CU5-...) is not recognised by the frequency inverter.</p> <ul style="list-style-type: none"> <li>• Check the fastening of the customer unit / contacts</li> <li>• EMC faults</li> </ul> <p>Check cable shielding and earthing terminals of electrical components.</p>
E018	<b>18.0</b>	<b>Safety circuit</b>	<p>The Safe Pulse Block safety circuit has triggered during release.</p>
E018	<b>18.5</b>	<b>Safety SS1</b>	<p>The parameterised trigger time (<b>P423</b>) of the SS1-t functionality has expired. STO is triggered as the inverter still sends output pulses.</p> <p>This error cannot be acknowledged. Restart the frequency inverter (Power Off → 120 s → Power On).</p>
E018	<b>18.6</b>	<b>Safety system</b>	<p>Safety function error: This error cannot be acknowledged.</p>
E019	<b>19.0</b>	<b>Parameter ident.</b>	<p>Automatic identification of the connected motor has failed.</p> <ul style="list-style-type: none"> <li>• Check connections and cables on both sides</li> <li>• Check the motor</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check motor data (<b>P201 ... P209</b>)</li> </ul>
E019	<b>19.1</b>	<b>Rotor position</b>	<p>Incorrect result for motor position identification by test signal method.</p>
E019	<b>19.2</b>	<b>Rotor pos. North/South</b>	<p>Incorrect result for motor position identification by test signal method</p>
E022	---	Reserved	<p>PLC error message → see supplementary manual <a href="#">BU 0550</a></p>
E023	---	Reserved	<p>PLC error message → see supplementary manual <a href="#">BU 0550</a></p>
E024	---	Reserved	<p>PLC error message → see supplementary manual <a href="#">BU 0550</a></p>
E025	---	Reserved	<p>POCON → error message see supplementary manual BU 0610</p>
E026	---	<b>microSD card error</b>	<p>MicroSD card data cannot be read.</p> <ul style="list-style-type: none"> <li>• Repeat data transfer.</li> <li>• Check data format (.nsdx).</li> <li>• Use original microSD card (Part No.: 275292200).</li> </ul>

## 6 Operating status messages

E090	90.0	System error	Unknown error code from sub system. The FI has received an error code from an external unknown module. FI update required. The new, extended error code can be read from <b>P700 [-04]</b> . This allows the error to be distinguished. <ul style="list-style-type: none"> <li>Restart device</li> </ul>
E091	91.0	Update error	Update failed
E091	91.1	Update file	The update file is defective Error during identification of the update file.
E091	91.2	Update timeout	The update file transfer took too long or the connection to the PLC/PC was interrupted during the transfer.
E091	91.3	Type update file	
E099	99.0	System error	Internal error. <ul style="list-style-type: none"> <li>Restart device</li> </ul> <b>Note:</b> With this error, it may be possible that the stored position ( <b>P619</b> ) is no longer correct and that the rotor position may be lost with a PMSM.
E110	---	Reserved	Functional safety → error message see supplementary manual BU 0630
E200	---	Reserved	BUS → error message see supplementary manual BU 0620
E220	---	Reserved	BUS → error message see supplementary manual BU 0620
E299	---	Reserved	BUS → error message see supplementary manual BU 0620

### Warning messages

Display in the SimpleBox / ControlBox		Warning Text in the ParameterBox	Cause • Remedy
Group	Details in P700 [-02]		
C001	1.0	Inverter overtemp.	Temperature monitoring of the inverter Temperature range has been exceeded or undershot. <ul style="list-style-type: none"> <li>Reduce or increase ambient temperature</li> <li>Check fan or cabinet ventilation</li> <li>Check the device for dirt</li> </ul> Further notes: <ul style="list-style-type: none"> <li>see <b>P739</b> for temperature display</li> </ul>
C002	2.0	Motor overtemp. PTC	Warning from the motor temperature sensor (trigger limit reached) <ul style="list-style-type: none"> <li>Reduce motor load</li> <li>Increase motor speed</li> <li>Install external motor fan or check the function</li> </ul> Further notes: <ul style="list-style-type: none"> <li>Check parameter setting <b>P425</b></li> </ul>
C002	2.1	Motor overtemp. I <sup>2</sup> t	The inverter has detected an impermissible motor temperature (motor I <sup>2</sup> t). <ul style="list-style-type: none"> <li>Reduce motor load</li> <li>Increase motor speed</li> <li>Repeat stator resistance measurement (Chap. 5.1.4 "Motor data / characteristic curve parameters")</li> </ul>

C002	2.2	<b>Ext resistor temp.</b>	<p>Temperature sensor (e.g. braking resistor) has been triggered. The digital input is “low”.</p> <ul style="list-style-type: none"> <li>• Check connection and temperature sensor</li> </ul>
C003	3.0	<b>Overcurrent I<sup>2</sup>t lim.</b>	<p>The current limit (I<sup>2</sup>t) has been exceeded (e.g more than 1.3 x rated current for 60 s).</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> <li>• Check rotary encoder settings (resolution, defect, connection)</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Adjust the current limit by changing the pulse frequency (<b>P504</b>).</li> </ul>
C003	3.1	<b>Overcurrent chopper</b>	<p>The current limit (I<sup>2</sup>t) of the brake chopper has been exceeded (e.g more than 1.3 x rated current for 60 s).</p> <ul style="list-style-type: none"> <li>• Avoid overcurrent in braking resistor</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check braking resistor values (<b>P555, P556, P557</b> and <b>P554</b>, if available)</li> </ul>
C003	3.5	<b>Torque limit</b>	<p>The limit value of the torque generating current (parameterised, mechanical load limit) has been reached.</p> <ul style="list-style-type: none"> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check value in <b>P112</b>.</li> </ul>
C003	3.6	<b>Current limit</b>	<p>The limit value of the FI output current (parameterised FI load limit) has been reached.</p> <ul style="list-style-type: none"> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check <b>P536</b></li> </ul>
C003	3.7	<b>Real power</b>	<p>Input current too high. Drive is running at the load limit.</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Shortening of the shutdown time due to                         <ul style="list-style-type: none"> <li>- Higher loads</li> <li>- Frequent overloads</li> </ul> </li> <li>• If the mains voltage is in the lower tolerance range, the input current increases</li> </ul>
C003	3.8	<b>Total current &lt; &gt; 0</b>	<p>The total current of the three phases (L1, L2, L3) is monitored. This warning is output if a threshold value is exceeded.</p> <p>The warning indicates a defect in the current measurement hardware.</p>
C004	4.1	<b>Overcurrent measur.</b>	<p>The pulse disconnection (<b>P537</b>) has been achieved.</p> <ul style="list-style-type: none"> <li>• Reduce motor load</li> <li>• Check system for blockage or overload</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Error message is only possible if (<b>P112</b>) and (<b>P536</b>) are switched off</li> <li>• Check motor data settings on the device (<b>P201 ... P209</b>) and check motor dimensioning</li> <li>• Check ramp times (<b>P102/P103</b>)</li> </ul>

## 6 Operating status messages

C008	8.0	Parameter loss	One of the cyclically saved messages such as operating hours or enabling time could not be saved successfully. The warning expires as soon as saving can be successfully performed again.
C012	12.1	Limit moto./Customer	The motor switch-off limit is reached. <ul style="list-style-type: none"> <li>Reduce motor load</li> <li>Check system for blockage or overload</li> </ul> Further notes: <ul style="list-style-type: none"> <li>Check settings <b>P534 [-01]</b></li> </ul>
C012	12.2	Limit gen.	The machine drives the motor and puts it into generator operation. Warning: 80% of the generator switch-off limit have been reached. <ul style="list-style-type: none"> <li>Reduce (generator) motor load</li> <li>Check system for overload</li> </ul> Further notes: <ul style="list-style-type: none"> <li>Check settings <b>P534 [-02]</b></li> </ul>
C012	12.5	Load monitor	Overshooting or undershooting of permissible load torques ( <b>P525 ... P529</b> ) for half of the time set in ( <b>P528</b> ). <ul style="list-style-type: none"> <li>Adjust load</li> </ul> Further notes: <ul style="list-style-type: none"> <li>Change limit values (<b>P525 ... P527</b>)</li> <li>Increase delay time (<b>P528</b>)</li> <li>Change monitoring mode (<b>P529</b>)</li> </ul>
C025	---	Reserved	POCON → error message see supplementary manual BU 0610
C026	26.0	microSD card not inserted	<ul style="list-style-type: none"> <li>microSD card inserted incorrectly</li> <li>microSD card defective</li> </ul>
C026	26.1	Incompatible data set	<ul style="list-style-type: none"> <li>microSD card inserted incorrectly</li> <li>microSD card defective</li> </ul>
C026	26.2	MicroSD card write error	<ul style="list-style-type: none"> <li>microSD card inserted incorrectly</li> <li>microSD card defective</li> </ul>
C026	26.3	SD card not recognised	<ul style="list-style-type: none"> <li>microSD card inserted incorrectly</li> <li>microSD card defective</li> </ul>
C090	90.0	Subsystem	The FI has received a warning number from another unknown device. <ul style="list-style-type: none"> <li>Update inverter</li> </ul>
C091	91.0	FW update active	Update active Part of the inverter is in update mode.

### Switch-on block messages

Display in the SimpleBox / ControlBox	Reason: Text in the ParameterBox	Cause • Remedy
Group	Details in P700 [-03]	
I0	0.1	<b>Volt. blocked by IO</b>  The input which is parameterised with the “Voltage disable” function ( <b>P420/P480</b> ) is not set (“Low”). <ul style="list-style-type: none"> <li>Set input (“High”)</li> <li>Check connections and cables on both sides</li> </ul> Further notes: <ul style="list-style-type: none"> <li>Check parameterisation of digital functions (<b>P420/ P480</b>)</li> </ul>

IO	<b>0.2</b>	<b>Quick stop by IO</b>	<p>The input which is parameterised with the “Quick stop” function (<b>P420/P480</b>) is not set (“Low”).</p> <ul style="list-style-type: none"> <li>• Set input (“High”)</li> <li>• Check connections and cables on both sides</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Check parameterisation of digital functions (<b>P420/ P480</b>)</li> </ul>
IO	<b>0.3</b>	<b>Volt. blocked by Bus</b>	<p>If “Source control word” (<b>P509</b>) is not 0 or 1, Bit 1 is not set in the control word (“Low”).</p> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Set Bit 1 to “High” in the control word</li> </ul>
IO	<b>0.4</b>	<b>Quick stop by Bus</b>	<p>If “Source control word” (<b>P509</b>) is not 0 or 1, Bit 2 is not set in the control word (“Low”).</p> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Set Bit 2 to “High” in the control word</li> </ul>
IO	<b>0.5</b>	<b>Enable at start</b>	<p>Enable signal was already applied during the initialisation phase of the frequency inverter (mains or control voltage “ON”). Or the frequency inverter switches from the “Fault” or “Switch-on inhibit” state to the “Ready” state although the enable is still active.</p> <ul style="list-style-type: none"> <li>• Deactivate enable signal</li> </ul> <p>Further notes:</p> <ul style="list-style-type: none"> <li>• Activate “Automatic starting” (<b>P428</b>) NOTICE! Risk of injury! Drive starts up immediately!</li> <li>• Check enable signals           <ul style="list-style-type: none"> <li>– Digital inputs (<b>P420</b>)</li> <li>– BUS IO In (<b>P480</b>)</li> <li>– Control word (<b>P740</b>)</li> </ul> </li> </ul>
IO	<b>0.6</b>	<b>Volt. blocked by PLC</b>	<p>Information message for PLC → see supplementary manual <a href="#">BU 0550</a></p>
IO	<b>0.7</b>	<b>Quickstop by PLC</b>	<p>Information message for PLC → see supplementary manual <a href="#">BU 0550</a></p>
IO00	<b>0.8</b>	<b>Right dir. locked</b>	<p>Switch-on inhibit with inverter shut-off activated by:</p> <ul style="list-style-type: none"> <li>• <b>P540</b> or by “Block enable right” (<b>P420 = 31, 73</b>)</li> </ul> <p>The frequency inverter switches to “Ready to switch-on” status.</p>
IO00	<b>0.9</b>	<b>Left dir. locked</b>	<p>Switch-on inhibit with inverter shut-off activated by:</p> <ul style="list-style-type: none"> <li>• <b>P540</b> or by “Block enable left” (<b>P420 = 32, 74</b>)</li> </ul> <p>The frequency inverter switches to “Ready to switch-on” status.</p>
I6	<b>6.0</b>	<b>Charging error</b>	<p>Charging relay not energised, because:</p> <ul style="list-style-type: none"> <li>• Mains / link voltage too low</li> <li>• Mains voltage failure</li> </ul>
IO11	<b>11.0</b>	<b>Analog Stop</b>	<p>If an analogue input of the frequency inverter or connected IO extension is configured for wire break detection (2 ... 10 V signal or 4 ... 20 mA signal) the frequency inverter changes to the status “ready for switch-on” of the analogue signal undershoots the value 1 V or 2 mA.</p> <p>This also occurs if the relevant analogue input is parameterised to function “0” (no function).</p> <ul style="list-style-type: none"> <li>• Check connection</li> </ul>
IO14 <sup>1)</sup>	<b>14.4</b>	Reserved	<p>POSICon → information message see supplementary manual BU 0610</p>

## 6 Operating status messages

I018 <sup>1)</sup>	18.0	Reserved	Information message for "Safe Stop" → function, see supplementary manual
--------------------	------	----------	--

1) Indication of operating mode (message) on the *ParameterBox* or virtual operating unit of the *NORD CON-Software*: **"Not ready"**

## 7 Technical data

### 7.1 General Data

Function	Specification
Output frequency	0.0 ... 400.0 Hz
Pulse frequency	4.0 ... 16.0 kHz, standard setting = 6 kHz Power reduction > 8 kHz for 230 V device, >6 kHz for 400 V device
Typical overload capacity	150% for 60 s, 200% for 3.5 s
Efficiency	Size 1 ... 3: approx. 95 %; BG 4 ... 5: approx. 97 %
Energy efficiency	IE2 (Chap. 7.2)
Insulation resistance	> 5 MΩ
Ambient temperature	-10 °C ... +40 °C (S1-100 % ED); -10 °C ... +50 °C (S3-70 % ED 10 min)
Storage and transport temperature	-20 °C ... +60°C
Long-term storage	< 50 °C ((Chap. 9.1 "Maintenance information "))
Protection class	IP20, NEMA Open Type, NEMA 1
Max. installation altitude above sea level	Up to 1000 m: No power reduction 1000 m to 2000 m: 1 % / 100 m power reduction, overvoltage category 3 2000 m to 4000 m: 1 % / 100 m power reduction, overvoltage category 2, external overvoltage protection required at mains input
Ambient conditions	Transport (IEC 60721-3-2): Mechanical: 2M1 Operation (IEC 60721-3-3): Mechanical: 3M4 Climatic: 3K3
Waiting period between 2 x "Mains on"	60 s for all devices in normal operating cycle
Protective measures against	<ul style="list-style-type: none"> <li>• Frequency inverter overtemperature</li> <li>• Over and undervoltage</li> <li>• Short circuit, earth fault</li> <li>• Overload</li> </ul>
Regulation and control	Sensorless current vector control (ISD), linear V/f characteristic curve, VFC open-loop CFC open-loop, CFC closed-loop
Motor temperature monitoring	I <sup>2</sup> t-Motor (UL approved), PTC / Bi-metal switch
Interfaces (integrated)	RS485 (USS / Modbus RTU)   CANopen RS232 (single slave)   SK 550P and higher: PROFINET IO, USB (SK 530P and higher)   EtherCAT, Ethernet/IP, POWERLINK
Electrical isolation	Control terminals (digital and customer unit inputs)
Connection terminals	Details and tightening torques of screw terminals (Chap. 2.5.3)and (Chap. 2.5.4).
External supply voltage	18 ... 30 V DC, ≥ 800 mA
Analogue setpoint input / PID input	2 x 0 ... 10 V, 0/4...20 mA, scalable, digital 7.5 ... 30 V
Analogue setpoint resolution	12 bit based on measurement range
Setpoint consistency	analogue < 1 %, digital < 0.02 %
Digital input	5 x (2.5 V) 7.5 ... 30 V, Ri = (2.2 kΩ) 6.1 kΩ, cycle time = 1 ... 2 ms + SK 530P and higher: 1 x 7.5 30 V, Ri = 6.1 kΩ, cycle time = 1 ... 2 ms
Control outputs	2 x relay 28 VDC / 230 VAC, 2 A (output 1/2 - K1/K2) SK 530P and higher: 2 x DOUT 24 V, 20 mA
Analogue output	U = 0 ... 10 V; I = 0 ... 20 mA scaleable



## 7.2 Technical data for determining the energy efficiency level

The following tables relate to the provisions of the Ecodesign EU Regulation 2019/1781.

### Information

#### Calculation basis for the energy efficiency level

The energy efficiency specifications come from calculations according to **DIN EN 61800** “Adjustable speed electrical power drive systems – Part 9-2: Ecodesign for power drive systems, motor starters, power electronics and their driven applications – Energy efficiency indicators for power drive systems and motor starters”.

**Simplifications are included in the calculation methods of the standard!**

Manufact	FI type	Rel. losses <sup>1)</sup> (rel. motor stator frequency / rel. torque-producing current)								Standby <sup>2)</sup>	Standby <sup>2)</sup> (UKCA)	IE rating
		90/100	90/50	50/100	50/50	50/25	0/100	0/50	0/25			
Getriebebau NORD GmbH & Co. KG	SK 5xxP-	[%]	[%]	[%]	[%]	[%]	[%]	[%]	[%]	[W]	[%]	
	250-340	7,3	6,6	6,8	6,4	6,3	6,5	6,2	6,2	7,5	2,99	IE2
	370-340	6,2	5,3	5,6	5,1	5,0	5,3	5,0	5,0	7,5	2,02	IE2
	550-340	4,5	3,7	4,0	3,5	3,4	3,7	3,4	3,4	7,5	1,36	IE2
	750-340	3,9	2,9	3,4	2,8	2,6	3,1	2,7	2,5	7,5	1,00	IE2
	111-340	4,1	3,1	3,5	2,9	2,6	3,2	2,7	2,6	7,1	0,65	IE2
	151-340	3,7	2,6	3,1	2,4	2,2	2,8	2,3	2,1	7,1	0,47	IE2
	221-340	3,3	2,2	2,7	2,0	1,8	2,4	1,9	1,7	7,1	0,32	IE2
	301-340	3,3	2,2	2,6	2,0	1,7	2,3	1,8	1,6	7,9	0,26	IE2
	401-340	3,6	2,5	3,0	2,3	2,0	2,7	2,2	1,9	7,9	0,20	IE2
	551-340	3,0	1,9	2,4	1,7	1,5	2,1	1,6	1,4	7,9	0,14	IE2
	751-340	2,9	2,0	2,7	1,9	1,7	2,7	1,9	1,6	9,6	0,13	IE2
	112-340	3,1	2,1	3,0	2,0	1,7	2,9	2,0	1,7	10,6	0,10	IE2
	152-340	2,7	1,7	2,5	1,7	1,4	2,5	1,6	1,4	15,0	0,09	IE2
	182-340	2,9	1,9	2,8	1,8	1,5	2,7	1,8	1,5	15,0	0,08	IE2
222-340	2,8	1,8	2,7	1,7	1,4	2,7	1,7	1,4	15,0	0,08	IE2	

1) Power losses in % of the rated apparent output power

2) Standby losses in % of the rated output power

Manuf	FI type	Output power	Indicative output power	Rated output current	Max. operating temperature	Rated input frequency	Rated input voltage range
Getriebebau NORD GmbH & Co. KG	<b>NORDAC PRO SK 5xxP-</b>	[kVA]	[kW]	[A]	[°C]	[Hz]	[V]
	250-340	0,5	0,25	0,8	40	50	380 V – 480 V
	370-340	0,7	0,37	1,1	40	50	380 V – 480 V
	550-340	1,0	0,55	1,5	40	50	380 V – 480 V
	750-340	1,3	0,75	2,0	40	50	380 V – 480 V
	111-340	1,7	1,10	2,6	40	50	380 V – 480 V
	151-340	2,3	1,50	3,5	40	50	380 V – 480 V
	221-340	3,3	2,20	5,0	40	50	380 V – 480 V
	301-340	4,4	3,00	6,7	40	50	380 V – 480 V
	401-340	5,9	4,00	8,9	40	50	380 V – 480 V
	551-340	7,9	5,50	12,1	40	50	380 V – 480 V
	751-340	10,0	7,50	15,1	40	50	380 V – 480 V
	112-340	14,4	11,00	21,9	40	50	380 V – 480 V
	152-340	19,5	15,00	29,6	40	50	380 V – 480 V
	182-340	23,9	18,50	36,3	40	50	380 V – 480 V
222-340	28,3	22,00	42,9	40	50	380 V – 480 V	

### 7.3 Electrical data

The following tables contain the data which is relevant for UL

Details of UL- / CSA approval conditions can be found in Section "UL and CSA approval". Use of mains fuses which are faster than those stated is permissible.

By use of a mains choke, the input current is reduced to approximately the value of the output current (Chap. 2.4.1.1 "Mains choke SK CI5").

#### 7.3.1 Electrical data 230 V

Device type		SK 5xxP	-250-123-	-370-123-	-550-123-	-750-123-							
		Size	1	1	1	1							
Nominal motor power (4-pole standard motor)	230 V		0.25 kW	0.37 kW	0.55 kW	0.75 kW							
	240 V		1/3 hp	1/2 hp	3/4 hp	1 hp							
Mains voltage	230 V		1 AC 200 ... 240 V, ± 10 %, 47 ... 63 Hz										
Input current	rms		4.2 A	5.2 A	6.5 A	8.5 A							
	FLA		4.1 A	5.1 A	6.4 A	8.3 A							
Output voltage	230 V		3 AC 0 – Mains voltage										
Output current	rms		1.7 A	2.4 A	3.2 A	4.2 A							
	FLA		1.7 A	2.4 A	3.1 A	4.1 A							
Min. braking resistor	Accessories		240 Ω	190 Ω	140 Ω	100 Ω							
Pulse frequency	Range		4 – 16 kHz										
	Factory setting		6 kHz										
Max. ambient temperature	S1		40°C	40°C	40°C	40°C							
	S3 70 %, 10 min.		50°C	50°C	50°C	50°C							
Type of ventilation			Free convection		Fan cooling, temperature-controlled switching thresholds: <sup>1)</sup> ON = 57 °C, OFF = 47 °								
			<b>General fuses (AC) (recommended)</b>										
Slow-blowing			6 A	6 A	10 A	10 A							
			<b>UL fuses (AC) UL approved</b>										
			<b>Fuse Type</b>		<b>I<sub>sc</sub> kA <sup>2)</sup></b>								
240 V	410 V	480 V	715 V	Class	CB	SIBA 50 215 26	SIBA 20 028 20	5	20				
x				J					x	6 A	8 A	10 A	15 A
x					x				x	15 A	15 A	15 A	20 A
	x					x			x	15 A	20 A	–	–
	x						x		x	–	–	25 A	35 A

1) Short test run after connection of the mains voltage

2) Maximum permissible mains short circuit current with mains

Device type		SK 5xxP	-111-123-	-151-123-	-221-123-								
		Size	2	2	2								
Nominal motor power (4-pole standard motor)	230 V		1.1 kW	1.5 kW	2.2 kW								
	240 V		1.5 hp	2 hp	3 hp								
Mains voltage	230 V	1 AC 200 ... 240 V, ± 10 %, 47 ... 63 Hz											
Input current	rms		12.7 A	16.8 A	22.4 A								
	FLA		12.4 A	16.5 A	22.0 A								
Output voltage	230 V	3 AC 0 – Mains voltage											
Output current	rms		5.7 A	7.3 A	9.6 A								
	FLA		5.6 A	7.2 A	9.5 A								
Min. braking resistor	Accessories		75 Ω	62 Ω	46 Ω								
Pulse frequency	Range	4 – 16 kHz											
	Factory setting	6 kHz											
Max. ambient temperature	S1		40°C	40°C	40°C								
	S3 70 %, 10 min		50°C	50°C	50°C								
Type of ventilation		Fan, temperature controlled switching thresholds: <sup>1)</sup> ON = 57 °C, OFF = 47 °											
<b>General fuses (AC) (recommended)</b>													
Slow-blowing			16 A	20 A	20 A								
		<b>Fuse Type</b>	<i>I<sub>sc</sub></i> kA <sup>2)</sup>		<b>UL fuses (AC) UL approved</b>								
240 V	480 V	410 V	715 V	Class	CB	SIBA 50 215 26	SIBA 20 028 20	5	20				
x				J					x	20 A	25 A	30 A	
		x					x	x		50 A	70 A	90 A	
x					x			x		25 A	30 A	30 A	

1) Short test run after connection of the mains voltage

2) Maximum permissible mains short circuit current with mains

**7.3.2 Electrical data 400 V**

Device type		SK 5xxP...	-250-340-	-370-340-	-550-340-	-750-340-	-111-340-								
		Size	1	1	1	1	2								
Nominal motor power (4-pole standard motor)	400 V		0.25 kW	0.37 kW	0.55 kW	0.75 kW	1.1 kW								
	480 V		1/3 hp	1/2 hp	3/4 hp	1 hp	1 1/2 hp								
Mains voltage	400 V	EN: 3 AC 380 ... 480 V, -20 % / +10 %, 47 ... 63 Hz UL: 3 AC 380Y/220...480Y/277V -20%/+10% 47-63Hz													
Input current	rms		1.1 A	1.3 A	1.8 A	2.3 A	3.3 A								
	FLA		1.0 A	1.2 A	1.7 A	2.1 A	3.0 A								
Output voltage	400 V	3 AC 0 – Mains voltage													
Output current	rms		1.0 A	1.3 A	1.8 A	2.4 A	3.1 A								
	FLA		0.9 A	1.2 A	1.6 A	2.2 A	2.9 A								
Min. braking resistor	Accessories		390 Ω	390 Ω	390 Ω	300 Ω	220 Ω								
Pulse frequency	Range	4 – 16 kHz													
	Factory setting	6 kHz													
Max. ambient temperature	S1		40°C	40°C	40°C	40°C	40°C								
	S3 70 %, 10 min.		50°C	50°C	50°C	50°C	50°C								
Type of ventilation			Free convection		Fan, temperature controlled Switching thresholds: <sup>1)</sup> ON = 57 °C, OFF = 47 °C										
			<b>General fuses (AC) (recommended)</b>												
Slow-blowing			6 A	6 A	6 A	6 A	6 A								
			<b>UL fuses (AC) UL approved</b>												
		<b>Fuse Type</b>	<b>I<sub>sc</sub> kA<sup>2)</sup></b>												
240 V AC	480 V AC	410 V DC	715 V DC	Class	CB	SIBA 50 215 26	SIBA 20 028 20	5	20						
	x			J						x	6 A	6 A	6 A	6 A	10 A
	x				x					x	15 A	15 A	15 A	15 A	15 A
			x			x				x	10 A	10 A	10 A	10 A	–
			x				x	x			–	–	–	–	35 A

1) Short test run after connection of the mains voltage

2) Maximum permissible mains short circuit current with mains

– Not available!

Device type		SK 5xxP...	-151-340-	-221-340-	-301-340-	-401-340-	-551-340-		
		Size	2	2	3	3	3		
Nominal motor power (4-pole standard motor)	400 V	400 V	1.5 kW	2.2 kW	3.0 kW	4.0 kW	5.5 kW		
	480 V	480 V	2 hp	3 hp	4 hp	5 hp	7.5 hp		
Mains voltage	400 V	400 V	EN: 3 AC 380 ... 480 V, -20 % / +10 %, 47 ... 63 Hz UL: 3 AC 380Y/220...480Y/277V -20%/+10% 47-63Hz						
Input current	rms		4.3 A	6.6 A	8.4 A	10.8 A	14.9 A		
	FLA		4.0 A	6.1 A	7.7 A	9.9 A	13.7 A		
Output voltage	400 V		3 AC 0 – Mains voltage						
Output current	rms		4.0 A	5.6 A	7.5 A	9.5 A	12.5 A		
	FLA		3.7 A	5.2 A	7.0 A	8.9 A	11.6 A		
Min. braking resistor	Accessories		180 Ω	130 Ω	91 Ω	74 Ω	60 Ω		
Pulse frequency	Range		4 – 16 kHz						
	Factory setting		6 kHz						
Ambient temperature	S1		40°C	40°C	40°C	40°C	40°C		
	S3 70 %, 10 min.		50°C	50°C	50°C	50°C	50°C		
Type of ventilation			Fan, temperature controlled Switching thresholds: <sup>1)</sup> ON = 57 °C, OFF = 47 °C						
			<b>General fuses (AC) (recommended)</b>						
Slow-blowing			6 A	10 A	10 A	16 A	16 A		
			<b>UL fuses (AC) UL approved</b>						
			<b>Fuse Type</b>		<b>I<sub>sc</sub> kA<sup>2)</sup></b>				
240 V AC	480 V AC	410 V DC	715 V DC	Class	CB	SIBA 50 215 26	SIBA 20 028 20	5	20
	x			J				x	
	x			RK5				x	
	x				x			x	
		x				x	x		
						x	x		
								10 A	15 A
								15 A	25 A
								25 A	30 A
								30 A	30 A
								35 A	35 A
								60 A	60 A
								60 A	60 A

1) Short test run after connection of the mains voltage

2) Maximum permissible mains short circuit current with mains

– Not available!

Device type		SK 5xxP...	-751-340-	-112-340-	-152-340-	-182-340-	-222-340-							
		Size	4	4	5	5	5							
Nominal motor power (4-pole standard motor)	400 V		7.5 kW	11 kW	15 kW	18.5 kW	22 kW							
	480 V		10 hp	15 hp	20 hp	25 hp	30 hp							
Mains voltage	400 V		EN: 3 AC 380 ... 480 V, -20 % / +10 %, 47 ... 63 Hz UL: 3 AC 380Y/220...480Y/277V -20%/+10% 47-63Hz											
Input current	rms		20.5 A	29.1 A	40.4 A	48.5 A	59.1 A							
	FLA		18.8 A	26.7 A	37.0 A	44.5 A	54.2 A							
Output voltage	400 V		3 AC 0 – Mains voltage											
Output current	rms		16.0 A	24.0 A	31.0 A	38.0 A	46.0 A							
	FLA		14.9 A	21.0 A	27.0 A	34.0 A	40.0 A							
Min. braking resistor	Accessories		44 Ω	29 Ω	23 Ω	18 Ω	15 Ω							
Pulse frequency	Range		4 – 16 kHz											
	Factory setting		6 kHz											
Ambient temperature	S1		40°C	40°C	40°C	40°C	40°C							
	S3 70 %, 10 min.		50°C	50°C	50°C	50°C	50°C							
Type of ventilation			Fan, temperature controlled Switching thresholds: <sup>1)</sup> ; ON = 57 °C, OFF = 47 °C											
			<b>General fuses (AC) (recommended)</b>											
Slow-blowing			25 A	35 A	50 A	50 A	63 A							
			<b>UL fuses (AC) UL approved</b>											
		<b>Fuse Type</b>	<b>I<sub>sc</sub> kA <sup>2)</sup></b>											
240 V AC	480 V AC	410 V DC	715 V DC	Class	CB	SIBA 50 215 26	SIBA 20 028 20	5	20					
	x			J				x		75 A	100 A	–	–	–
	x				X			x		75 A	100 A	125 A	125 A	125 A

1) Short test run after connection of the mains voltage


2) Maximum permissible mains short circuit current with mains

– Not available!

## 8 Additional information

### 8.1 Setpoint processing

Representation of the setpoint processing.








Illustration 7: Setpoint processing

## 8.2 Process controller

The process controller is a PI controller which can be used to limit the controller output. In addition, the output is scaled as a percentage of a master setpoint. This provides the option of controlling any downstream drives with the master setpoint and readjusting using the PI controller.







Figure 8: Process controller flow diagram

8.2.1 Process controller application example



## 8.2.2 Process controller parameter settings

**Example: SK 500P, setpoint frequency: 50 Hz, control limits: +/- 25%,**

$$P105 \text{ (maximum frequency) [Hz]} \geq \text{Setpoint freq. [Hz]} + \left( \frac{\text{Setpoint freq. [Hz]} \times P415[\%]}{100\%} \right)$$

$$\text{Example: } \geq 50\text{Hz} + \frac{50\text{Hz} \times 25\%}{100\%} = \mathbf{62.5\text{Hz}}$$

P400 [-01] (Function analogue input): **"4"** (frequency addition)

P411 (setpoint frequency) [Hz] Set frequency with 10 V at analogue input 1

Example: **50 Hz**

P412 (Process controller setpoint): CR middle position / Default setting **5 V** (adjust if necessary)

P413 (P-controller) [%]: Factory setting **10 %** (adjust if necessary)

P414 (I-controller) [% / ms]: recommended **100%/s**

P415 (limitation +/-) [%] Controller limitation (see above)

**Note:**

In the function process controller, parameter P415 is used as a controller limiter downstream from the PI controller. This parameter therefore has a double function.

Example: **25 %** of setpoint

P416 (ramp before controller) [s]: Factory setting **2s** (if necessary, adjust to match control behaviour)

P420 (Function digital input 1): **"1"** Enable right

P400 [-02] (Function analogue input **"14"** actual value PID process controller 2):

### 8.3 Electromagnetic compatibility (EMC)

If the device is installed according to the recommendations in this manual, it meets all EMC directive requirements, as per the EMC product standard EN 61800-3.

#### 8.3.1 General Provisions

As of July 2007, all electrical equipment which has an intrinsic, independent function and which is sold as an individual unit for end users, must comply with Directive 2004/108/EEC (formerly Directive EEC/89/336). There are three different ways for manufacturers to indicate compliance with this directive:

1. *EU Declaration of Conformity*

This is a declaration from the manufacturer, stating that the requirements in the applicable European standards for the electrical environment of the equipment have been met. Only those standards which are published in the Official Journal of the European Community may be cited in the manufacturer's declaration.

2. *Technical documentation*

Technical documentation can be produced which describes the EMC characteristics of the device. This documentation must be authorised by one of the "Responsible bodies" named by the responsible European government. This makes it possible to use standards which are still in preparation.

3. *EU Type test certificate*

This method only applies to radio transmitter equipment.

The devices only have an intrinsic function when they are connected to other equipment (e.g. to a motor). The base units cannot therefore carry the CE mark that would confirm compliance with the EMC directive. Precise details are therefore given below about the EMC behaviour of this product, based on the proviso that it is installed according to the guidelines and instructions described in this documentation.

The manufacturer can certify that his equipment meets the requirements of the EMC directive in the relevant environment with regard to their EMC behaviour in power drives. The relevant limit values correspond to the basic standards EN 61000-6-2 and EN 61000-6-4 for interference immunity and interference emissions.

#### 8.3.2 EMC evaluation

Two standards must be observed when evaluating electromagnetic compatibility.

1. **EN 55011 (environmental standard)**

In this standard, the limit values are defined in dependence on the basic environment in which the product is operated. A distinction is made between two environments, where the **first environment** describes the non-industrial **living and business area** without its own high-voltage or medium-voltage distribution transformers. The **second environment** defines **industrial areas**, which are not connected to the public low-voltage network, but have their own high-voltage or medium-voltage distribution transformers. The limit values are subdivided into **classes A1, A2 and B**.

2. **EN 61800-3 (product standard)**

In this standard, the limit values are defined in dependence on the usage area of the product. The limit values are subdivided into **categories C1, C2, C3 and C4**, where class C4 basically only applies to drive systems with higher voltage ( $\geq 1000$  V AC) or higher current ( $\geq 400$  A). However, class C4 can also apply to the individual device if it is incorporated in complex systems.

The same limit values apply to both standards. However, the standards differ with regard to an application that is extended in the product standard. The operator decides which of the two standards applies, whereby the environmental standard typically applies in the event of a fault remedy.

The main connection between the two standards is explained as follows:

Category according to EN 61800-3	C1	C2	C3
Limit value class according to EN 55011	B	A1	A2
Operation permissible in			
First environment (living environment)	X	X <sup>1)</sup>	-
Second environment (industrial environment)	X	X <sup>1)</sup>	X <sup>1)</sup>
Note required in accordance with EN 61800-3	-	<sup>2)</sup>	<sup>3)</sup>
Distribution channel	Generally available	Limited availability	
EMC expertise	No requirements	Installation and commissioning by EMC expert	

1) Device used neither as a plug-in device nor in moving equipment

2) "The drive system can cause high-frequency interference in a living environment that may make interference suppression measures necessary."

3) "The drive system is not intended for use in a public low-voltage network that feeds residential areas."

**Table 11: EMC comparison between EN 61800-3 and EN 55011**

### 8.3.3 EMC of device

#### NOTICE

#### EMC interference to the environment

This device produces high-frequency interference, which may make additional suppression measures necessary in domestic environments (Chap. 8.3.2 "EMC evaluation").

- Use of shielded motor cables is essential in order to comply with the specified radio interference suppression level.



#### Information

#### EMC kits

To reduce EMC interference according to the EMC Directive, so-called EMC kits may be used, which can be mounted on the appropriate places on the frequency inverter .

The device is exclusively intended for commercial use. It is therefore not subject to the requirements of the standard EN 61000-3-2 for radiation of harmonics.

The limit value classes are only achieved if

- the wiring is EMC-compliant
- the length of shielded motor cable does not exceed the permissible limits

The motor cable shielding must be connected to both sides (frequency inverter shield bracket and the metal motor terminal box). Depending on the inverter version (...-A or ...-O) and according to the type and use of mains filters or chokes, different permissible motor cable lengths result for compliance with the declared limit value classes.

### Information

For connection of shielded motor cables with a length > 30 m, in particular with low power frequency inverters the current monitoring may trigger, so that use of an output choke (SK CO5...) is also necessary.

Device type	Conducted emissions 1 150 kHz – 30 MHz	
	Class C2	Class C1
SK 5xxP-250-123-A ... SK 5xxP-550-123-A	20 m	-
SK 5xxP-750-123-A ... SK 5xxP-221-123-A	20 m	5 m
SK 5xxP-250-340-A ... SK 5xxP-550-340-A	20 m	-
SK 5xxP-750-340-A ... SK 5xxP-551-340-A	20 m	5 m
SK 5xxP-751-340-A ... SK 5xxP-112-340-A	In preparation	
SK 5xxP-152-340-A ... SK 5xxP-222-340-A	In preparation	

**Table 12: EMC, max. shielded motor cable length with regard to compliance with the limit value classes**

EMC overview of standards that are used in accordance with EN 61800-3 as checking and measuring procedures:		
<i>Interference emission</i>		
Cable-related emission (interference voltage)	EN 55011	C2
		C1
Radiated emission (interference field strength)	EN 55011	C2
		-
<i>Interference immunity EN 61000-6-1, EN 61000-6-2</i>		
ESD, discharge of static electricity	EN 61000-4-2	6 kV (CD), 8 kV (AD)
EMF, high frequency electro-magnetic fields	EN 61000-4-3	10 V/m; 80 – 1000 MHz
Burst on control cables	EN 61000-4-4	1 kV
Burst on mains and motor cables	EN 61000-4-4	2 kV
Surge (phase-phase / phase-ground)	EN 61000-4-5	1 kV / 2 kV
Cable-led interference due to high frequency fields	EN 61000-4-6	10 V, 0.15 – 80 MHz
Voltage fluctuations and drops	EN 61000-2-1	+10 %, -15 %; 90 %
Voltage asymmetries and frequency changes	EN 61000-2-4	3 %; 2 %

**Table 13: Overview according to product standard EN 61800-3**





Figure 9: Wiring recommendation



8.3.4 Declarations of Conformity

## GETRIEBEBAU NORD

Member of the NORD DRIVESYSTEMS Group



---

Getriebebau NORD GmbH & Co. KG  
Getriebebau-Nord-Str. 1 . 22941 Bargteheide, Germany . Fon +49(0)4532 289 - 0 . Fax +49(0)4532 289 - 2253 . Info@nord.com C310601\_0122

---

### EU Declaration of Conformity

In the meaning of the EU directives 2014/35/EU Annex IV, 2014/30/EU Annex II, 2009/125/EG Annex IV and 2011/65/EU Annex VI

---

Getriebebau NORD GmbH & Co. KG as manufacturer in sole responsibility hereby declares,

Page 1 of 1

that the variable speed drives of the product series NORDAC PRO

- **SK 500P-xxx-123-.-.. , SK 500P-xxx-340-.-..**  
(xxx= 250, 370, 550, 750, 111, 151, 221, 301, 401, 551, 751, 112, 152, 182, 222)  
also in these functional variants:  
**SK 510P-... , SK 530P-... , SK 540P-... , SK 550P-...**

and the further options/accessories:  
**SK TU5-... , SK CU5-... , SK PAR-3. , SK CSX-3. , SK SSX-3A, SK POT1-.. , SK EBIOE-2, SK EBGR-1, SK TIE5-BT-STICK, SK EMC5-.. , SK DRK5-.. , SK BRU5-.-... , SK BR2-... , SK CI5-... , SK CO5-... , HLD 110-500/..**

comply with the following regulations:

<b>Low Voltage Directive</b>	<b>2014/35/EU</b>	OJ. L 96 of 29.3.2014, p. 357–374
<b>EMC Directive</b>	<b>2014/30/EU</b>	OJ. L 96 of 29.3.2014, p. 79–106
<b>Ecodesign Directive</b>	<b>2009/125/EG</b>	OJ. L 285 of 31.10.2009, p. 10–35
<b>Regulation (EU) Ecodesign</b>	<b>2019/1781</b>	OJ. L 272 of 25.10.2019, p. 74–94
<b>RoHS Directive</b>	<b>2011/65/EU</b>	OJ. L 174 of 1.7.2011, p. 88–11
<b>Delegated Directive (EU)</b>	<b>2015/863</b>	OJ. L 137 of 4.6.2015, p. 10–12


**Applied standards:**

EN 61800-5-1:2007+A1:2017	EN 61800-3:2018	EN 61800-9-1:2017
EN 60529:1991+A1:2000+A2:2013+AC:2016	EN 63000:2018	EN 61800-9-2:2017


It is necessary to notice the data in the operating manual to meet the regulations of the EMC-Directive. Specially take care about correct EMC installation and cabling, differences in the field of applications and if necessary original accessories.

First marking was carried out in 2019.




**Bargteheide, 07.01.2022**



U. Küchenmeister  
Managing Director



pp F. Wiedemann  
Head of Inverter Division

<h1 style="margin: 0;">NORD GEAR LIMITED</h1> <p style="margin: 0;">Member of the NORD DRIVESYSTEMS GROUP</p>									
<p>NORD Gear Limited 11 Barton Lane, Abingdon, Oxfordshire, United Kingdom OX14 3NB   Tel. No.: +44 1235 534404   Email: GB-Sales@nord.com</p> <p style="text-align: right;">DoC number C350601_0821_EN_UKCA</p>									
	<h2 style="margin: 0;">Declaration of Conformity</h2>								
<p>NORD Gear Limited hereby declares under sole responsibility that the product series as originally delivered:</p> <p><b>SK 500P-xxx-123-.-., SK 500P-xxx-340-.-.</b>                  (xxx = 250, 370, 550, 750, 111, 151, 221, 301, 401, 551, 751)                  also in functional variants:  <b>SK 510P-.-., SK 530P-.-., SK 540P-.-., SK 550P-.-.</b></p> <p>and further options/accessories:  <b>SK TU5-.-., SK CU5-.-., SK PAR-3., SK CSX-3., SK SSX-3A, SK POT-., SK EBIOE-2, SK EBGR-1,                  SK TIES-BT-STICK, SM EMC5-., SK DRK5-., SK BRU5-.-., SK BR2-.-., SK CI5-.-., SK CO5-.-.,                  HLD 110-500/..</b></p> <table border="1" style="width: 100%; border-collapse: collapse; font-size: x-small;"> <tr> <td style="width: 50%; padding: 5px;">                     complies with the following statutory requirements and carries the UKCA marking accordingly:                 </td> <td style="width: 50%; padding: 5px;">                     and conforms with the following designated standards:                 </td> </tr> <tr> <td style="padding: 5px;">                     Electrical Equipment (Safety) Regulations S.I. 2016/1101 (as amended)                 </td> <td style="padding: 5px;">                     EN 61800-5-1:2007+A1:2017                      EN 61800-9-1:2017                      EN 61800-9-2:2017                      EN 60529:1991+A1:2000+A2:2013+AC:2016                 </td> </tr> <tr> <td style="padding: 5px;">                     Electromagnetic Compatibility Regulations S.I. 2016/1091 (as amended)                 </td> <td style="padding: 5px;">                     EN 61800-3:2004+A1:2012+AC:2014                 </td> </tr> <tr> <td style="padding: 5px;">                     Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations S.I. 2012/3032 (as amended)                 </td> <td style="padding: 5px;">                     BS EN IEC 63000:2018                 </td> </tr> </table> <p>According to the EMC directive, the listed devices are not independently operable products, they are intended for installation in machines. Compliance to the directive requires the correct installation of the product, it is necessary to take notice of the data and safety instructions in the installation and operating manual. Specifically take care regarding the correct EMC installation and cabling requirements.</p>		complies with the following statutory requirements and carries the UKCA marking accordingly:	and conforms with the following designated standards:	Electrical Equipment (Safety) Regulations S.I. 2016/1101 (as amended)	EN 61800-5-1:2007+A1:2017 EN 61800-9-1:2017 EN 61800-9-2:2017 EN 60529:1991+A1:2000+A2:2013+AC:2016	Electromagnetic Compatibility Regulations S.I. 2016/1091 (as amended)	EN 61800-3:2004+A1:2012+AC:2014	Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations S.I. 2012/3032 (as amended)	BS EN IEC 63000:2018
complies with the following statutory requirements and carries the UKCA marking accordingly:	and conforms with the following designated standards:								
Electrical Equipment (Safety) Regulations S.I. 2016/1101 (as amended)	EN 61800-5-1:2007+A1:2017 EN 61800-9-1:2017 EN 61800-9-2:2017 EN 60529:1991+A1:2000+A2:2013+AC:2016								
Electromagnetic Compatibility Regulations S.I. 2016/1091 (as amended)	EN 61800-3:2004+A1:2012+AC:2014								
Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations S.I. 2012/3032 (as amended)	BS EN IEC 63000:2018								
<p>Abingdon, 07.04.2021</p>  <p><b>Andrew Stephenson</b> Managing Director</p>									

### 8.4 Reduced output power

The frequency inverters are designed for special overload situations. For example, 1.5x overcurrent can be used for 60 s. For approx. 3.5 s, 2x overcurrent is possible. A reduction of the overload capacity or its duration must be considered for the following circumstances:

- Output frequencies < 4.5 Hz and DC voltage (stationary pointer)
- Pulse frequencies greater than the nominal pulse frequency (P504)
- Increased mains voltages > 400 V
- Increased heat sink temperature

The following characteristic curves can be used to obtain the corresponding current/power limit.

#### 8.4.1 Increased heat dissipation due to pulse frequency

This illustration shows how the output current must be reduced, depending on the pulse frequency for 230V and 400V devices, in order to avoid excessive heat dissipation in the frequency inverter.

For 400V devices, the reduction begins at a pulse frequency above 6kHz. For 230V devices, the reduction begins at a pulse frequency above 8kHz.

The diagram shows the possible current load capacity for continuous operation.




Figure 10: Heat losses due to pulse frequency

### 8.4.2 Reduced overcurrent due to time

The possible overload capacity changes depending on the duration of an overload. Several values are cited in this table. If one of these limiting values is reached, the frequency inverter must have sufficient time (with low utilisation or without load) in order to regenerate itself.

If operated repeatedly in the overload region at short intervals, the limiting values stated in the tables are reduced.


<b>230V devices:</b> Reduced overload capacity (approx.) due to pulse frequency (P504) and time						
Pulse frequency [kHz]	Time [s]					
	> 600	60	30	20	10	3.5
3...8	110%	150%	170%	180%	180%	200%
10	103%	140%	155%	165%	165%	180%
12	96%	130%	145%	155%	155%	160%
14	90%	120%	135%	145%	145%	150%
16	82%	110%	125%	135%	135%	140%

<b>400V devices:</b> Reduced overload capacity (approx.) due to pulse frequency (P504) and time						
Pulse frequency [kHz]	Time [s]					
	> 600	60	30	20	10	3.5
3...6	110%	150%	170%	180%	180%	200%
8	100%	135%	150%	160%	160%	165%
10	90%	120%	135%	145%	145%	150%
12	78%	105%	120%	125%	125%	130%
14	67%	92%	104%	110%	110%	115%
16	57%	77%	87%	92%	92%	100%

Table 14: Overcurrent relative to time

### 8.4.3 Reduced overcurrent due to output frequency

To protect the power unit at low output frequencies (< 4.5 Hz, from size 4 < 7.5 Hz), monitoring is provided to determine the temperature of the IGBTs (*insulated-gate bipolar transistor*) by means of high current. A pulse disconnection (**P537**) with variable limit is introduced so that no current can be assumed above the limit shown in the diagram. At standstill with 6 kHz pulse frequency, no current can thus be assumed above 1.1x the nominal current.



The resulting upper limit values for the pulse disconnection for the various pulse frequencies can be found in the following tables. The adjustable value (10 ... 201) that can be set in parameter **P537** is limited to the value specified in the tables depending on the pulse frequency. Values below the limit can be adjusted as required.

230 V devices: Reduced overload capability (approx.) due to pulse frequency ( <b>P504</b> ) and output frequency							
Pulse frequency [kHz]	Output frequency [Hz]						
	4.5	3.0	2.0	1.5	1.0	0.5	0
3 ... 8	200%	170%	150%	140%	130%	120%	110%
10	180%	153%	135%	126%	117%	108%	100%
12	160%	136%	120%	112%	104%	96%	95%
14	150%	127%	112%	105%	97%	90%	90%
16	140%	119%	105%	98%	91%	84%	85%

400 V devices: Reduced overload capability (approx.) due to pulse frequency ( <b>P504</b> ) and output frequency							
Pulse frequency [kHz]	Output frequency [Hz]						
	4.5	3.0	2.0	1.5	1.0	0.5	0
3 ... 6	200%	170%	150%	140%	130%	120%	110%
8	165%	140%	123%	115%	107%	99%	90%
10	150%	127%	112%	105%	97%	90%	82%
12	130%	110%	97%	91%	84%	78%	71%
14	115%	97%	86%	80%	74%	69%	63%
16	100%	85%	75%	70%	65%	60%	55%

400 V devices: Reduced overload capability (approx.) due to pulse frequency (P504) and output frequency from size 4								
Pulse frequency [kHz]	Output frequency [Hz]							
	7.5	6	5	4	3	2	1	0
3 ... 6	200%	180%	170%	155%	145%	130%	120%	110%
8	169%	152%	143%	131%	122%	110%	101%	93%
10	146%	131%	124%	113%	106%	95%	87%	80%
12	128%	115%	109%	99%	93%	83%	77%	71%
14	115%	103%	97%	89%	83%	74%	69%	63%
16	103%	93%	88%	80%	75%	67%	62%	57%

Table 15: Overcurrent depending on pulse and output frequency

### 8.4.4 Reduced output current due to low voltage

The frequency inverters are thermally designed with regard to the rated output currents. For lower low voltages larger currents cannot be used in order to keep the output power constant. For mains voltages above 400 V the permissible output current is reduced inversely proportional to the mains voltage in order to compensate for switching losses.




Figure 11: Reduced output current due to low voltage

### 8.4.5 Reduced output current due to the heat sink temperature

The temperature of the heat sink is included in the calculation of the reduction of output current, so that at low heat sink temperatures, a higher load capacity can be permitted, especially for higher pulse frequencies. At high heat sink temperatures, the reduction is increased correspondingly. The ambient temperature and the ventilation conditions for the device can therefore be optimally exploited.

## 8.5 Operation on the FI circuit breaker

For devices with an active mains filter (standard configuration for TN- / TT networks) leakage currents of  $\leq 16$  mA are to be expected. These are designed for operation with leakage current circuit breakers for the protection of persons.

For devices with an inactive mains filter (special configuration for TN networks) leakage currents of  $\leq 30$  mA are to be expected. These are not suitable for operation with leakage current circuit breakers for the protection of persons.

Only all-current sensitive FI circuit breakers (type B or B+) must be used.

(Chap. 2.5.3.2 "Mains connection (PE, L1, L2/N, L3)")

( See also document [TI 800\\_00000003](#).)

## 8.6 NORD system bus

### 8.6.1 Description

Communication between the various devices from Getriebebau NORD GmbH & Co. KG (frequency inverters and optional modules) and other accessories (absolute encoders) is carried out via a separate NORD system bus. The NORD system bus is a CAN field bus; communication is via the CANopen protocol. There are restrictions for the use of the system bus interface for SK 500P and SK 510P. These can be obtained from the following table:

Function	SK 500P / SK 510P	SK 530P	SK 550P
SK EBIOE-2/CU4//TU4-IOE	No	Yes	Yes
SK CU4-TU4-PBR as PROFIBUS gateway	No	Yes	Not advisable → Industrial Ethernet on board
CANopen absolute encoders	Yes	Yes	Yes
Master function – Master - Slave	Yes	Yes	Yes
NORDCON Tunnelling	Only passive	Yes	Yes
Industrial - Ethernet gateway	slave	slave	Master



If a frequency inverter with a field bus interface (SK 550P) is connected to further devices via the system bus, these can also be indirectly integrated into the field bus communication without a separate field bus interface. Several frequency inverters can be accessed via an SK 550P.




Figure 12: Example of the structure of a NORD system bus

Item	Description
1	NORD system bus (CAN field bus)
2	SK 550P frequency inverter with field bus interface
3	Frequency inverter SK 5x0P
4	Absolute encoder
5	NORDCON computer (on Windows® based PC, on which the NORDCON parameterisation and control software is installed)
6	Field bus

### 8.6.2 NORD system bus participants


Up to 4 frequency inverters with the associated absolute encoders can be integrated into the NORD system bus. All participants on the NORD system bus must be assigned with a unique address (Node ID). The addresses of the frequency inverters are set with parameter **P515 [-01]** “CAN bus address”.

The address of connected standard absolute encoders from NORD is set via DIP switches. Absolute encoders must be assigned directly to a frequency inverter. This is carried out using the following equation:

$$\text{Absolute encoder address} = \text{CAN bus address of the frequency inverter} + 1$$

This results in the following matrix:

<b>Device</b>	FI1	AE1	FI2	AE2	...
<b>Node ID (CAN bus address)</b>	32	33	34	35	...

The termination resistor must be activated on the first and last participant in the system bus ( Frequency inverter manual). The bus speed of the frequency inverter must be set to “250 kbaud” (**P514** “CAN bus baud rate”). This also applies to any absolute encoders which are connected.

### 8.6.3 Physical structure

<b>Standard</b>	CAN
<b>Physical design</b>	2x2, twisted pair, shielded, stranded wires, wire cross-section $\geq 0.25 \text{ mm}^2$ (AWG23), surge impedance approx. $120 \Omega$
<b>Bus length</b>	max. 20 m total expansion (network), max. 20 m between 2 subscribers,
<b>Structure</b>	preferably linear
<b>Spur cables</b>	possible, (max. 6 m)
<b>Termination resistors</b>	$120 \Omega$ , 250 mW at both ends of a system bus (switchable via DIP switches)
<b>Baud rate</b>	250 kBaud

The CAN\_H and CAN\_L signals must be connected using a twisted pair of wires. The GND potentials are connected using the second pair of wires.



### 8.7 Options for optimising the energy efficiency

**⚠ WARNING**

**Unexpected movement due to overload**

In case of overload of the drive there is a risk that the motor will "break down" (sudden loss of torque). An overload may be caused e.g. by inadequate dimensioning of the drive unit or by the occurrence of sudden peak loads. Sudden peak loads may be of a mechanical origin (e.g. blockage) or may be caused by extremely steep acceleration ramps (P102, P103, P426).

Depending on the type of application, "breakdown" of the motor may cause unexpected movement (e.g. dropping of loads by lifting equipment).


To prevent any risk, the following must be observed:

- For lifting equipment applications or applications with frequent large load changes, parameter P219 must remain in the factory setting (100 %).
- Do not inadequately dimension the drive unit, provide adequate overload reserves.
- If necessary, provide fall protection (e.g. for lifting equipment) or equivalent protective measures.

NORD frequency inverters have a low power consumption and are therefore highly efficient. In addition, with the aid of "Automatic flux optimisation" (Parameter (P219)) the inverter provides a possibility for increasing the overall efficiency of the drive in certain applications (in particular applications with partial load).

According to the torque required, the magnetisation current through the frequency inverter or the motor torque is reduced to the level which is required for the momentary drive power. The resulting considerable reduction in power consumption, as well as the optimisation of the  $\cos \varphi$  factor of the motor rating in the partial load range contributes to creating optimum conditions both with regard to energy consumption and mains characteristics.



A parameterisation which is different from the factory setting (Factory setting = 100%) is only permissible for applications which do not require rapid torque changes. (For details, see Parameter (P219))



Is = Motor current vector (line current)  
 IsD = Magnetisation current vector (magnetisation current)  
 IsQ = Load current vector (load current)

Figure 13: Energy efficiency due to automatic flux optimisation

## 8.8 Motor data – characteristic curves (Asynchronous motors)

The possible characteristic curves with which the motors can be operated are explained in the following. For operation with the 50 Hz or 87 Hz characteristic curve, the name plate data of the motor is relevant (  Section ). For operation with a 100 Hz characteristic curve, the use of specially calculated motor data is required (  Section ).

### 8.8.1 50 Hz characteristic curve

(→ Adjustment range 1:10)

For 50 Hz operation, the used motor can be operated up to its rating point at 50 Hz with nominal torque. Operation above 50 Hz is possible, but causes the torque output to reduce in a non-linear manner (see diagram). Above the rating point, the motor enters its field weakening range, as the voltage cannot be increased above the value of the mains voltage if the frequency is increased above 50 Hz.




Illustration 14: Characteristic curve 50 Hz

### Information

#### Compare motor data with specifications on the name plate.

To be able to optimally adjust the frequency inverter to the motor used, the motor parameter must match with those of the motor.

- Select the motor used in the motor list in parameter **P200**. The motor list shows you all IE3 NORD motors.
- For use of IE1 or IE2 motors, but in particular for use of third-party motors, compare the motor data in the parameters **P201** ... **P209** with the specifications on the name plate and correct them if necessary.
- Finally, you must calibrate the stator resistance, see **P220**, or enter it manually in **P208**.

### 115 V / 230 V – frequency inverter

For 115 V devices, the input voltage is doubled in the device so that the required maximum output voltage of 230 V is achieved for the device.

The following data refers to a 230 V/400 V winding of the motor. It applies to IE1 and IE2 motors. Please note that these specifications may vary slightly, as the motors are subject to certain manufacturing tolerances. It is recommended to have the resistance of the connected motor calibrated by the frequency inverter (**P208 / P220**).

Motor (IE1) SK ...	Frequency inverter SK 5xxP-...	M <sub>N</sub> <sup>1)</sup> [Nm]	Motor data for parameterisation							
			F <sub>N</sub> [Hz]	n <sub>N</sub> [min-1]	I <sub>N</sub> [A]	U <sub>N</sub> [V]	P <sub>N</sub> [kW]	cos φ	Y/Δ	R <sub>St</sub> [Ω]

Notice: A comma counts as a full stop and signifies a decimal place.

71S/4	250-x23- *	1,73	50	1365	1,3	230	0,25	0,79	Δ	39,9
71L/4	370-x23- *	2,56	50	1380	1,89	230	0,37	0,71	Δ	22,85
80S/4	550-x23- *	3,82	50	1385	2,62	230	0,55	0,75	Δ	15,79
80L/4	750-x23- *	5,21	50	1395	3,52	230	0,75	0,75	Δ	10,49
90S/4	111-x23-	7,53	50	1410	4,78	230	1,1	0,76	Δ	6,41
90L/4	151-323-	10,3	50	1390	6,11	230	1,5	0,78	Δ	3,99
100L/4	221-323-	14,6	50	1415	8,65	230	2,2	0,78	Δ	2,78
100LA/4	301-323-	20,2	50	1415	11,76	230	3,0	0,78	Δ	1,71
112M/4	401-323-	26,4	50	1430	14,2	230	4,0	0,83	Δ	1,11
132S/4	551-323-	36,5	50	1450	20,0	230	5,5	0,8	Δ	0,72
132M/4	751-323-	49,6	50	1450	26,8	230	7,5	0,79	Δ	0,46
132MA/4	112-323-	60,6	50	1455	32,6	230	9,2	0,829	Δ	0,39

1) At the rating point

### 400 V frequency inverter

The following data refer to a power of 2.2 kW on a 230/400 V winding of the motor.

It applies to IE1 and IE2 motors. Please note that these specifications may vary slightly, as the motors are subject to certain manufacturing tolerances. It is recommended to have the resistance of the connected motor calibrated by the frequency inverter (**P208 / P220**).

Motor (IE1) SK ...	Frequency inverter SK 5xxP-...	$M_N$ <sup>1)</sup> [Nm]	Motor data for parameterisation							
			$f_N$ [Hz]	$n_N$ [min <sup>-1</sup> ]	$I_N$ [A]	$U_N$ [V]	$P_N$ [kW]	cos $\varphi$	Y/ $\Delta$	$R_{St}$ [ $\Omega$ ]

Notice: A comma counts as a full stop and signifies a decimal place.

80S/4	550-340-	3,82	50	1385	1,51	400	0,55	0,75	Y	15,79
80L/4	750-340-	5,21	50	1395	2,03	400	0,75	0,75	Y	10,49
90S/4	111-340-	7,53	50	1410	2,76	400	1,1	0,76	Y	6,41
90L/4	151-340-	10,3	50	1390	3,53	400	1,5	0,78	Y	3,99
100L/4	221-340-	14,6	50	1415	5,0	400	2,2	0,78	Y	2,78
100LA/4	301-340-	20,2	50	1415	6,8	400	3,0	0,78	$\Delta$	5,12
112M/4	401-340-	26,4	50	1430	8,24	400	4,0	0,83	$\Delta$	3,47
132S/4	551-340-	36,5	50	1450	11,6	400	5,5	0,8	$\Delta$	2,14
132M/4	751-340-	49,6	50	1450	15,5	400	7,5	0,79	$\Delta$	1,42
160M/4	112-340-	72,2	50	1455	20,9	400	11,0	0,85	$\Delta$	1,08
160L/4	152-340-	98,1	50	1460	28,2	400	15,0	0,85	$\Delta$	0,66
180MX/4	182-340-	122	50	1460	35,4	400	18,5	0,83	$\Delta$	0,46
180LX/4	222-340-	145	50	1460	42,6	400	22,0	0,82	$\Delta$	0,35

1) At the rating point

### 8.8.2 87 Hz characteristic curve (only 400V devices)

(→ Variation 01:17)

The 87 Hz - characteristic represents an extension of the speed adjustment range with a constant motor nominal torque. The following points must be met for realisation:

- Motor delta connection with a motor winding for 230/400 V
- Frequency inverter with an operating voltage 3~400 V
- Output current of frequency inverter must be greater than the delta current of the motor used (ref. value → frequency inverter power  $\geq \sqrt{3}$  motor power)




Figure 15: 87 Hz characteristic curve

In this configuration, the motor used has a rated operating point at 230 V/50 Hz and an extended operating point at 400 V/ 87 Hz. This increases the power of the drive by a factor of  $\sqrt{3}$ . The nominal torque of the motor remains constant up to a frequency of 87 Hz. Operation of a 230 V winding with 400 V is totally uncritical as the insulation is designed for test voltages of > 1000 V.

### Information

The following motor data apply to standard motors with a 230 V/400 V winding.

Motor (IE1) SK ...	Frequency inverter SK 5xxP-...	M <sub>N</sub> <sup>1)</sup> [Nm]	Motor data for parameterisation							
			F <sub>N</sub> [Hz]	n <sub>N</sub> [min <sup>-1</sup> ]	I <sub>N</sub> [A]	U <sub>N</sub> [V]	P <sub>N</sub> [kW]	cos φ	Y/Δ	R <sub>St</sub> [Ω]
71S/4	550-340-	1,73	50	1365	1,3	230	0,25	0,79	Δ	39,9
71L/4	750-340-	2,56	50	1380	1,89	230	0,37	0,71	Δ	22,85
80S/4	111-340-	3,82	50	1385	2,62	230	0,55	0,75	Δ	15,79
80L/4	151-340-	5,21	50	1395	3,52	230	0,75	0,75	Δ	10,49
90S/4	221-340-	7,53	50	1410	4,78	230	1,1	0,76	Δ	6,41
90L/4	301-340-	10,3	50	1390	6,11	230	1,5	0,78	Δ	3,99
100L/4	401-340-	14,6	50	1415	8,65	230	2,2	0,78	Δ	2,78
100LA/4	551-340-	20,2	50	1415	11,76	230	3,0	0,78	Δ	1,71
112M/4	751-340-	26,4	50	1430	14,2	230	4,0	0,83	Δ	1,11
132S/4	112-340-	36,5	50	1450	20,0	230	5,5	0,8	Δ	0,72
132M/4	152-340-	49,6	50	1450	26,8	230	7,5	0,79	Δ	0,46
132MA/4	182-340-	60,6	50	1455	32,6	230	9,2	0,829	Δ	0,39
160MA/4	222-340-	72,2	50	1455	37	230	11	0,85	Δ	0,36

Notice: A comma counts as a full stop and signifies a decimal place.

1) At the rating point

Motor (IE3) SK ...	Frequency inverter SK 5xxP-...	$M_N^{1)}$ [Nm]	Motor data for parameterisation							
			$F_N$ [Hz]	$n_N$ [min <sup>-1</sup> ]	$I_N$ [A]	$U_N$ [V]	$P_N$ [kW]	cos $\varphi$	Y/ $\Delta$	$R_{St}$ [ $\Omega$ ]

Notice: A comma counts as a full stop and signifies a decimal place.

63 SP/4	250-340-	0,84	50	1370	0,68	230	0,12	0,66	$\Delta$	66,7
63 LP/4	370-340-	1,24	50	1385	1,02	230	0,18	0,62	$\Delta$	39,7
71 SP/4	550-340-	1,69	50	1415	1,21	230	0,25	0,71	$\Delta$	24,0
71 LP/4	750-340-	2,51	50	1405	1,58	230	0,37	0,76	$\Delta$	17,7
80 SP/4	111-340-	3,70	50	1420	2,23	230	0,55	0,75	$\Delta$	10,4
80 LP/4	151-340-	5,06	50	1415	3,10	230	0,75	0,72	$\Delta$	6,50
90 SP/4	221-340-	7,35	50	1430	4,12	230	1,1	0,78	$\Delta$	4,16
90 LP/4	301-340-	10,1	50	1415	5,59	230	1,5	0,79	$\Delta$	3,15
100 LP/4 <sup>2)</sup>	401-340-	14,4	50	1460	8,13	230	2,2	0,76	$\Delta$	1,77
100 AP/4 <sup>2)</sup>	551-340-	19,8	50	1450	10,9	230	3,0	0,8	$\Delta$	1,29
112 MP/4	751-340-	26,5	50	1440	13,6	230	4,0	0,83	$\Delta$	0,91
132 SP/4	112-340-	35,8	50	1465	18,9	230	5,5	0,8	$\Delta$	0,503
132 MP/4	152-340-	49,0	50	1460	27,3	230	7,5	0,77	$\Delta$	0,381
160 SP/4	182-340-	59,8	50	1470	29,0	230	9,2	0,88	$\Delta$	0,295
160 MP/4	182-340-	71,7	50	1465	35,5	230	11,0	0,85	$\Delta$	0,262

1) At the rating point

2) APAB series



### 8.8.3 100 Hz characteristic curve (only 400 V devices)

(→ Variation 01:20)

An operating point 100 Hz/400 V can be selected for a greater speed adjustment range with up to a ratio of 1:20. Special motor data is required in this case (see below) that differs from the normal 50 Hz data. It must be ensured in this case that a constant torque is generated across the entire adjustment range but that it is smaller than the nominal torque for 50 Hz operation.

The advantage, in addition to the greater speed adjustment range, is the improved motor temperature behaviour. An external fan is not absolutely essential for smaller output speed ranges.




Figure 16: 100 Hz characteristic curve

**NOTE:** The following motor data applies for standard motors with a 230 / 400 V winding. It must be noted that this information may change slightly because the motors are subject to certain tolerances. It is recommended that the resistance of the connected motor is measured by the frequency inverter (P208 / P220).

Motor (IE1) SK ...	Frequency inverter SK 5xxP-...	$M_N^{1)}$ [Nm]	Motor data for parameterisation							
			$F_N$ [Hz]	$n_N$ [min <sup>-1</sup> ]	$I_N$ [A]	$U_N$ [V]	$P_N$ [kW]	cos $\varphi$	Y/ $\Delta$	$R_{St}$ [ $\Omega$ ]
63S/4	250-340-	0,90	100	2880	0,95	400	0,25	0,63	$\Delta$	47,37
63L/4	370-340-	1,23	100	2895	1,07	400	0,37	0,71	$\Delta$	39,90
71L/4	550-340-	1,81	100	2900	1,59	400	0,55	0,72	$\Delta$	22,85
80S/4	750-340-	2,46	100	2910	2,0	400	0,75	0,72	$\Delta$	15,79
80L/4	111-340-	3,61	100	2910	2,8	400	1,1	0,74	$\Delta$	10,49
90S/4	151-340-	4,90	100	2925	3,75	400	1,5	0,76	$\Delta$	6,41
90L/4	221-340-	7,19	100	2920	4,96	400	2,2	0,82	$\Delta$	3,99
100L/4	301-340-	9,78	100	2930	6,95	400	3,0	0,78	$\Delta$	2,78
100LA/4	401-340-	12,95	100	2950	7,46	400	4,0	0,76	$\Delta$	1,71
112M/4	551-340-	17,83	100	2945	11,3	400	5,5	0,82	$\Delta$	1,11
132S/4	751-340-	24,24	100	2955	16,0	400	7,5	0,82	$\Delta$	0,72
132MA/4	112-340-	35,49	100	2960	23,0	400	11,0	0,80	$\Delta$	0,39

Notice: A comma counts as a full stop and signifies a decimal place.

1) At the rating point

Motor (IE3) SK ...	Frequency inverter SK 5xxP-...	$M_N^{1)}$ [Nm]	Motor data for parameterisation							
			$F_N$ [Hz]	$n_N$ [min <sup>-1</sup> ]	$I_N$ [A]	$U_N$ [V]	$P_N$ [kW]	cos $\varphi$	Y/ $\Delta$	$R_{St}$ [ $\Omega$ ]

Notice: A comma counts as a full stop and signifies a decimal place.

63 SP/4	250-340-	0,59	100	2885	0,58	400	0,18	0,61	$\Delta$	66,7
63 LP/4	250-340-	0,82	100	2910	0,83	400	0,25	0,56	$\Delta$	39,7
71 SP/4	370-340-	1,20	100	2920	1,01	400	0,37	0,69	$\Delta$	24,0
71 LP/4	550-340-A	1,79	100	2925	1,34	400	0,55	0,72	$\Delta$	17,7
80 SP/4	750-340-A	2,44	100	2935	1,77	400	0,75	0,73	$\Delta$	10,4
80 LP/4	111-340-A	3,58	100	2930	2,13	400	1,1	0,84	$\Delta$	6,50
90 SP/4	151-340-A	4,86	100	2945	3,1	400	1,5	0,79	$\Delta$	4,16
90 LP/4	221-340-A	7,17	100	2930	4,33	400	2,2	0,83	$\Delta$	3,15
100 LP/4 <sup>2)</sup>	301-340-A	9,65	100	2970	5,79	400	3,0	0,82	$\Delta$	1,77
100 AP/4 <sup>2)</sup>	401-340-A	12,9	100	2960	7,52	400	4	0,85	$\Delta$	1,29
112 MP/4	551-340-A	17,8	100	2950	10,3	400	5,5	0,85	$\Delta$	0,91
132 SP/4	751-340-A	24,1	100	2970	14,3	400	7,5	0,83	$\Delta$	0,503
132 MP/4	112-340-A	29,6	100	2970	18	400	9,2	0,82	$\Delta$	0,381
160 SP/4	152-340-A	35,3	100	2975	21	400	11	0,85	$\Delta$	0,295
160 MP/4	152-340-A	48,2	100	2970	27,5	400	15	0,86	$\Delta$	0,262
160 LP/4	182-340-A	59,4	100	2975	34,4	400	18,5	0,85	$\Delta$	0,169
180 MP/4	222-340-A	70,4	100	2985	40,6	400	22	0,85	$\Delta$	0,101

1) At the rating point

2) APAB series

### 8.9 Motor data – characteristic curves (synchronous motors)

In the following, possible assignments of the motors and frequency inverters as well as relevant parameterisation data are listed. Only use the specifications from the tables.

Motor data					Frequency inverter SK 5xxP-...	Selection of motor data via parameter P200 Parameter value
Motor (IE4) SK ...	Y/Δ	M <sub>N</sub> <sup>1)</sup> [Nm]	P <sub>N</sub> [kW]	n <sub>N</sub> [rpm]		
80T1/4	Y	5,00	1,10	2100	-111-123-	0.75 kW 230V 80T1/4
					-111-340-	1.10 kW 400V 80T1/4
80T1/4	Δ	4,80	1,50	3000	-151-340-	1.50 kW 400V 80T1/4
90T1/4	Y	6,80	1,50	2100	-151-123-	1.10 kW 230V 90T1/4
					-151-340-	1.50 kW 400V 90T1/4
90T1/4	Δ	7,00	2,20	3000	-221-340-	2.20 kW 400V 90T1/4
90T3/4	Y	10,0	2,20	2100	-221-123-	1.50 kW 230V 90T3/4
					-221-340-	2.20 kW 400V 90T3/4
90T3/4	Δ	9,50	3,00	3000	-301-340-	3.00 kW 400V 90T3/4
100T2/4	Y	13,6	3,00	2100	-301-340-	3.00 kW 400V 100T2/4
100T2/4	Δ	12,7	4,00	3000	-401-340-	4.00 kW 400V 100T2/4
100T5/4	Y	18,2	4,00	2100	-401-340-	4.00 kW 400V 100T5/4
100T5/4	Δ	17,5	5,50	3000	-551-340-	5.50 kW 400V 100T5/4

Motor data					Frequency inverter SK 5xxP-...	Selection of motor data via parameter P200 Parameter value
Motor (IE5) SK ...	Y/Δ	M <sub>N</sub> <sup>1)</sup> [Nm]	P <sub>N</sub> [kW]	n <sub>N</sub> [rpm]		
71N1/8	Y	1,60	0,35	2100	-370-340- -550-340-	0.35 kW 400V 71N1/8
71N2/8	Y	3,20	0,70	2100	-750-340-	0.70 kW 400V 71N2/8
71N3/8	Y	4,80	1,05	2100	-111-340-	1.05 kW 400V 71N3/8
71F1/8	Y	2,00	0,50	2400	-550-340-	0.50 kW 400V 71F1/8
71F2/8	Y	4,00	1,00	2400	-111-340-	1.00 kW 400V 71F2/8
71F3/8	Y	6,00	1,50	2400	-151-340-	1.50 kW 400V 71F3/8
71F4/8	Y	8,80	2,20	2400	-221-340-	2.20 kW 400V 71F4/8
90N1/8	Y	5,00	1,10	2100	-111-340-	1.10 kW 400V 90N1/8
90N2/8	Y	6,82	1,50	2100	-151-340-	1.50 kW 400V 90N2/8
90N3/8	Y	10,0	2,20	2100	-221-340-	2.20 kW 400V 90N3/8
90F1/8	Y	6,00	1,50	2400	-151-340-	1.50 kW 400V 90F1/8
90F2/8	Y	8,80	2,20	2400	-221-340-	2.20 kW 400V 90F2/8
90F3/8	Y	11,9	3,00	2400	-301-340-	3.00 kW 400V 90F3/8
90F4/8	Y	14,7	3,70	2400	-401-340-	3.70 kW 400V 90F4/8

### 8.10 Scaling of setpoint/actual values


The following table contains details for the scaling of typical setpoint and actual values. These details relate to parameters (P400), (P418), (P543), (P546), (P740) or (P741).

Designation Setpoints {Function}	Analogue signal		Bus signal						Limit for absolu- te
	Value range	Scaling	Value range	Max. value	Type	100% =	-100% =	Scaling	
Setpoint frequency {01}	0-10V (10V=100%)	P104 ... P105 (min - max)	±100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P105	P105
Frequency addition {04}	0-10V (10V=100%)	P410 ... P411 (min - max)	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P411	P105
Frequency subtraction {05}	0-10V (10V=100%)	P410 ... P411 (min - max)	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P411	P105
Maximum frequency {07}	0-10V (10V=100%)	P411	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P411	P105
Cur.val process ctrl {14}	0-10V (10V=100%)	P105* U <sub>AIn</sub> (V)/10V	±100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P105	P105
Nom.val process ctrl {15}	0-10V (10V=100%)	P105* U <sub>AIn</sub> (V)/10V	±100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f <sub>sol</sub> [Hz]/P105	P105
Torque current limit {2}	0-10V (10V=100%)	P112* U <sub>AIn</sub> (V)/10V	0-100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	/	4000 <sub>hex</sub> * Torque [%] / P112	P112
Current limit {6}	0-10V (10V=100%)	P536* U <sub>AIn</sub> (V)/10V	0-100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	/	4000 <sub>hex</sub> * Current limit [%] / P536 * 100 [%]	P536
Ramp time {49}	0-10V (10V=100%)	P102 / P103 U <sub>AIn</sub> (V)/10V	100%	32767	INT	7FFF <sub>hex</sub> 32767 <sub>dec</sub>	/	P102 / P103 bus setpoint/4000 <sub>hex</sub>	P102 / P105
Acceleration time {56}									
Deceleration time {57}									
<b>Actual values</b> {Function}									
Actual frequency {01}	0-10V (10V=100%)	P201* U <sub>AOut</sub> (V)/10V	±100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f[Hz]/P201	
Actual speed {02}	0-10V (10V=100%)	P202* U <sub>AOut</sub> (V)/10V	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * n[rpm]/P202	
Current {03}	0-10V (10V=100%)	P203* U <sub>AOut</sub> (V)/10V	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * I[A]/P203	
Torque current {04}	0-10V (10V=100%)	P112* 100/ √((P203) <sup>2</sup> - (P209) <sup>2</sup> )* U <sub>AOut</sub> (V)/10V	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * I <sub>q</sub> [A]/((P112)*100/ √((P203) <sup>2</sup> -(P209) <sup>2</sup> )	
Setpoint frequency master value {19} ... {24}	0-10V (10V=100%)	P105* U <sub>AOut</sub> (V)/10V	±100%	16384	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * f[Hz]/P105	
Speed from encoders {22}	/	/	±200%	32767	INT	4000 <sub>hex</sub> 16384 <sub>dec</sub>	C000 <sub>hex</sub> .16385 <sub>dec</sub>	4000 <sub>hex</sub> * n[rpm] / (P201 * 60s / number of pole pairs)	

Table 16: Scaling of set/actual values (selection)

### 8.11 Definition of setpoint and actual value processing (frequencies)

The frequencies used in parameters (P502) and (P543) are processed in various ways according the following table.



Function	Name	Meaning	Output to ...			without Right/ Left	with Slip
			I	II	III		
8	Setpoint frequency	Setpoint frequency from setpoint source	X				
1	Actual frequency	Setpoint frequency for motor model		X			
23	Actual frequency with slip	Actual frequency at motor			X		X
19	Setpoint frequency master value	Setpoint frequency from setpoint source Master value (free from enable correction)	X			X	
20	Setpoint frequency n R master value	Setpoint frequency for motor model Master value (free from enable correction)		X		X	
24	Master value of actual frequency with slip	Actual frequency at motor Master value (free from enable correction)			X	X	X
21	Actual frequency without slip master value	Actual frequency without slip Master value			X		

Table 17: Processing of setpoints and actual values in the frequency inverter

## **9 Maintenance and servicing information**

### **9.1 Maintenance information**

NORD frequency inverters are *maintenance-free* in normal operation(Chap. 7 "Technical data").

#### **Dusty environments**

If the device is operated in dusty air, the cooling surfaces must be cleaned with compressed air at regular intervals.

#### **Long-term storage**



#### **Information**

---

##### **Climatic conditions for long-term storage**

- Temperature: +5 to +35°C
  - Relative humidity: < 75%
- 

The device must be connected to the supply network for at least 60 minutes each year. During this time, the device must not be loaded at either the motor or control terminals.

If these steps are not taken, this may result in destruction of the device.

## 9.2 Service notes

For service/repair cases please contact your NORD Service contact person. You will find your contact person listed on your order confirmation. Additionally you will find further possible contact persons using the following link: <https://www.nord.com/en/global/locatortool.jsp>.

When contacting our technical support please have the following information available:

- Device type (name plate/display)
- Serial number (name plate)
- Software version (parameter P707)
- Information regarding accessories and options used

If you would like to send the device in for repair please proceed as follows:

- Remove all non-original parts from the device.

NORD accepts no liability for any attached parts such as power cables, switches or external displays.

- Back up the parameter settings before sending in the device.
- State the reason for returning the component/device.
  - You can obtain a return note from our web site ([Link](#)) or from our technical support.
  - In order to rule out the possibility that the cause of a device fault is due to an optional module, the connected optional modules should also be returned in case of a fault.
- Specify a contact person for possible queries.



### Information

---

#### Factory settings of parameters

Unless otherwise agreed, the device is reset to the factory settings after inspection or repair.

---

The manual and additional information can be found on the Internet under [www.nord.com](http://www.nord.com).



### 9.3 Disposal

NORD products are made of high-quality components and valuable materials. Therefore, have faulty or defective appliances checked to see if they can be repaired and reused.

If repair and reuse is not possible, observe the following disposal notes.

#### 9.3.1 Disposal according to German law

- The components are marked with the crossed-out waste bin according to the “Electrical and Electronic Equipment Directive – ElektroG3” (dated 20 May 2021, valid from 1 January 2022).



The appliances must therefore not be disposed of as unsorted municipal waste, but must be collected separately and handed to a WEEE (Waste of Electrical and Electronic Equipment) registered collection point.

- The components do not contain any electrochemical cells, batteries or accumulators, which must be separated and disposed of separately.
- In Germany, NORD components can be handed in at the headquarters of Getriebbau NORD GmbH & Co. KG.

WEEE Reg. No.	Name of the manufacturer / authorised representative	Category	Appliance type
DE12890892	Getriebbau NORD GmbH & Co. KG	Appliances where at least one of the outer dimensions exceeds 50 cm (large appliances)	Large appliances for exclusive use in other than private households
		Appliances where none of the outer dimensions exceeds 50 cm (small appliances)	Small appliances for exclusive use in other than private households

- Contact: [info@nord.com](mailto:info@nord.com).

#### 9.3.2 Disposal outside of Germany

Outside Germany, please contact the local subsidiaries or distributors of the NORD DRIVESYSTEM Group.

## 9.4 Abbreviations

<b>AI (AIN)</b>	Analog input	<b>I/O</b>	In / Out (Input / Output)
<b>AO (AOUT)</b>	Analogue output	<b>ISD</b>	Field current (Current vector control)
<b>BR</b>	Braking resistor	<b>LED</b>	Light-emitting diode
<b>DI (DIN)</b>	Digital input	<b>PMSM</b>	Permanent Magnet Synchronous motor (permanently excited synchronous motor)
<b>DO (DOUT)</b>	Digital output	<b>S</b>	Supervisor Parameter, P003
<b>I / O</b>	Input /Output	<b>SH</b>	"Safe stop" function
<b>EEPROM</b>	Non-volatile memory	<b>SW</b>	Software version, P707
<b>EMKF</b>	Electromotive force (induction voltage)	<b>TI</b>	Technical information / Data sheet (Data sheet for NORD accessories)
<b>EMC</b>	Electromagnetic compatibility		
<b>FI-(Switch)</b>	Leakage current circuit breaker		
<b>FI</b>	Frequency inverter		

## Key word index

<b>6</b>	
6040 Controlwort (P028) .....	88
6041 Statuswort (P029).....	89
6042 Target velocity (P020) .....	87
6043 Velocity demand (P021) .....	87
6044 Control effort (P022).....	87
6046 Velocity amount (P023).....	87
6048 Velocity accele (P024).....	88
6049 Velocity decele (P025) .....	88
604A Velocity qStop (P026) .....	88
6053 Percent demand (P027) .....	88
605D Stop opt. code (P030).....	89
6060 Modes of operat (P031).....	89
6061 Modes of op.Dis (P032).....	90
6063 & 6064 Akt. Position (P046) .....	91
6065 & 6066 Slip error (P047 .....	92
6067 & 6068 target window (P048 .....	92
606B & 606C & 6069 Velocity actual (P062).96	
606D & 606E Velocity window (P063).....	97
606F & 6070 Velocity thresh (P064) .....	97
6071 Target torque (P033) .....	90
6077 Torque act val (P073).....	98
6078 Current act val (P074) .....	98
6079 DC link cir vol (P075).....	98
607A Target position (P049) .....	92
607C Homing offset (P061).....	96
607E Polarity (P050) .....	92
607F Max pro velocit (P051) .....	92
6081 Profile velocit (P052) .....	93
6083 Prof accelerat (P065).....	97
6084 Prof decelerat (P066) .....	97
6085 qStop decelerat (P067) .....	97
6086 Motion pro type (P053).....	93
6087 Torque ramp (P076).....	98
608A Pos dimension (P055).....	94
6091 Gear ratio (P056).....	94
6092 Feed constant (P057).....	94
6098 Homing method (P058) .....	95
6099 Ref. Pt. for speed (P059).....	96
609A Homing accelera (P060) .....	96
60FD Digital inputs (P034) .....	90
60FE Digital outputs (P035) .....	91
60FF Target Velocity (P072) .....	98
<b>A</b>	
Absolute min. freq. (P505).....	160
Acceleration time (P102) .....	99
Actual	
Speed (P717).....	189
Actual current (P719).....	189
Actual error (P700) .....	184
Actual error DS402(P700) .....	184
Actual field current (P721).....	189
Actual frequency (P716).....	189
Actual frequency processing .....	254
Actual operating status (P700) .....	184
Actual torque current (P720) .....	189
Actual values .....	193, 194, 253
Actual voltage (P722).....	190
Actual warning (P700).....	184
Adaptation to IT networks .....	46
Additional parameters .....	157
Adjustment range	
1/10.....	244, 247, 249
Amplification ISD control (P213).....	111
Analog input adjustment 100% (P403) .....	133
Analog input filter (P404) .....	134
Analog input function (P400) .....	128
Analog input matching 0%( P402) .....	132
Analog input mode (P401) .....	130
Analog output func. (P418).....	137
Analog output offset (P417).....	136
Analog output scal. (P419) .....	139
Apparent power (P726).....	190
Array parameters .....	68
Automatic acknowledged. (P506).....	160
Automatic flux adjustment (P219).....	113
Automatic flux optimisation .....	243
Automatic starting (P428) .....	144
<b>B</b>	
Basic parameter .....	99
Basic parameters .....	75
Boost precontrol (P215 .....	111
Brake chopper.....	33
Brake delay off (P114).....	106
Brake reaction time (P107) .....	102
Brake resistor type (P557) .....	181
Braking resistor .....	33, 219
Braking resistor (P556) .....	181
Braking resistor energy (P713).....	188
Bus actual value (P543).....	175
Bus error (P700) .....	184
Bus node .....	242
Bus set point function (P546).....	176
Bus status via PLC (P353).....	126
<b>C</b>	
Cable duct.....	28
CAN Address (P515) .....	164
CAN bus address (P515).....	242
CAN bus baud rate (P514) .....	164, 242
CAN ID .....	242
CAN master cycle (P552) .....	179
CANopen .....	240
CANopen status (P748).....	197
CE mark .....	229
Change password (P005) .....	86
Characteristic curve parameter... 107, 203, 211	
Characteristics .....	11
Charging error".....	214
Check output voltage (P539) .....	173
Choke.....	36
Configuration (P744).....	195
Control box.....	62
Control connection .....	50
Control method (P300).....	118

Control terminals .....	128	Field weakening controller I (P319) .....	120
Control voltage .....	51	Field weakening controller P (P318) .....	120
ControlBox .....	64	Field weakening limit (P320) .....	121
Copy parameter set (P101) .....	99	Fixed frequency 1 (P429) .....	144
Cos phi (P206) .....	109	Fixed frequency 2 (P430) .....	145
Counter statistics (P751) .....	198	Fixed frequency 3 (P431) .....	145
Current :DC brake (P109) .....	104	Fixed frequency 4 (P432) .....	145
Current last error (P703) .....	184	Fixed frequency 5 (P433) .....	145
Current limit (P536) .....	171	Fixed frequency array (P465) .....	150
Current set freq. (P718) .....	189	Fixed frequency mode (P464) .....	150
Current vector control .....	114	Flux delay (P558) .....	182
Curve setting .....	111, 114	Flux feedb.fact.PMSM (P333) .....	124
<b>D</b>		Flying start (P520) .....	166
Database version (P742) .....	194	Flying start offset (P522) .....	167
DC coupling .....	48	Flying start resolution (P521) .....	166
DC Run-on time (P559) .....	182	Funct-BusIO Out Bits (P481) .....	153
Deceleration time (P103) .....	100	Function Bus IO In Bits (P480) .....	152
Delivery condition .....	75	Function PTC input (P425) .....	143
Device characteristics .....	11	<b>G</b>	
Device id (P780) .....	198	Gateway .....	69
Digital inputs (P420) .....	140	<b>H</b>	
Digital output function (P434) .....	146	Heat dissipation .....	28
Digital output hysteresis (P436) .....	149	High Resistance Grounding .....	46
Digital output scaling (P435) .....	148	HRG network .....	46
Digital output status (P711) .....	188	HTL encoder .....	60
Display factor (P002) .....	86	Hysteresis switchover frequency (P332) ....	124
Disposal .....	257	<b>I</b>	
Dissipated heat .....	28	I2t motor (P535) .....	171
Drive profile (P551) .....	178	Ident startrotor pos (P330) .....	123
DS402 parameter .....	87	Immunity from interference .....	231
Dynamic boost (P211) .....	110	Incremental encoder .....	60
Dynamic braking .....	33	Incremental encoder (P301) .....	118
<b>E</b>		Information .....	184
Efficiency .....	28	Input choke .....	37
Electrical data .....	23, 24, 219	Input voltage (P728) .....	190
EMC Directive .....	229	Installation .....	28
EMF voltage PMSM (P240) .....	116	Installation altitude .....	216
Emission of interference .....	231	Internet .....	256
EN 55011 .....	229	Inverter name (P501) .....	157
EN 61000 .....	231	Inverter type (P743) .....	194
EN 61800-3 .....	229	Inverter voltage range (P747) .....	196
Encoder .....	59	ISD control .....	114
Encoder function (P325) .....	121	IT network .....	46
Encoder offset PMSM (P334) .....	124	<b>J</b>	
Energy consumption (P712) .....	188	Jog frequency (P113) .....	105
Energy Efficiency .....	243	<b>K</b>	
Enter key .....	64	KTY84-130 .....	76
Environmental standard .....	229	<b>L</b>	
Error messages .....	199	Last extended error (P752) .....	198
Error statistics (P750) .....	197	Last fault (P701) .....	184
EU Declaration of Conformity .....	229	Last frequency error (P702) .....	184
<b>F</b>		Leading func. output (P503) .....	158
Factor I <sup>2</sup> t Motor (P533) .....	170	Leakage current .....	46, 239
Factory setting (P523) .....	167	LED indicators .....	200
Fans .....	61	Lifting equipment with brake .....	102
Fault .....	199	Linear V/f characteristic curve .....	114
FI circuit breaker .....	239	Link circuit coupling .....	48
Field (P730) .....	191	Link circuit last error (P705) .....	185
Field current controller I (P316) .....	120	Link circuit voltage (P736) .....	192
Field current controller P (P315) .....	120	Load control delay (P528) .....	169
Field current limit controller (P317) .....	120	Load control freq. (P527) .....	169

Load control mode (P529).....	170	Oscillation damping (P217).....	112
Load monitoring.....	154, 178	Output choke.....	38
Load monitoring (P525 ... 529).....	168	Overtemperature.....	203
Load monitoring maximum (P525).....	167	Overvoltage.....	206
Load monitoring minimum (P526).....	169	Overvoltage switch-off.....	33
Long-term storage.....	216	<b>P</b>	
<b>M</b>		P - torque limit factor (P111).....	105
Mains choke.....	37	P chopper limit (P555).....	181
Mains voltage Monitoring (P538).....	172	P set last error (P706).....	185
Maintenance.....	255	Par.-identification (P220).....	115
Marking.....	20	Parameter identification.....	115
Mass Inertia PMSM (P246).....	117	Parameter lost.....	206
Master - Slave.....	157	Parameter set (P100).....	99
Master function.....	157	Parameter, Saving mode (P560).....	182
Max. freq. a-in 1/2 (P411).....	135	Password (P004).....	86
Maximum frequency (P105).....	100	Peak current PMSM (P244).....	117
Mechanical Power (P727).....	190	Phase U current (P732).....	191
Menu group.....	80	Phase V current (P733).....	191
Messages.....	199	Phase W current (P734).....	191
microSD card.....	58	PI- process controller.....	226
Min. chopper threshold (P554).....	180	PID control D comp. (P415).....	136
Min. freq. a-in 1/2 (P410).....	134	PID control I comp. (P414).....	135
Minimal configuration.....	75	PID control P comp. (P413).....	135
Minimum frequency (P104).....	100	PLC display value (P360).....	127
Minimum process control frequency (P466).....	150	PLC functionality (P350).....	125
Mode phase sequence (P540).....	173	PLC Integer setpoint (P355).....	126
Mode Rotorpos ident (P336).....	125	PLC Long setpoint (P356).....	126
Modulation depth (P218).....	112	PLC set values (P553).....	180
Module status(P746).....	196	PLC setpoint selection (P351).....	126
Module version (P745).....	196	PLC Status (P370).....	127
Monitoring		PMSM inductance (P241).....	116
Motor temperature.....	76	POSSICON.....	183
Motor cable.....	38	PotentiometerBox function (P549).....	177
Motor choke.....	38	Power limit.....	235
Motor circuit (P207).....	109	Power system stabilisation PMSM VFC (P245).....	117
Motor data..... 70, 107, 203, 211, 244, 247, 249		Present cos phi (P725).....	190
Motor list (P200).....	107	Process controller.....	150, 226
Motor phase sequence (P583).....	183	Product standard.....	229
Motor temperature monitoring.....	76	PT100.....	76
Multi I/O.....	62	PT1000.....	76
<b>N</b>		Pulse Disconnection.....	170
Name plate.....	70	Pulse Disconnection (P537).....	172
No-load current (P209).....	110	Pulse frequency (P504).....	159
Nom.val process ctrl (P412).....	135	Pulse number.....	59
Nominal current (P203).....	108	PZD bus in (P740).....	193
Nominal frequency (P201).....	108	PZD bus out (P741).....	194
Nominal power (P205).....	109	<b>Q</b>	
Nominal speed (P202).....	108	Quick guide.....	75
Nominal voltage (P204).....	108	Quick stop on Error (P427).....	143
NORD		Quick stop time (P426).....	143
System bus.....	240	<b>R</b>	
NORDCON computer.....	241	Ramp smoothing P106.....	101
Norm. BusIO Out Bits (P482).....	155	Ramptime PI setpoint (P416).....	136
Norm. BusIO Out Bits (P483).....	156	Rating point	
<b>O</b>		50 Hz.....	244
OK key.....	64	50Hz.....	247, 249
Op.-time last error (P799).....	198	Ratio encoder (P326).....	122
Operating display.....	62	Reason FI disabled (P700).....	184
Operating state.....	199	reduced output power.....	235
Operating time (P714).....	188	Reluct. angle IPMSM (P243).....	116
Option monitoring (P120).....	106		

Rotary encoder connection.....	59	System bus tunnelling.....	69
Rotation direction.....	173	<b>T</b>	
Running time (P715).....	188	Technical data.....	28, 43, 216, 255
<b>S</b>		Telegram time-out (P513).....	163
Scaling of setpoint/actual values	193, 194, 253	Temperature (P739).....	192
SD card.....	58	Temperature sensor.....	76
Selection display (P001).....	85	Temperature switch .....	33
Selection keys .....	64	Time boost precontrol (P216).....	112
SELECTION keys.....	64	Time DC-brake on (P110).....	104
Set analog output (P542).....	174	Torq curr ctrl limit (P314) .....	119
Set digital out (P541).....	174	Torque (P729).....	190
Setpoint frequency processing .....	254	Torque curr. ctrl. P (P312) .....	119
Setpoint processing .....	224	Torque current controller I (P313).....	119
Setpoints.....	193, 194, 253	Torque current limit (P112) .....	105
Size .....	29	Torque disconnect limit (P534).....	170
SK CI5-.....	37	Torque precontrol (P214).....	111
SK CO1-.....	38	Total currents .....	51
SK CU5-MLT .....	62	TTL encoder.....	60
SK TU5-CTR .....	64	Type code .....	25, 26
Skip frequency 1 (P516).....	164	<b>U</b>	
Skip frequency 2 (P518).....	165	UL/CSA approval .....	219
Skip frequency range 1 (P517).....	165	Usage rate brakeres. (P737) .....	192
Skip frequency range 2 (P519).....	165	Usage rate motor (P738) .....	192
Slip compensation (P212) .....	111	USS address (P512).....	162
Software version (P707).....	185	USS baud rate (P511).....	162
Source control word (P509).....	161	<b>V</b>	
Source Setpoints (P510) .....	162	V/C analog inputs(P709).....	187
Speed controller I (P311).....	119	V/I Analog (P405).....	134
Speed controller P (P310).....	119	V/I Analogue outputs (P710).....	187
Speed ctr. I brake release time (P321) .....	121	Value keys .....	64
Speed encoder (P735) .....	192	VALUE keys.....	64
Speed slip delay (P328) .....	122	Value Masterfunction (P502) .....	157
Speed slip error (P327) .....	122	Vector control.....	114
Standard version .....	14	Ventilation .....	28
Start key.....	64	Voltage –d (P723).....	190
Static boost (P210).....	110	Voltage last error (P704).....	185
Stator resistance (P208).....	109	Voltage –q (P724) .....	190
Status of digital in. (P708) .....	186	<b>W</b>	
Stop key.....	64	Warning information.....	20
Storage .....	216, 255	Warning messages .....	211
Supervisor code (P003).....	86	Warnings .....	199, 211
Switch-off mode (P108).....	103	Watchdog.....	149
Switch-on cycles.....	216	Watchdog time (P460) .....	149
Switch-on/switch-off delay (P475).....	151	Wiring guidelines.....	42
Switchover freq. CFC ol (P331).....	124	<b>M</b>	
Switchover freq.VFC PMSM (P247).....	117	µSD orders (P550).....	177



Headquarters  
Getriebebau NORD GmbH & Co. KG  
Getriebebau-Nord-Str. 1  
22941 Bargteheide, Deutschland  
T: +49 45 32 / 289 0  
F: +49 45 32 / 289 22 53  
info@nord.com